




Programming & Troubleshooting Guide

IntelliPak™ I and IntelliPak™ II

Commercial Single Zone Rooftop Air Conditioner or Commercial Rooftop Air Handlers, with Variable Air Volume (VVDA/VVZT) Controls or Constant Air Volume (CVDA/CVZT) Controls



IntelliPak I models

S*HF*20-75
S*HG*90-130

S*HL*20-75

IntelliPak II models

S*HJ090-162

S*HK*90-130 W*HB, W*HE
W*HCA-C

SAFETY WARNING

Only qualified personnel should install and service the equipment. The installation, starting up, and servicing of heating, ventilating, and air-conditioning equipment can be hazardous and requires specific knowledge and training. Improperly installed, adjusted or altered equipment by an unqualified person could result in death or serious injury. When working on the equipment, observe all precautions in the literature and on the tags, stickers, and labels that are attached to the equipment.



Introduction

Read this manual thoroughly before operating or servicing this unit.

Warnings, Cautions, and Notices

Safety advisories appear throughout this manual as required. Your personal safety and the proper operation of this machine depend upon the strict observance of these precautions.

The three types of advisories are defined as follows:

⚠ WARNING Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

⚠ CAUTION Indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury. It could also be used to alert against unsafe practices.

NOTICE Indicates a situation that could result in equipment or property-damage only accidents.

Important Environmental Concerns

Scientific research has shown that certain man-made chemicals can affect the earth's naturally occurring stratospheric ozone layer when released to the atmosphere. In particular, several of the identified chemicals that may affect the ozone layer are refrigerants that contain Chlorine, Fluorine and Carbon (CFCs) and those containing Hydrogen, Chlorine, Fluorine and Carbon (HCFCs). Not all refrigerants containing these compounds have the same potential impact to the environment. Trane advocates the responsible handling of all refrigerants-including industry replacements for CFCs such as HCFCs and HFCs.

Important Responsible Refrigerant Practices

Trane believes that responsible refrigerant practices are important to the environment, our customers, and the air conditioning industry. All technicians who handle refrigerants must be certified. The Federal Clean Air Act (Section 608) sets forth the requirements for handling, reclaiming, recovering and recycling of certain refrigerants and the equipment that is used in these service procedures. In addition, some states or municipalities may have additional requirements that must also be adhered to for responsible management of refrigerants. Know the applicable laws and follow them.

⚠ WARNING

Proper Field Wiring and Grounding Required!

Failure to follow code could result in death or serious injury. All field wiring **MUST** be performed by qualified personnel. Improperly installed and grounded field wiring poses **FIRE** and **ELECTROCUTION** hazards. To avoid these hazards, you **MUST** follow requirements for field wiring installation and grounding as described in NEC and your local/state electrical codes.

⚠ WARNING

Personal Protective Equipment (PPE) Required!

Installing/servicing this unit could result in exposure to electrical, mechanical and chemical hazards.

- Before installing/servicing this unit, technicians **MUST** put on all PPE required for the work being undertaken (Examples; cut resistant gloves/sleeves, butyl gloves, safety glasses, hard hat/bump cap, fall protection, electrical PPE and arc flash clothing). **ALWAYS** refer to appropriate Material Safety Data Sheets (MSDS)/Safety Data Sheets (SDS) and OSHA guidelines for proper PPE.
- When working with or around hazardous chemicals, **ALWAYS** refer to the appropriate MSDS/SDS and OSHA/GHS (Global Harmonized System of Classification and Labeling of Chemicals) guidelines for information on allowable personal exposure levels, proper respiratory protection and handling instructions.
- If there is a risk of energized electrical contact, arc, or flash, technicians **MUST** put on all PPE in accordance with OSHA, NFPA 70E, or other country-specific requirements for arc flash protection, **PRIOR** to servicing the unit. **NEVER PERFORM ANY SWITCHING, DISCONNECTING, OR VOLTAGE TESTING WITHOUT PROPER ELECTRICAL PPE AND ARC FLASH CLOTHING. ENSURE ELECTRICAL METERS AND EQUIPMENT ARE PROPERLY RATED FOR INTENDED VOLTAGE.**

Failure to follow instructions could result in death or serious injury.

Copyright

This document and the information in it are the property of Trane, and may not be used or reproduced in whole or in part without written permission. Trane reserves the right to revise this publication at any time, and to make changes to its content without obligation to notify any person of such revision or change.

Trademarks

All trademarks referenced in this document are the trademarks of their respective owners.

Revision History

- Minor running edits.
- Addition of ["Fault Detection and Diagnostics,"](#) p. 7
- Addition of configuration screen details in ["CONFIGURATION Menu,"](#) p. 98
- Addition of testing and troubleshooting details in ["SERVICE MODE Menu \(Local Human Interface\),"](#) p. 107
- Additional values added to Active Diagnostic - Auto Reset, see [p. 118](#).



Table of Contents

Introduction	2
Warnings, Cautions, and Notices	2
Copyright	3
Commonly Used Acronyms	5
Glossary of Terms	6
Menu Keys	11
Data Manipulation Keys	12
Unit Operation Keys	13
General Status Display	13
STATUS Menu	26
SETUP Menu	54
Emergency Override Definitions (with LCI or BCI module installed)	66
SETPOINT Menu	86
CONFIGURATION Menu	98
SERVICE MODE Menu (Local Human Interface only)	107
DIAGNOSTICS Menu	116
Diagnostics	122
Module Input / Output Descriptions	150
Index	154

Commonly Used Acronyms

For convenience, a number of acronyms and abbreviations are used throughout this manual. These acronyms are alphabetically listed and defined below.

Table 1. Acronyms

act = active, actuator	IGV = inlet guide vanes
AH = air handler	Indep = Independent
annunc = annunciate	INFO = Information Only (Diagnostic)
AS = airside	I/O = input/output
aux = auxiliary	IOM = installation/operation/ maintenance manual
BAS = Building Automation System	IPAK = IntelliPak I™, IntelliPak II™
BCI = BACnet® Communication Interface Module	IPC = interprocessor communications
ccfm = cfm/100 (ex. 120.5 CCFM = 12050 CFM)	IPCB = Interprocessor Communications Bridge (mod)
cfm = cubic-feet-per-minute	iwc = inches water column
cfg = configured, configuration	LCI = LonTalk® Communication Interface Module
ckt = circuit	LCI-I = LonTalk® Communication Interface for IPAK
cmd = command	LH = left-hand
comp(s) = compressor, compressors	lo = low
cond(s) = condenser, condensers	LON = LonWorks® (Echelon®, etc.)
config = configured, configuration	LRE = leaving recovery exhaust
ctrl = control	max = maximum
CV = constant volume	manif = manifolded
CVDA = Const. Volume airflow/Discharge Air temp ctrl	MCM = Multiple Circuit Module
CVZT = Const. Volume airflow/Zone Temp ctrl	MDM = Modulating Dehumidification Module
cw = clockwise	min = minimum, minute
cww = counterclockwise	misc = miscellaneous
cy = cycle	mod = modulating, module
DCV = Demand Control Ventilation	MPM = Multi-Purpose Module
dflt = default	MWU = morning warm-up
diag = diagnostic	NSB = Night Setback Panel
dmpr = damper	num = number
DWU = daytime warm-up	O/A, OA = outside air
DX = direct expansion (compressor control)	occ = occupied
E/A, EA = exhaust air	OVRD = override
ECEM = Exhaust Comparative Enthalpy Module	PAR = partial system disable, auto reset
econ = economizer, economizing	PMR = partial system disable, manual reset
ent = entering	pos = position
evap = evaporator	O/A, OA = outside air
F/A, FA = fresh air	pot = potentiometer
FDD = Fault Detection and Diagnostics	PPM = parts per million
funct = function	press = pressure
GBAS = Generic Building Automation System (module)	prop = proportional
HEAT = heat, heater, Heat (module)	psig = pounds-per-square-inch gauge pressure
HGBP = hot gas bypass	PWS = part-winding start
HGP = hot gas bypass	R/A, RA = return air
hi = high	refrig = refrigerant
HI = Human Interface (module)	RHI = Remote Human Interface (module)
HO = History Only (Diagnostic)	rpm = revolutions-per-minute
HVAC = heating, ventilation and air conditioning	ICS = Integrated Comfort System

Commonly Used Acronyms

Table 1. Acronyms (continued)

RHI = Remote Human Interface (module)	UCM = unit control module
rpm = revolutions-per-minute	unocc = unoccupied
RT = rooftop unit	VAV = variable air volume
RTM = rooftop module	VCM = Ventilation Control Module
S/A, SA = supply air	vdc = volts dc
SAP = supply air pressure	vent = ventilation
sat = saturated	vfd = variable frequency drive
SCM = Single Circuit Module	VOM = ventilation override module
SF = supply fan	VSM = variable speed (compressor) module
src = source	VSC = variable speed compressor
stg = stage	VVDA = Variable Volume airflow/Discharge Air temp ctrl
stnd = standard	VVZT = Variable Volume airflow/Zone Temp ctrl
stpt, stp = setpoint	w/, w- = with
sw = switch	w/o, wo- = without
sz = single-zone (unit airflow)	w.c. = water column
TCI = Tracer Communications Interface (module)	wu = warm-up
temp = temperature	XL = across-the-line start
RH = right-hand, relative humidity	

Notes:

1. Echelon, LON, LONWORKS, LonBuilder, NodeBuilder, LonManager, LonTalk, LonUsers, Neuron, 3120, 3150, the Echelon logo, and the LonUsers logo are trademarks of Echelon Corporation registered in the United States and other countries. LonLink, LonResponse, LonSupport, LonMaker, and LonPoint are trademarks of Echelon Corporation.
2. BACnet® is a registered trademark of the American Society of Heating, Refrigeration and Air-conditioning Engineers Inc. (ASHRAE.)

Glossary of Terms

Carefully review these definitions since they are used throughout this document and the Installation, Operation, Maintenance Guide (IOM). Knowledge of these terms is essential in gaining an understanding of how these units operate.

Active Setpoints. The setpoint which is currently being used by the specified control.

BACnet. An open, device networking communications protocol for controls. This protocol utilizes BACnet and ANSI/ASHRAE® Standard 135-2004 protocol which provides building owners the capability to connect various types of building control systems or subsystems together

Comparative Enthalpy. An economizer/cooling control strategy which compares return air enthalpy with outdoor enthalpy. If the outdoor enthalpy is significantly less than return enthalpy the economizer will be utilized for cooling.

Compressor Protection Switch. (See Low Pressure Control). A pressure switch installed on the suction line that prevents compressor operation below the switch's setpoint. The purpose is to prevent no-flow scroll compressor operation.

Comm3/4. A Trane proprietary network communication protocol.

Comm5. Trane's implementation of LonTalk (an open network communication protocol).

Condenser Pressure. The saturated condenser pressure measured on each circuit's condenser section on Evaporative Condenser units. Condenser pressure is converted to Saturated Condenser Temperature for display on the Human Interface. The data from these sensors is used in head pressure control.

Control Band. The range of temperatures, pressures or humidity which would normally be maintained by the various control functions.

Control Point. The value of a setpoint that an algorithm is using at any given time.

Deadband. A narrow band of sensor range equally spaced above and below the setpoint that defines a region where the algorithm will be satisfied and the controlled output will be maintained without change.

Dehumidification Override High Zone Temp. The temperature in the critical zone on VAV units where Dehumidification is disabled to prevent over-heating the space due to excess reheat.

Dehumidification Override Low Zone Temp. The temperature in the critical zone on VAV units where Dehumidification is disabled to prevent sub-cooling the space due to insufficient reheat.

Demand Control Ventilation (DCV). An ASHRAE compliant ventilation scheme that varies the Outside Air Damper minimum position or Fresh Air Flow (TRAQs) between minimum and maximum ventilation Setpoints based on CO2 level.

Dry Bulb. An outdoor temperature above which economizing will be disabled (unless comparative enthalpy is the economizer control type being used.)

Economizer Zone Temp Setpoint Suppression. A parameter used for setting the active economizer cooling control point to a value lower than the Zone Temp Cooling Setpoint to optimize economizer operation.

Emergency Stop. A binary input on the RTM, connected to a field-supplied switch, when set to OPEN causes a unit shutdown with a manual reset diagnostic.

Energy Recovery Wheel. A wheel that rotates through the outdoor and exhaust air streams, transferring energy between the two, to optimize unit efficiency.

Evap Diff. Evaporator Differential is a parameter indicating performance of a refrigeration system. It is calculated by determining the difference between the entering and leaving temperatures of the evaporator. If this value rises too high it may indicate a problem with the system.

External Stop. A binary input on the RTM, connected to a field-supplied switch, when set to OPEN causes a unit stop request.

Fault Detection and Diagnostics. A feature that determines whether the Outside Air damper actuator has failed to control the damper properly, and annunciates specific diagnostics under such conditions.

Hot Gas Bypass. A feature to reduce a refrigeration circuit's cooling capacity by bypassing hot discharge line refrigerant directly to the evaporator coil of the system to more effectively operate in low load conditions.

Humidification Control. During modes of continuous fan operation a relay is energized when the Humidity measured in the controlled space drops below an adjustable Humidification Setpoint. The humidifier device is a user supplied device placed in the supply air stream.

IntelliPak™ I. Units covering the 20 through 130 ton capacity IntelliPak cabinet sizes, and containing the latest control modules and software.

IntelliPak™ II. Units covering the 90 through 150 ton capacity IntelliPak II cabinet sizes, and containing the latest control modules and software.

LonTalk®. An open, device networking communications protocol for controls. This protocol is defined in ANSI approved typical EIA/CEA-709.1-A-1999.

Low Ambient Compressor Lockout. A function which prevents compressor operation at low outdoor ambient temperatures.

Low Vi Compressor Operation. Enhancements to the compressor control will be implemented on units with Low Vi compressors installed, which will insure optimized compressor operation at all times.

Night SetBack (NSB). Applies to the control of the rooftop unit during unoccupied periods. Also refers to the NSB panel, a communicating wall sensor with night setback capability.

Rapid Restart. Certain unit applications require override of the normal unit startup sequence after a power outage. Target cooling requirements are established within a specified time to meet extreme high return air temperatures.



Commonly Used Acronyms

Reference Enthalpy. An outdoor enthalpy value, set at the HI, above which economizing will be disabled.

Remote Human Interface. (See Interprocessor Communication Module). A human interface module designed to be mounted remotely from the unit. There are some functional differences between a unit mounted and a remote mounted human interface module.

Reset Amount Maximum. An adjustable parameter on the HI where the maximum amount of reset allowed is defined.

Reset End Temperature. The temperature at which the maximum reset amount will occur.

Reset Start Temperature. The temperature at which reset will begin.

Return Fan Control. . Return Fan Control is a feature which allows units to operate at a higher external or duct system static pressure, or to reduce the load (horsepower requirement) on the supply fan motor. The fan is placed in the return air path.

Return Fan Plenum Pressure. The area between the Exhaust and Return Dampers and the outlet of the Return Fan defines the return plenum. The absolute static pressure measured in this area is the Return Fan Plenum Pressure.

Return Plenum Pressure High Limit. This control feature, available on all return fan options, shuts the supply fan and return fan off if the pressure in the return plenum exceeds a non-adjustable setpoint of 3.5 iwc.

Space Pressure. The pressure in the building as measured by the space pressure transducer, referenced to outside (atmospheric) pressure.

Single Zone Variable Air Volume. The active discharge air setpoint, used for cooling, heating and supply fan speed control, is based on the zone temperature load conditions.

Supply Air Pressure High Limit. A pressure limit to prevent unit casing and/or ductwork over pressurization.

Statitrac™. A control method to maintain proper space pressurization.

Supply Air Pressure. The pressure in inches-water-column (IWC) of the supply duct plenum or outlet as measured by the supply air pressure transducer, referenced to local outside (atmospheric) pressure.

Supply Air Tempering. An active heating mode where the supply air temperature has dropped below a preset value, usually due to cold outside air being brought in to provide building ventilation.

Supply Air Temperature Control Point. The revised value of SATemp Setpoint after supply air temperature reset has been applied.

Supply Air Temperature Reset. A function that shifts the SATemp Setpoint an amount based on the value of another parameter—typically ZoneTemp or Outdoor AirTemp. The purpose of this function is to lower unit capacity to better meet load requirements.

Target Setpoints. An internally calculated control point which is typically derived from other setpoints in combination with specific unit operating conditions.

Variable Speed Compressor. An inverter driven compressor that has the capability to provide continuous-incremental cooling capacity control.

UCM Control System

Trane Large Commercial Rooftop Units are controlled by a microelectronic control system that consists of a network of modules and are referred to as Unit Control Modules (UCM).

The unit size, type VVDA (VAV w/ IGV/VFD), SZxx (SZVAV), RRXX (Rapid Restart), CVDA (VAV w/o IGV/VFD), CVZT (CV), VVZT (SZVAV), heating functions, peripheral devices, options, exhaust capabilities, etc. determine the number and type of modules that a particular rooftop unit may employ.

The **UCM** receives analog or binary inputs, then processes this information and supplies outputs in the form of modulating voltages, contact closures, etc. to control damper actuators, fan motors, compressors, valves, electric heating coils and other electrical devices in the unit to maintain set comfort levels.

The UCM provides some equipment protection functions both directly and indirectly, such as duct pressure limits and compressor lockouts.

Listed below are the various modules that may be employed in a UCM control system.

Rooftop Module (1U1 IntelliPak II / 1U48 IntelliPak I)

(standard on all units)The **RTM** is the central processor of the system. It continuously receives information from the other unit modules, sensors, the remote control panel, and customer supplied relays. It then interprets this information and responds to cooling, heating, and ventilation requests by directing the other modules in the system to energize the proper unit components. It also directly initiates supply and exhaust fan operations, and economizer operation.

Compressor Module (1U3 IntelliPak II / 1U49 IntelliPak I)

(compressor control, head pressure control, evaporative condensing)The **SCM/MCM** module upon receiving a request for mechanical cooling staging from the RTM, energizes the appropriate compressors. It provides protection of the refrigerant circuit through feedback information it receives from various protection devices. It provides the necessary sensor interface to provide both air-cooled and water-cooled condenser head-pressure control.

Heat Module (1U6 IntelliPak II / 1U50 IntelliPak I)

(staged heat, modulating heat, air-handler chill water valve control)The **HEAT** module, directs the unit's heater to stage up, down, or modulate to bring the controlled temperature to within the applicable heating setpoint. Chill water valve control is handled by the modulating output and is coordinated with the heat control to insure proper cooling and heating operation.

Exhaust/Comparative Enthalpy Module (1U5 IntelliPak II / 1U52 IntelliPak I)

(Statitrac building pressure control, comparative enthalpy)The **ECM** receives data from the return air humidity sensor, the return air temperature sensor, and the return air space pressure transducer to control the economizer, exhaust fan and the exhaust dampers to maintain set space pressure.

Ventilation Control Module (7U14 IntelliPak II / 3U218 IntelliPak I)

(TRAQ dampers, DCV, outdoor air preheat)The **VCM** receives data from two velocity pressure sensors associated with front and back TRAQ assemblies to measure fresh air flow entering the unit. These measurements are converted to CFM and added to give total fresh air flow. This value can be used for monitoring purposes, to maintain flow to a minimum fresh air flow Setpoint, or to maintain appropriate CO₂ levels in the controlled space using its space CO₂ sensor input and the DCV feature. Without TRAQ assemblies installed the VCM can use DCV and the CO₂ sensor input to control OA Damper minimum position to maintain CO₂ levels in the space. A preheat control relay output is also provided on this module to maintain tempered outdoor air during ventilation using the VCM Auxiliary Temperature input. The preheat unit is user-supplied.

Multi Purpose Module (1U9 IntelliPak II / 1U105 IntelliPak I)

(return fan, energy recovery wheel, evaporative condensing)The **MPM** supports the function of return plenum pressure control by providing inputs for measuring return plenum pressure, calibrating that reading, and providing an output to control the return fan speed (if variable speed configured) in response to control algorithm requests. Energy Wheel control along with bypass damper control, and interface to the saturated condensing pressure sensors for evaporative condensing head-pressure control.

Modulating Dehumidification Module (1U15 IntelliPak II / 1U107 IntelliPak I)

(dehumidification hot gas reheat)The **MDM** supports specific control inputs and outputs for modulating dehumidification control including modulating reheat and cooling valve control as well as the reheat pumpout coil relay output.

Generic Building Automation System Module (1U10 GBAS(0-5VDC) / 1U11 GBAS(0-10VDC) IntelliPak II) or (1U51 – GBAS(0-5VDC)/(0-10VDC) IntelliPak I)

(interface to third party BAS controls)The **GBAS** modules allows a non-Trane building control system to communicate with the unit and accepts external Setpoints in form of analog inputs (0 - 5V or 0 - 10V depending on the module selected) and a binary Input for demand limit. Five (5) binary outputs are available on 0 - 5V modules. One (1) binary output and four (4) analog outputs are available on the 0 - 10V modules. Refer to the "Field Installed Control Wiring" section of the

Commonly Used Acronyms

Unit Installation, Operation, Maintenance Manual (IOM) for the control wiring to the GBAS module and the various desired Setpoints with the corresponding DC voltage inputs.

Ventilation Override Module (1U8 IntelliPak II / 1U53 IntelliPak I)

(special ventilation unit operation) The VOM module provides the necessary I/O interface to third party customer controls and allows specific override operation of the unit's air handling functions such as space pressurization, exhaust, purge, unit off, etc.

Variable Speed Module (1U123 IntelliPak I)

(variable speed compressor operation) The VSM module provides the necessary I/O interface to control variable speed compressor drives.

Interprocessor Communications Bridge (1U12 IntelliPak II / 1U55 IntelliPak I)

(communications isolation for remote human interface, external IPC wiring) The IPCB module expands communications from the unit UCM network to a Remote Human Interface Panel. DIP switch settings on the IPCB module for this application should be; Switches 1 and 2 "Off", Switch 3 "On". This module is used to isolate the unit communications bus from the outside wiring, and any potential wiring faults that may occur.

BACnet® Communication Interface Module (1U66 IntelliPak II / 1U104 IntelliPak I)

(used on units with Trane ICS or 3rd party Building Automation Systems) The BCI module expands communications from the unit UCM network to a Trane Tracer Summit, or a 3rd party building automation system that utilizes BACnet, and allows external Setpoint and configuration adjustment and monitoring of status and diagnostics.

Lontalk® Communication Interface Module (1U7 IntelliPak II / 1U65 IntelliPak I)

(used on units with Trane ICS or 3rd party Building Automation Systems) The LCI module expands communications from the unit UCM network to a Trane Tracer Summit, or a 3rd party building automation system that utilizes LonTalk, and allows external Setpoint and configuration adjustment and monitoring of status and diagnostics.

Human Interface Module (Local = 1U2, Remote = 9U13 IntelliPak II) (1U65 IntelliPak I)

(standard on all units) The LHI and RHI (Local and Remote Human Interface) share a similar keypad which is illustrated, see [Figure 1. Human Interface Module](#) on page 11. This device enables the customer, building owner, or contractor, to communicate to the Rooftop unit the necessary parameters for unit operation such as cooling and heating Setpoints, demand limiting, ventilation override modes, etc

The local (unit mounted) Human Interface and the Remote Human Interface Panel functions are identical, except for Service mode which is not available on the Remote Human Interface Panel.

The local HI Module is located in the unit's main control panel. A small door located in the unit's control panel door allows access to the HI Module's keypad and display window.


There is a 2 line by 40 character LCD screen which provides status information for the various unit functions as well as menus used to set or modify the operating parameters. There is a 16 key keypad adjacent to the LCD screen, which allows the operator to scroll through the various menus and make adjustments to the setpoints, etc.

The LCD screen has a backlight that makes the information easier to read. The light will go out if no keys are pressed for 30 minutes. If it goes out, simply press the Status key.

The information displayed in the LCD window will be top-level status information unless the operator initiates other displays.

At power-up, the Human Interface LCD will display one of four initial screens illustrated in the "General Status" section.

Figure 1. Human Interface Module



Menu Keys

The six main menu keys illustrated in [Figure 2. Human Interface Keypad](#), (**Status**, **Setpoints**, **Setup**, **Configuration**, **Diagnostics**, and **Service Mode**) are used to bring up the various interactive menus where the user inputs and accesses unit operating data. Pressing these keys will display the initial screen for the menu designated by the key's name. The following information describes the keys and their functions when viewing the various menus.

Note:

1. If no key is pressed for 30 minutes while the LCD is displaying a menu screen, it will revert back to the unit operating status screen.

Status Key

Pressing the **Status** key causes the LCD to display the operating status screen; i.e. "On"; "Unit Stop"; "External Stop"; "Emergency Stop"; "Service Mode". Pressing the **Next** key allows the operator to scroll through the screens which provide information such as air and refrigerant temperatures, humidity levels, fan operation, compressor operation, heater operation, economizer positioning, exhaust operation, as well as heating, cooling, and compressor lockout setpoints. Pressing the **Status** key while viewing any of the data screens will cause the LCD to go back to the operating status screen.

Commonly Used Acronyms

Setpoints Key

Pressing the **Setpoints** key will cause the LCD screen to display the first of the setpoint screens where the operator will designate default temperature and pressure setpoints. While scrolling through the setpoint screens, pressing this key again will cause the LCD to display the first setpoint screen.

Diagnostics Key

Pressing the **Diagnostics** key at any time will allow the operator to view any active unit diagnostics, or 20 of the most recently logged unit diagnostics. The LCD screen will display one of the diagnostic screens (depending on which diagnostic, if any, is present). If no key is pressed for 30 minutes while the screen is displaying diagnostic information, it will revert back to the operating status display.

Configuration Key

Pressing the **Configuration** key will cause the LCD screen to display the first of the configuration screens where the operator will designate unit configuration data such as unit type, capacity, system control, etc.

This information was programmed at the factory. Pressing the configuration key at any level in the configuration menu will display the first configuration screen.

Note:

1. This key should be used if the unit's configuration data is lost or new options are added in the field, and to view current configuration.
2. The **Stop** key must be pressed prior to making any changes under the Configuration menu.

Setup Key

Pressing the **Setup** key will cause the LCD screen to display screens where the operator will designate various operating parameters such as temperature and pressure ranges, limits, percentages, setpoint source selections, and sensor input definitions for the control of the rooftop unit's various operating modes. Pressing the **Setup** key at any level in the setup menu will display the first setup screen.

Service Mode Key

Pressing the **Service Mode** key causes the LCD to display the first of the service test mode screens showing various unit components which may be turned on or off for the particular test being performed. Once the status of these components is designated, the LCD will display screens that allow the operator to designate the TEST START time delay for each test.

Data Manipulation Keys

The six data manipulation keys illustrated in [Figure 2. Human Interface Keypad](#) on page 14, (**Enter**, **Cancel**, **+** (**Plus**), **-** (**Minus**), **Previous**, and **Next** are used to modify the data within the screens (change values, move the cursor, confirm choices)

Enter Key

The **Enter** key will confirm the new values that were designated by pressing the **+** (**Plus**) or **-** (**Minus**) keys at all edit points. When viewing status and diagnostics screens, it has no function.

Cancel Key

After changing data, at an editable screen, but before confirming it with the **Enter** key, pressing the **Cancel** key will return the data to its previous value. This key shall also function to clear active diagnostics.

+ (Plus) Key

When viewing a setpoint screen, this key will increase the value of the displayed item per the units selected. When working with a status menu, it will add the current status display to the CUSTOM MENU. When viewing setup, or service test screens, it will proceed forward through all the selections of that menu item, increase setpoints, toggle choices OFF to ON, DISABLED to ENABLED.

- (Minus) Key

When viewing a setpoint screen, this key will decrease the value of the displayed item per the units selected. When working with a CUSTOM MENU, it will delete the current selected display. When viewing setup, or service test screens, it will proceed backwards through all the selections of that menu item, decrease setpoints, toggle choices ON to OFF, ENABLED to DISABLED.

Next Key

Pressing the **Next** key causes the LCD to scroll forward through the various displays for each menu. At displays with multiple edit points it moves the cursor forward from one edit point to another.

Previous Key

Pressing the **Previous** key causes the LCD to scroll backward through the various displays for each menu. At displays with multiple edit points, it moves the cursor backward from one edit point to another.

Unit Operation Keys

The four unit operation keys (**Auto, Stop, Test Start, Custom**) are used to control and monitor the unit in normal operating mode, and also to initiate an active unit service test event.

Auto Key

Pressing the **Auto** key at any time will cause the display to go to the top level status display and, if the unit is shutdown, will cause the unit to begin operation in the appropriate mode no matter what level in the menu structure is currently being displayed. If the current display is an editable display, the **Auto** key will confirm the desired edit point similar to the **Enter** key.

Stop Key

Pressing the **Stop** key will cause the unit to transition to the stop state. If the current display is editable, pressing the **Stop** key will cancel the desired edit similar to the **Cancel** key. Prior to making any changes to the configuration menu screens, the **Stop** key must be pressed.

Test Start Key (Service Test Mode Start)

Pressing the **Test Start** key while viewing any screen in the *Service Mode Menu* will start the service test. Pressing this key while displaying any screen other than the *Service Mode Menu* will not start the service test, and has no other function.

Custom Key

Pressing the **Custom** key will change the display to the *Custom Menu*. This menu is simply a status menu that contains screens that the user monitors most frequently. The custom menu can only contain five status screens. To create the custom menu, press the **Status** key, followed by the **Next** key (this brings up the initial status screen). If you want to add this screen to the custom menu, press the **+ (Plus)** key, if not, press the **Next** key again until a status screen appears that you would like to add to the custom menu. Pressing the **+ (Plus)** key while viewing any of the various status screens will add that screen to the custom menu. Once the custom menu is programmed it can be accessed by pressing the **Custom** key. To remove a status screen from the custom menu, press the **Custom** key, then press the **Next** key until the status screen that you want to remove appears, then press the **- (Minus)** key.


General Status Display

Anytime the rooftop unit is powered up, or the **Status, Auto, or Stop** keys are pressed, the unit mounted Human Interface will display one of the following general status display screens. The operator will then be able to enter keystrokes which will allow him to navigate through a set of menus and submenus in order to provide/access various monitoring, setup,

General Status Display

and configuration information. The Human Interface will not display screens or parts of screens for which the unit is not configured.

Figure 2. Human Interface Keypad



Unit "Off" or "Stopped"

If at power up the unit is not running, the following display will appear on the Human Interface LCD screen. When this screen is being displayed, the only functional keys are the six menu keys (**Status, Setpoints, Diagnostics, Setup, Configuration, and Service Mode**), the **Auto** key, the **Custom** key, and the **Stop** key.

Stop by Network Initializing	Supply Fan ON Diagnostics
---------------------------------	------------------------------

Used With: Top Status Display
(Shown when unit is off or stopped)

Possible Values:
[see field descriptions at left]

Top Left Field:

Unit Off
Unit Stopped
External Stop
Emergency Stop
Stop by Network
Unit Starting
Service Mode Off

Top Right Field:

Supply Fan OFF
Supply Fan ON

Bottom Left Field:

(blank)
Shutdown
Initializing
Freeze Avoidance
Active

Bottom Right Field:

(blank)
(Diagnostics)

Unit "On"

If the unit has entered an operating state (running), the following display will appear on the Human Interface LCD screen. When this screen is being displayed, the only functional keys are the six menu keys (**Status, Setpoints, Diagnostics, Setup, Configuration, and Service Mode**), the **Auto** key, the **Custom** key, and the **Stop** key.

VVDA OA Flow 380.0 CCFM Occupied Cool 2	Supply Fan ON Diagnostics
--	------------------------------

Used With: Top Status Display
(Shown when unit is on)

Possible Values:
[see field descriptions at left]

Top Left Field:

CVZT
VVDA
CVDA
VVZT

Top Middle Field:

(blank)
OA Flow 0 to 500
CCFM
Freeze Avoidance

Top Right Field:

Supply Fan ON
Supply Fan OFF

Bottom Left Field:

(blank)
Occupied
Unoccupied
MorningWU
DaytimeWU
Standby
Shutdown
Occupied TOV
Initializing
Tempering
Rapid Restart

Bottom Middle Field:

(blank)
Heat 1 to 6
Cool 1 to 4
OA Dmpr 0 to 100 %
Dehumid
Purge
Humidify
SA Fan 0 to 100%

Bottom Right Field:

(blank)
Diagnostics



General Status Display

“Emergency Override” Active

If the unit has entered an Emergency Override mode of operation, one of the following displays will appear on the Human Interface LCD screen.

Ventilation Override Mode PRESSURIZE	Diagnostics
---	-------------

Used With: LCI or BCI Options

Top Left Field:

Top Right Field: (blank)

Bottom Left Field:

PRESSUREIZE

DEPRESSURIZE

PURGE

SHUTDOWN

FIRE

Bottom Right Field:

Diagnostics (Trouble Indicator)

(blank)

“VOM” Active

If at power up the unit is running and has entered a Ventilation Override mode of operation, the following display will appear on the Human Interface LCD screen.

Ventilation Override Mode	A	Diagnostics
---------------------------	---	-------------

Used With: VOM Option

Possible Values:

Top Right Field: A, B, C, D, E, OFF

Bottom Left Field:

(blank)

Bottom Right Field:

Diagnostics (Trouble Indicator)

(blank)

“No Configuration” Condition

If at power up the unit has not been programmed with the necessary configuration data for normal unit operation, the following display will appear on the Human Interface LCD screen. When this screen is being displayed, the only functional key is the **Configuration** key.

Note: This screen will only appear when the RTM has been field replaced. Refer to the Configuration Menu section.

NO CONFIGURATION PRESENT PRESS CONFIGURATION KEY

Used With: All Units

Factory Presets

The UCM controlled unit has many operating functions which are preset at the factory, but may be modified to meet the unique requirements of each job. The following list in [Table 2](#), identifies each of the unit's adjustable functions and the value assigned to it. If these factory presets match the application's requirements, simply press the **Auto** key at the Human Interface module to begin unit operation (after completing the Pre-Start and Start-Up procedures in the Installation, Operation, and Maintenance manual). If the application requires different settings, turn to the listed page beside the function, press the designated function menu key, then press and hold the **Next** or **Previous** key until its screen appears on the LCD. Once the proper screen appears, simply follow the programming instructions given below the applicable screen in this manual.

Note: Listed items availability is dependent on unit configuration.)

Table 2. Factory Presets List (Note: Listed Items availability is dependent on unit configuration.)

Adjustable Function	Factory Preset	Changed To	To adjust press...
General Function			
Unit Address (Comm3/Comm4only)	1	_____	Setup
System Mode	Auto	_____	Setup
Supply Fan Mode	Auto	_____	Setup
Unit Start Delay	0	_____	Setup
Single Zone VAV Econ Control	Enabled	_____	Setup
Single Zone VAV Heat Control	Disabled	_____	Setup
Daytime Warm-up	Disabled	_____	Setup
Morning Warm-up	Enabled	_____	Setup
Morning Warm-up type	Cycling	_____	Setup
Supply Air Tempering	Disabled	_____	Setup
Unoccupied Mechanical Cooling	Enable	_____	Setup
Unoccupied Heating	Enable	_____	Setup
Unoccupied Mechanical Cooling	Enable	_____	Setup
Unoccupied Heating	Enable	_____	Setup
Occupied Dehumidification	Enable	_____	Setup
Unoccupied Dehumidification	Enable	_____	Setup
Occupied Humidification	Disable	_____	Setup
Unoccupied Humidification	Disable	_____	Setup
Rapid Restart Economizer Control	Disable	_____	Setup
VCM Preheat Output	Disable	_____	Setup
Demand Limit Definition - Cooling	None	_____	Setup
Demand Limit Definition - Heating	None	_____	Setup
Compressor Lead/Lag	Enable	_____	Setup
Evap Temperature Limit	35 F	_____	Setup
Coil Frost Cutout Temp	30 F	_____	Setup
Isolation Damper Interlock	Disable	_____	Setup
Information Format			
Display Text	English	_____	Setup
Display Units	English	_____	Setup
VAV Control			
SA Temp Reset Cool	None	_____	Setup



General Status Display

Table 2. Factory Presets List (continued)(Note: Listed Items availability is dependent on unit configuration.)

Adjustable Function	Factory Preset	Changed To	To adjust press...
Reset Cool Start Temp (Zone/OA)	(72/90)	_____	Setup
Reset Cool End Temp (Zone/OA)	(69/70)	_____	Setup
Reset Cool Max Amount	5	_____	Setup
SA Temp Reset Heat	None	_____	Setup
Reset Heat Start Temp (Zone/OA)	(65/10)	_____	Setup
Reset Heat End Temp (Zone/OA)	(68/60)	_____	Setup
Reset Heat Max Amount	10	_____	Setup
VAV Box Stroke Time	6 Min	_____	Setup
Max Occ. IGV/VFD Command	100 %	_____	Setup
Economizer Control			
Economizer Control Enable Type	Drybulb	_____	Setup
Unoccupied Economizer	Enable	_____	Setup
Head Pressure Control			
Sump Drain Relay Control (on power loss)	Drain	_____	Setup
Sump Purge Interval Time	Disabled	_____	Setup
Sump Purge Duration Time (IPak-I/IPak-II) ^(a)	(120/60 sec.)	_____	Setup
Sump Water Heater Setpoint	38 F	_____	Setup
Low Limit (Air-cooled/Water-cooled) ^(a)	(80/70 deg F)	_____	Setup
Upper Limit	120 deg F	_____	Setup
Temporary low limit suppression	20 deg F	_____	Setup
Efficiency check point	105 deg F	_____	Setup
Low amb. control point (Air-cooled/Water-cooled) ^(a)	(90/80 deg F)	_____	Setup
Alternate Refrigerant Type ^(a)	Disabled	_____	Setup
Sensor Source Selection			
Daytime Warm-Up	RTM Zone Temp	_____	Setup
Occupied Zone Control	RTM Zone Temp	_____	Setup
Unoccupied Zone Control	RTM Zone Temp	_____	Setup
Morning Warm-Up	RTM Zone Temp	_____	Setup
Space Humidity Control	RTM Space Humidity	_____	Setup
Dehumid OVRD Zone Temp	RTM Zone Temp	_____	Setup
Zone Reset Function	RTM Zone Temp	_____	Setup
Rapid Restart Function	ECEM Return Temp	_____	Setup
Monitor	RTM Zone Temp	_____	Setup
Outside Air Ventilation			
Demand Control Ventilation	Disable	_____	Setup
Active/Passive DCV Control	Passive	_____	Setup
OA Flow Compensation	Enabled	_____	Setup
OA Flow CO2 Reset (IPak-INon-DCV)	Disabled	_____	Setup
CO2 Start (IPak-I Non-DCV)	800	_____	Setup
CO2 Max (IPak-I Non-DCV)	1000	_____	Setup

Table 2. Factory Presets List (continued)(Note: Listed Items availability is dependent on unit configuration.

Adjustable Function	Factory Preset	Changed To	To adjust press...
OA Flow Calibration Gain (Left)	1.0	_____	Setup
OA Flow Calibration Offset (Left)	0 CFM	_____	Setup
OA Flow Calibration Gain (Right)	1.0	_____	Setup
OA Flow Calibration Offset (Right)	0 CFM	_____	Setup
OA Normalization	100 CCFM	_____	Setup
OA Flow Calibration Data - Altitude:	0 Ft	_____	Setup
RTM Alarm Output Definition	Any Active Diagnostic	_____	Setup
GBAS Input/Output Definitions			
GBAS (0-5) Analog Input 1 Definitions	Not Assigned	_____	Setup
GBAS (0-5) Analog Input 2 Definitions	Not Assigned	_____	Setup
GBAS (0-5) Analog Input 3 Definitions	Not Assigned	_____	Setup
GBAS (0-5) Analog Input 4 Definitions	Not Assigned	_____	Setup
GBAS (0-5) Output 1 Definitions	Not Assigned	_____	Setup
GBAS (0-5) Output 2 Definitions	Not Assigned	_____	Setup
GBAS (0-5) Output 3 Definitions	Not Assigned	_____	Setup
GBAS (0-5) Output 4 Definitions	Not Assigned	_____	Setup
GBAS (0-5) Output 5 Definitions	Not Assigned	_____	Setup
GBAS (0-10) Analog Input 1 Definitions	Not Assigned	_____	Setup
GBAS (0-10) Analog Input 2 Definitions	Not Assigned	_____	Setup
GBAS (0-10) Analog Input 3 Definitions	Not Assigned	_____	Setup
GBAS (0-10) Analog Input 4 Definitions	Not Assigned	_____	Setup
GBAS (0-10) Output 1 Definitions	Not Assigned	_____	Setup
GBAS (0-10) Output 2 Definitions	Not Assigned	_____	Setup
GBAS (0-10) Output 3 Definitions	Not Assigned	_____	Setup
GBAS (0-10) Output 4 Definitions	Not Assigned	_____	Setup
GBAS (0-10) Output 5 Definitions	Not Assigned	_____	Setup
Ventilation Override Definition	See Definitions	_____	Setup
Temperature Input Offset for...			
RTM Zone Temperature	0 deg F	_____	Setup
RTM Aux Temperature	0 deg F	_____	Setup
Outdoor Air Temperature	0 deg F	_____	Setup
Heat Aux Temperature	0 deg F	_____	Setup
Return Air Temperature	0 deg F	_____	Setup
Device Characteristics...			
Outside Air Damper (if equipped)			
Actuator Setup	Direct	_____	Setup
Max Stroke Time	30 sec	_____	Setup
Max Voltage	10 VDC	_____	Setup



General Status Display

Table 2. Factory Presets List (continued)(Note: Listed Items availability is dependent on unit configuration.)

Adjustable Function	Factory Preset	Changed To	To adjust press...
Min Voltage	2 VDC	_____	Setup
Supply Fan IGV/VFD (if equipped)			
Actuator Setup	Direct	_____	Setup
Max Stroke Time	30/0 sec	_____	Setup
Max Voltage	10 VDC	_____	Setup
Min Voltage	2 VDC	_____	Setup
Return Fan VFD (if equipped)			
Actuator Setup	Direct	_____	Setup
Max Stroke Time	60/0 sec	_____	Setup
Max Voltage	10 VDC	_____	Setup
Min Voltage	2 VDC	_____	Setup
Exhaust Damper/VFD (if equipped)			
Actuator Setup	Direct	_____	Setup
Max Stroke Time	60 sec	_____	Setup
Max Voltage	10 VDC	_____	Setup
Min Voltage	0 VDC	_____	Setup
Hydronic Heat (if equipped)			
Actuator Setup	Direct	_____	Setup
Max Stroke Time	60 sec	_____	Setup
Max Voltage	10 VDC	_____	Setup
Min Voltage	2 VDC	_____	Setup
Low Ambient Damper Ckt-1 (if equipped)			
Actuator Setup	Direct	_____	Setup
Max Stroke Time	60 sec	_____	Setup
Max Voltage	10 VDC	_____	Setup
Min Voltage	2 VDC	_____	Setup
Low Ambient Damper Ckt-2 (if equipped)			
Actuator Setup	Direct	_____	Setup
Max Stroke Time	60 sec	_____	Setup
Max Voltage	10 VDC	_____	Setup
Min Voltage	2 VDC	_____	Setup
Cond Fan VFD Ckt -1(if equipped)			
Actuator Setup	Direct	_____	Setup
Max Stroke Time	60 sec	_____	Setup
Max Voltage	10 VDC	_____	Setup
Min Voltage	0 VDC	_____	Setup

Table 2. Factory Presets List (continued)(Note: Listed Items availability is dependent on unit configuration.

Adjustable Function	Factory Preset	Changed To	To adjust press...
Cond Fan VFD Ckt-2 (if equipped)			
Actuator Setup	Direct	_____	Setup
Max Stroke Time	60 sec	_____	Setup
Max Voltage	10 VDC	_____	Setup
Min Voltage	0 VDC	_____	Setup
Modulating Gas Heat Actuator (if equipped)			
Actuator Setup (Ipak-I/Ipak-II) ^(a)	(Direct/Reverse)	_____	Setup
Max Stroke Time	90 sec	_____	Setup
Max Voltage	10 VDC	_____	Setup
Min Voltage (Ipak-I/Ipac-II) ^(a)	(5 VDC/2 VDC)	_____	Setup
Outdoor Air Bypass Damper (if equipped)			
Actuator Setup	Direct	_____	Setup
Max Stroke Time	60 sec	_____	Setup
Max Voltage	10 VDC	_____	Setup
Min Voltage	2 VDC	_____	Setup
Exhaust Bypass Damper (if equipped)			
Actuator Setup	Direct	_____	Setup
Max Stroke Time	60 sec	_____	Setup
Max Voltage	10 VDC	_____	Setup
Min Voltage	2 VDC	_____	Setup
Variable Speed Comp (if equipped)			
Actuator Setup	Direct	_____	Setup
Max Stroke Time	30 sec	_____	Setup
Max Voltage	10 VDC	_____	Setup
Min Voltage	0 VDC	_____	Setup
Control Algorithm Tuning Parameters (Partial)^(a)			
VAV Cooling Control Gains			
Proportional (w-VSC / wo-VSC)	(2.0%/F/3.3%/F)	_____	Setup
Reset Time (w-VSC/wo-VSC)	(100 Sec/50 Sec)	_____	Setup
Zone Control Occupied Heating Proportional Gain			
IPak I Gas	30.0 deg F	_____	Setup
IPak I Electric	45.0 deg F	_____	Setup
IPak II Gas	30.0 deg F	_____	Setup
IPak II Electric-90 kw	45.0 deg F	_____	Setup
IPak II Electric -140 kw	60.0 deg F	_____	Setup
IPak II Electric-265 kw	75.0 deg F	_____	Setup
IPak II Electric-300 kw	75.0 deg F	_____	Setup



General Status Display

Table 2. Factory Presets List (continued)(Note: Listed Items availability is dependent on unit configuration.)

Adjustable Function	Factory Preset	Changed To	To adjust press...
CV Air Economizer Control Gains			
Proportional	10.0 % F	_____	Setup
Reset Time	DISABLE	_____	Setup
Rate Time	0 Sec	_____	Setup
Bias	0 deg F	_____	Setup
SZVAV Cooling Control Gains			
Proportional	6.0 % F	_____	Setup
Reset Time	1200 Sec	_____	Setup
Rate Time	0 Sec	_____	Setup
Bias	0 deg F	_____	Setup
Zone Control Modulating Heat Gains			
Proportional	10.0 % F	_____	Setup
Reset Time	DISABLE	_____	Setup
Rate Time	0 Sec	_____	Setup
Bias	0 deg F	_____	Setup
SZVAV Heating Control Gains			
Proportional	8.0% F	_____	Setup
Reset Time	1200 Sec	_____	Setup
Rate Time	0 Sec	_____	Setup
Bias	0 deg F	_____	Setup
Rapid DX Interstage Timing	30 Sec	_____	Setup
Default Setpoints			
Supply Air Cooling (VAV/SZVAV) ^(a)	(55 F/50 F)	_____	Setpoints
Supply Air Heating (VAV/SZVAV) ^(a)	(100 F/105 F)	_____	Setpoints
SA Cool Deadband	8.0 F	_____	Setpoints
SA Heat Deadband	4.0 F	_____	Setpoints
DWU Initiate	67 F	_____	Setpoints
DWU Terminate	71 F	_____	Setpoints
Occupied Zone Cooling	74 F	_____	Setpoints
Occupied Zone Heating	71 F	_____	Setpoints
Zone Derived Setpoint	4 F	_____	Setpoints
Unoccupied Zone Cooling	85 F	_____	Setpoints
Unoccupied Zone Heating	60 F	_____	Setpoints
Unoccupied Zone MWU	72 F	_____	Setpoints
Rapid Restart Critical Temp ^(a)	90 F	_____	Setpoints
Occ Dehumidification	60%	_____	Setpoints
Occ Dehumid Hysteresis Offset	5%	_____	Setpoints
Unocc Dehumidification	60%	_____	Setpoints
Unocc Dehumid Hysteresis Offset	5%	_____	Setpoints
Supply Air Reheat Setpoint	70 F	_____	Setpoints
Supply Air Reheat Deadband	4 F	_____	Setpoints
Maximum Reheat Valve Limit	85%	_____	Setpoints
Dehumid Ovrdr High Zone Temp	75 F	_____	Setpoints

Table 2. Factory Presets List (continued)(Note: Listed Items availability is dependent on unit configuration.

Adjustable Function	Factory Preset	Changed To	To adjust press...
Dehumid Ovrdr Low Zone Temp	68 F	_____	Setpoints
Cond Coil Purge Interval	90 Min	_____	Setpoints
Occ Humidification	30%	_____	Setpoints
Occ Humidification Hysteresis Offset	5%	_____	Setpoints
Unocc Humidification	30%	_____	Setpoints
Unocc Humidification Hysteresis Offset	5%	_____	Setpoints
Economizer Cooling Setpoint Suppression (CV)	3 F	_____	Setpoints
Reference Enthalpy	25 BTU/LB	_____	Setpoints
Economizer Drybulb Enable Stpt	75 F	_____	Setpoints
Supply Air Low Limit	50 F	_____	Setpoints
VCM Preheat Actuate Temp	35 F	_____	Setpoints
Design Min CO ₂ (DCV)	1000 PPM	_____	Setpoints
DCV Min CO ₂	800 PPM	_____	Setpoints
Design Min OA Flow (DCV)	220 CCFM	_____	Setpoints
DCV Min OA Flow	67 CCFM	_____	Setpoints
DCV Min OA Flow Deadband	5 CCFM	_____	Setpoints
Min OA Flow w\ VCM	Set per unit size	_____	Setpoints
Min OA Flow Deadband	Set per unit size	_____	Setpoints
Design Min OA Damper Position (DCV)	15%	_____	Setpoints
DCV Min OA Damper Position	5%	_____	Setpoints
OA Damper Min Position (non-DCV)	15%	_____	Setpoints
OAD Min Position w/IGV/VFD at 0%	25%	_____	Setpoints
OAD Min Position w/IGV/VFD at 50%	20%	_____	Setpoints
OAD Min Position w/IGV/VFD at 100%	15%	_____	Setpoints
OAD Min Position (Default)	15%	_____	Setpoints
Supply Air Pressure	2.0 IWC	_____	Setpoints
Supply Air Pressure High Limit	4.0 IWC	_____	Setpoints
Supply Air Pressure Deadband	0.5 IWC	_____	Setpoints
Max Return Plenum Pressure	0.8 IWC	_____	Setpoints
Return Plenum Pressure Deadband	0.1 IWC	_____	Setpoints
Space Pressure - Setpoint	0.08 IWC	_____	Setpoints
Space Pressure - Deadband	.04 IWC	_____	Setpoints
Space Pressure Low Limit	-0.2 IWC	_____	Setpoints
Exhaust Enable Point	25%	_____	Setpoints
Exhaust Inhibit Point	DISABLE	_____	Setpoints
Low Ambient Comp. Lockout (Standard Units)	50 F	_____	Setpoints
Low Ambient Comp. Lockout (Low Ambient Units)	0 F	_____	Setpoints
Standby Freeze Avoidance	0%	_____	Setpoints
Recovery Frost Avoidance Setpoint	27 F	_____	Setpoints
Setpoint Source Selection For...			
Supply Air Temp Cooling	Hi Default	_____	Setpoints
Supply Air Temp Heating	Hi Default	_____	Setpoints
Occupied Zone Cooling	Hi Default	_____	Setpoints



General Status Display

Table 2. Factory Presets List (continued)(Note: Listed Items availability is dependent on unit configuration.

Adjustable Function	Factory Preset	Changed To	To adjust press...
Occupied Zone Heating	Hi Default	_____	Setpoints
Unoccupied Zone Cooling	Hi Default	_____	Setpoints
Unoccupied Zone Heating	Hi Default	_____	Setpoints
Morning Warm-Up	Hi Default	_____	Setpoints
Economizer Dry Bulb Enable	Hi Default	_____	Setpoints
Outside Damper Minimum Position	Hi Default	_____	Setpoints
Occupied Dehumidification	Hi Default	_____	Setpoints
Unoccupied Dehumidification	Hi Default	_____	Setpoints
Supply Air Reheat	Hi Default	_____	Setpoints
Occupied Humidity	Hi Default	_____	Setpoints
Unoccupied Humidity	Hi Default	_____	Setpoints
Minimum Outside Air Flow Rate	Hi Default	_____	Setpoints
Supply Air Pressure	Hi Default	_____	Setpoints
Space Pressure	Hi Default	_____	Setpoints

(a) Field replacement of control modules requires proper human interface setup to insure unit performance

Password Protected Screens

Some of the operating displays on the Human Interface LCD screens and require a password to change. The following screens display the various programming sections that require a password in order to view or to modify the preset operating parameters. The password for each screen is a different series of **+** (**Plus**) or **-** (**Minus**) key strokes in a predefined sequence. Shown below are the password protected screens, and the passwords for accessing them.

The following screens display the various programming sections that require a specific password to be entered by a qualified operator in order to modify the operating parameters. The following screen will appear if the password is not entered within approximately 15 seconds.

Password Entry Time Limit Exceeded

Configuration is Password Protected
Please Enter Password: _____

1. Press the **+** or **-** keys in this sequence (**+** **-** **-** **-**) to access this restricted screen.
2. Press the **Enter** key to confirm the password and enter the menu.

Ventilation Override Mode _____
Enter Password to Lock Definition:

1. Press the + or - keys in this sequence (+ - - +) to lock each VOM Mode.
2. Press the **Enter** key to confirm the password and Lock the definitions.

Diagnostic Reset is Password Protected
Please Enter Password: _____

1. Press the + or - keys in this sequence (- + +) to access this restricted screen.
2. Press the **Enter** key to confirm the diagnostic reset.

Diagnostic Log is Password Protected
Please Enter Password: _____

1. Press the + or - keys in this sequence (- + + -) to access this restricted screen.
2. Press the **Enter** key to confirm clearing the diagnostic log.

Turning Parameters are Password Protected
Please Enter Password: _____

1. Contact Clarksville Service for Password.

Navigating the Human Interface Screens

In the following sections the user will be presented with a number of screens and submenus that follow the selection of a main menu key entry (**Status, Setpoints, Diagnostics, Setup, Configuration, Service Mode** and **Custom**). When a submenu is presented, it may be accessed by pressing the **Enter** key or, skipped entirely by pressing the **Next** key. Upon entering a menu, or submenu, the user will navigate through the desired selections by pressing the **Next** and **Previous** keys. The most probable keystroke would be to press **Next** to cycle forward through the screens as shown in these sections, but pressing the **Previous** key may be desirable to review previous screens or to quickly navigate to the end of a menu.

Once the user has navigated to a desired selection, the + (**Plus**) and - (**Minus**) keys will be pressed to cycle through the selection range of the menu item. The range of each item selected is dependent upon the item and is listed for each screen in the following sections. For instance, if the user has selected a **Configuration** item typical choices displayed with each + (**Plus**) or - (**Minus**) keystroke may be *Installed* or *Not Installed*. If a **Setup** menu were accessed a choice may be *Enabled* or *Disabled*. Temperature **Setpoints** will typically cycle through their range one degree at a time, and so on. Similar to pressing the **Previous** key above, pressing the - (**Minus**) key to decrement through the range may provide quick access to the desired value.

Once a change has been made to the desired menu item the user will press the **Enter** key to accept the change, or press the **Cancel** key to ignore the modification and return the displayed item to its original value.



STATUS Menu

The status menu is used to view various operating conditions such as temperatures, pressures and humidity levels. It is also used to view unit component status such as fan, compressor, heater, and economizer operation, as well as setpoint status.

The screens shown in this section are for example only. Pressing the **+ (Plus)** key while viewing any of the status display screens will add that screen to the Custom menu. While viewing the Custom menu, a screen can be removed by pressing the **- (Minus)** key.

When a status screen is displayed for 30 minutes without a key being pressed, the LCD screen will revert to the general operating status display. If this happens, press the **Status** key again to return to the status menu. The following are examples of status screens that may be viewed by pressing the **Status** key.

Note:

1. Many of the screens displayed in this section are applicable only for the options that are installed in the unit and may not be visible on your unit.
2. The range for some selections depend upon a sensor connected to a control module. Normal ranges expected will be listed for each screen shown. If the sensor is operating outside its normal limits, or has failed, "+ERR" will appear if out of range high, and "-ERR" if it is out of range low.

Press the **Status** key to begin viewing the status screens.

TOP LEVEL STATUS SCREEN

VVDA OA Flow	350.0 CCFM	Supply Fan ON
Occupied	Cool 4	Diagnostics

- Press **Next/Previous** keys to navigate.

GENERAL SYSTEM STATUS SUBMENU SCREENS

General System Status Submenu
Press ENTER to View Data in this Submenu

Used With: All Units

- Press **Next** key to skip this Submenu.

Active Unit Control Source:	LOCAL
Active Cluster Member Role:	STANDALONE

Used With: BAS Interface Installed

Possible Values:

Source: LOCAL, BAS/NETWORK
Role: STANDALONE, SLAVE, MASTER

- Press **Next/Previous** keys to navigate.

RTM Supply Fan Relay:	OFF
RTM Supply Airflow Proving:	FLOW

Used With: All Units

Possible Values:

Fan Relay: ON, OFF
Airflow Proving: FLOW, NO FLOW

- Press **Next/Previous** keys to navigate.

Note: One of the three following screens will be shown based on supply air pressure options.

Supply Fan IGV/VFD Target:	30%
Master's Algorithm Command to All Units	

Used With: Clustered VVDA Units
Possible Values: 0 to 100%

OR

Supply Fan IGV/VFD Cmd	Opening To	30 %
Active Supply Air Pressure		2.0 IWC

Used With: VVDA Units
Possible Values:
 Cmd: 0 to 100%
 Press: 0.0 to 7.9 IWC

"Opening To" and "Closing To" indicate direction.
 "Limited To" when shown indicates an active override.

OR

Active Supply Air Pressure	2.0 IWC
----------------------------	---------

Used With: CVDA/CVZT Units
Possible Values: 0.0 to 7.9 IWC

- Press **Next/Previous** keys to navigate.

Note: One of the three following screens will be shown based on power exhaust options.

Exhaust Fan OFF

Used With: Units w Power Exhaust w/o Statitrac, w/o Return Fan
Possible Values: ON, OFF

OR

Exhaust Damper/VFD Target:	70 %
Master's Algorithm Command to All Units	

Used With: Clustered, w/Statitrac, w/o Return Fan Units
Possible Values: 0 to 100%

OR

Exhaust Fan ON	Space Pressure	0.00 IWC
Exhaust Damper/VFD	Opening To	32 %

Used With: Units w/Statitrac, w/o Return Fan
Possible Values:
 Fan: ON, OFF
 Pressure:
 IPakI: -0.2 to 0.3 IWC
 IPakII: -0.67 to 0.67 IWC
 Damper/VFD: 0 to 100%

"Opening To" and "Closing To" indicates direction.
 "Limited To" when shown indicates an active override.

- Press **Next/Previous** keys to navigate.

Note: One of the four following screens will be shown based on heating type options.



STATUS Menu

Electric Heat: ENABLED Stage: 6 K11: ON K12: ON K1: ON
--

"ENABLED" indicates heat is available.
 "DISABLED" indicates heating is not allowed.
 "LIMITED" indicates heating is available at reduced capacity.

OR

Gas Heat: ENABLED Stage: 2 K11: ON K12: ON K1: ON

"ENABLED" indicates heat is available.
 "DISABLED" indicates heating is not allowed.
 "LIMITED" indicates heating is available at reduced capacity.

OR

Hydronic Heat: ENABLED Valve Position: Opening To: 100 %

"ENABLED" indicates heat is available.
 "DISABLED" indicates heating is not allowed.
 "LIMITED" indicates heating is available at reduced capacity.
 "Opening To" and "Closing To" indicates direction.

OR

Mod Gas Heat: ENABLED Valve Position: Opening To: 100 %
--

"ENABLED" indicates heat is available.
 "DISABLED" indicates heating is not allowed.
 "LIMITED" indicates heating is available at reduced capacity.
 "Opening To" and "Closing To" indicates direction.

- Press **Next/Previous** keys to navigate.

Used With: Units w/Electric Heat

Possible Values:

Electric Heat:

ENABLED,
 DISABLED By Setup,
 LIMITED By Demand Limit
 DISALBED By BAS/Network

Stage: 0,1,2,3,4,5,6

K*: ON, OFF

Used With: Units w/Staged Gas Heat

Possible Values:

Gas Heat:

ENABLED,
 DISABLED By Setup,
 LIMITED By Demand Limit
 DISALBED By BAS/Network

Stage: 0,1,2

K*: ON, OFF

Used With: Units w/Hydronic Heat

Possible Values:

Hydronic Heat:

ENABLED,
 DISABLED By Setup,
 LIMITED By Demand Limit
 DISABLED By Low Air Temp
 DISALBED By BAS/Network

Position: 0 to 100%

Used With: Units w/Mod Gas Heat

Possible Values:

Mod Gas Heat:

ENABLED,
 DISABLED By Setup,
 LIMITED By Demand Limit
 DISABLED By Low Air Temp
 DISALBED By BAS/Network

Position: 0 to 100%

Chilled Water: ENABLED
Valve Position: Opening To 100 %

“ENABLED” indicates cooling is available.
 “DISABLED” indicates cooling is not allowed.
 “LIMITED” indicates cooling is available at reduced capacity.
 “Opening To” and “Closing To” indicates direction.

- Press **Next/Previous** keys to navigate.

Used With: Air Handler Units w/Chilled Water

Possible Values:

Chilled Water:

ENABLED,
 DISABLED By Setup,
 LIMITED By Demand Limit
 DISABLED By Low Air Temp
 DISALBED By BAS/Network

Position: 0 to 100%

Dehumidification Status: DISABLED
by Comfort Control Override is Active

Used With: Units w/Dehumidification
Top Line Possible Values: ENABLED, DISABLED

Bottom line Possible Values:

When ENABLED is Shown:
 (blank line)

When LOCKED is Shown:

[See “[Table 3. Dehumidification Lockout Sources](#)” Below]

Table 3. Dehumidification Lockout Sources

Value Displayed in Bottom Field	Disable Conditions
Disabled By Call for Cooling Demand Limit	Compressors unavailable due to demand limit.
Disabled By Compressor Lockout Sources	Required compressors are not available.
Disabled By Occ Dehumid Function Disable	Occupied Dehumid. control is disabled.
Disabled By Dehumid Override Zone Temp High/Low	VVDA/CVDA critical zone temp is too high/low.
Disabled By OA Temperature Out Of Range	Outdoor air temperature is out of range.
Disabled By Unocc Dehumid Function Disable.....	Unoccupied Dehumid. control is disabled.
Disabled By Comfort Control Override is Active.....	Comfort cooling control has priority.
Disabled By Required Sensor Failure Condition	Sensor(s) for dehumid. control have failed.
Disabled By Sat Reheat Cond Temp Sensor Fail	Sensor for dehumid. control have failed.
Disabled By Reheat Head Pressure High Limit.....	Reheat circuit is experiencing high pressures.
Disabled By Condenser Coil Purge is Active.....	Active purge mode temporary override.
Disabled By Comp Press Differential.....	Excessive refrig. pressures across compressors.

- Press **Next/Previous** keys to navigate.

Humidification Status: ENABLED
Humidification is Active

Used With: Units w/Humidification

Top Right Field: ENABLED, DISABLED

Bottom Field:

The following shown when DISABLED:
 by Occ Humidification Function Disable
 by Unocc Humid Function Disable

The following shown when ENABLED:

Humidification is Inactive
 Humidification is Active

- Press **Next/Previous** keys to navigate.

STATUS Menu

End of Submenu (NEXT) to Enter STATUS

- Press **Next/Previous** keys to navigate.

COMPRESSOR STATUS SUBMENU SCREENS

Compressor Status Submenu
Press ENTER to View Data in This Submenu

- Press the **Next** key to skip this Submenu.

Note: *Combinations of the following screens will be shown based on unit cooling capacity option.*

Compressor Relay K10 Locked
Disabled By Compressor Protection (MORE)

Note: *There will be 2 screens shown for this configuration, one screen for K10 and one for K11.*

- Press **Next/Previous** keys to navigate.

OR

Compressor Relay K11 Locked
Disabled By Compressor Protection (MORE)

Note: *There will be 4 screens shown for this configuration, one for K11, one for K12*, one for K3, and one for K4*. See the following replacement screen for K12 when a variable speed compressor is installed on 40-70 ton units. K12 and K4 will show either Enabled or Activated by Compressor Protection when the compressor is ON.*

Important:

- **See the following replacement screen for K12 when a variable speed compressor is installed on 40-70 ton units.*
- **K12 and K4 will show either Enabled, or Activated by Compressor Protection, when the compressor is ON.*

- Press **Next/Previous** keys to navigate.

Used With: Units w/DX Cooling

Used With: IPakI 20-30Ton DX Cooling

Possible Values:

Compressor Relay:

K10: 1st Compressor

K11: 2nd Compressor

Top Right Field:

ON, OFF, LOCKED

Bottom Field:

When ON or OFF is Shown: ENABLED

When LOCKED is Shown:

[See "Table 4. Compressor Lockout Sources" on page 32"]

Used With: IPakI 40-130Ton DX Cooling

Possible Values:

Compressor Relay:

K11: 1st Compressor

K12: 2nd Compressor

K3: 3rd Compressor

K4: 4th Compressor

Top Right Field:

ON, OFF, LOCKED

Bottom Field:

When ON or OFF is Shown: ENABLED

When LOCKED is Shown:

[See "Table 4. Compressor Lockout Sources" on page 32"]

Capacity of Variable Speed Comp: 0%
 Disabled By Compressor Protection (MORE)

Notes:

- This screen replaces K12 if a variable speed compressor is installed.
- *Applied Design Capacity is the maximum cooling capacity of the variable speed compressor for this unit's tonnage design.
- Press **Next/Previous** keys to navigate.

OR

Ckt 1 Compr Relay K11: OFF
 Enabled

Notes:

- There will be **2** screens shown for the configuration, one for K11 and one for K12.
- *K12 will show either Enabled or Activated by Compressor Protection when the compressor is ON.
- Press **Next/Previous** keys to navigate.

Ckt 2 Compr Relay K3: ON
 Enabled

- There will be **2** screens shown for the configuration, one for K3 and one for K4.
- K4 will show either Enabled or Activated by Compressor Protection when the compressor is ON.

Used With: IPakI 40-70 Ton DX Cooling Configured w/Variable Speed Compressor

Possible Values: % of Applied Design Capacity*

Top Right Field: 0-100%

Bottom Field:

During Normal control: [blank]

When VSC is locked: [See "Table 4.

Compressor Lockout Sources" on page 32"]

Used With: IPakII DX Cooling

Possible Values:

Compressor Relay:

K11: 1st Compressor

K12: 2nd Compressor

Top Right Field:

ON, OFF, LOCKED

Bottom Field:

When ON or OFF is Shown: ENABLED

When LOCKED is Shown:

[See "Table 4. Compressor Lockout Sources" Below]

Used With: IPakII DX Cooling

Possible Values: Possible Values:

Compressor Relay:

K3: 3rd Compressor

K4: 4th Compressor

Top Right Field:

ON, OFF, LOCKED

Bottom Field:

When ON or OFF is Shown: ENABLED

When LOCKED is Shown:

[See "Table 4. Compressor Lockout Sources" Below]



STATUS Menu

Table 4. Compressor Lockout Sources

Value Displayed in Bottom Field	Lockout Conditions
Disabled By Compressor Protection.....	Compressor proving input did not close.
Disabled By Contactor/Drive Failure.....	Compressor proving input stuck closed.
Disabled By Low Pressure Cutout	Low pressure cutout input to MCM.
Disabled By Bad Cond Temp Sensor.....	Temp sensor is out of range.
Disabled By Demand Limit.....	From GBAS or BAS/Network.
Disabled By Frost Protection	Leaving evap temp. < coil frost setpoint.
Disabled By BAS/Network Lockout.....	BAS demand or capacity limited.
Disabled By Minimum Off Time.....	3 minutes.
Disabled By Low Ambient Lockout	Ambient temp. < Low Ambient Lockout Stpt.
Disabled By Ventilation Override.....	Source is VOM input A-E, or BAS/Network.
Disabled By LPC Delay	3 minutes.
Disabled By Water Flow Status.....	Evap. condenser water flow failure.
Disabled By Cond Coil Purge Request.....	Dehumidification coil purge mode.
Disabled By Sump Temp Sensor Fail.....	Evap. condenser sump water temperature.
Disabled By Low Refrig Charge.....	Evap. temp. difference exceeded for 10 min.
Disabled By Ckt	Evap Low Limit Entering evaporator temp. is excessively low.
Disabled by Reheat Ckt Evap Low Limit	Entering evaporator temp. is excessively low.
Disabled By Evap Temp Sensor Fail.....	Entering or leaving temp. sensor(s) failed.
Disabled by Comp Press Differential.....	Excessive refrig. pressures across compressors.
Disabled By Sump Min Level Sensor Fail	Evap. condenser min level switch failed.
Disabled By Sump Pump Failure	Evap. condenser pump proving failed.
Disabled By Sump Min Level Control	Evap. condenser water level marginal.
Activated By Compressor Protection.....	Comps on for refrigerant management

- Press **Next/Previous** keys to navigate.

Circuit 1	Evap Diff: 5.0°F
Enter Evap: 48.5°F	Leave Evap: 53.5°F

"Evap Diff:" and associated value not displayed if:

1. circuit is inactive, or
2. for first ten minutes of circuit operation, or
3. HGBP is installed

"Enter Evap:" and associated value not displayed if:

1. HGBP is installed

- Press **Next/Previous** keys to navigate.

Circuit 1	
Saturated Condensing Temp:	100.0°F

- Press **Next/Previous** keys to navigate.

Used With: DX Cooling

Possible Values:

Evap Diff: 0.0 to 200.0°F
 Enter Evap: -40.0 to 200.0°F
 Leave Evap: -40 to 200.0°F

Used With: DX Cooling.

Possible Values:

Temp: -40.0 to 200.0°F

Circuit 2	Evap Diff: 12.0°F
Enter Evap: 40.0°F	Leave Evap: 52.0°F

Used With: DX Cooling \geq 40Ton
Possible Values:

Evap Diff: 0.0 to 200.0°F
 Enter Evap: -40.0 to 200.0°F
 Leave Evap: -40 to 200.0°F

"Evap Diff:" and associated value not displayed if:

1. circuit is inactive, or
2. for first ten minutes of circuit operation, or
3. HGBP is installed

"Enter Evap:" and associated value not displayed if:

1. HGBP is installed

- Press **Next/Previous** keys to navigate.

Circuit 2	Saturated Condensing Temp: 97.0°F
------------------	--

Used With: DX Cooling \geq 40Ton
Possible Values:

Temp: -40.0 to 200.0°F

- Press the **Next** key to navigate forward.

Circuit 1	Cond Fan Staging
K1: ON K2: ON	Stage 4

Used With: DX Cooling
Possible Values:

K1: ON, OFF; K2: ON, OFF

Bottom Right Field:

OFF
 Stage 1
 Stage 2
 Stage 3
 Stage 4

"K2:" status not displayed, and maximum stage is 1, on water-cooled condenser units.

- Press **Next/Previous** keys to navigate.

Circuit 2	Cond Fan Staging
K5: ON K6: ON	Stage 4

Used With: DX Cooling \geq 40Ton
Possible Values:

K5: ON, OFF; K6: ON, OFF

Bottom Right Field:

OFF
 Stage 1
 Stage 2
 Stage 3
 Stage 4

"K6:" status not displayed and maximum stage is 1 on water-cooled condenser units.

- Press **Next/Previous** keys to navigate.

Condenser Fan Speed:	
Circuit 1: 100%	Circuit 2: 100%

Used With: DX Cooling w/Low Ambient Option or Water-Cooled Condensers

Possible Values:

Circuit 1: 0 to 100%
 Circuit 2: 0 to 100%

"Circuit 2:" only shown for units \geq 40Tons.

- Press **Next/Previous** keys to navigate.



STATUS Menu

Condenser Sump Water Temp:	73.1°F
Condenser Sump Heater Relay:	OFF

"Cond Sump Heater Relay" only shown if Sump Heater installed.

- Press **Next/Previous** keys to navigate.

Condenser Sump Pump Relay Command:	ON
Condenser Sump Pump Proving:	FLOW

- Press **Next/Previous** keys to navigate.

Condenser Sump Fill Relay:	OFF
Condenser Sump Fill Valve:	OPEN

- Press **Next/Previous** keys to navigate.

Condenser Sump Drain Relay:	ON
Condenser Sump Drain Valve:	CLOSED

"Relay" and "Valve" states are configurable based on the need to hold water in the sump or drain it on power loss. See the **IOM**, and "[Table 7: Sump Drain Valve States](#)" on page 110 in **Service Test** section for further information.

- Press **Next/Previous** keys to navigate.

Cond Sump Water Level Max Input:	OPEN
Cond Sump Water Level Min Input:	CLOSED

- Press **Next/Previous** keys to navigate.

External Sump Drain Request:	INACTIVE
------------------------------	----------

- Press **Next/Previous** keys to navigate.

Reheat Coil Pumpout Relay:	OFF
Reheat Coil Pumpout Valve:	CLOSED

- Press **Next/Previous** keys to navigate.

Used With: DX Cooling w/Water-Cooled Condensers

Possible Values:

Temp: 0.0 to 200.0°F
Relay: ON, OFF

Used With: DX Cooling w/Water-Cooled Condensers

Possible Values:

Relay: ON, OFF
Proving: FLOW, NO FLOW

Used With: DX Cooling w/Water-Cooled Condensers

Possible Values:

Relay: ON, OFF
Valve: CLOSED, OPEN

Used With: DX Cooling w/Water-Cooled Condensers

Possible Values:

Sump Drain Relay: ON, OFF
Sump Drain Valve: CLOSED, OPEN

Used With: DX Cooling w/Water-Cooled Condensers

Possible Values:

Max Input: CLOSED, OPEN
Min Input: CLOSED, OPEN

Used With: DX Cooling w/Water-Cooled Condensers

Possible Values: ACTIVE, INACTIVE

Used With: DX Cooling w/ Dehumidification

Possible Values:

Relay: ON, OFF
Valve: CLOSED, OPEN

Dehumid Reheat Valve Position:	0%
Dehumid Cooling Valve Position:	100%

Used With: DX Cooling w/ Dehumidification

Possible Values:

Reheat Valve: 0 to Max Reheat Valve Position Setpoint (see Setpoints Menu)
Cooling Valve: 10 to 100%

- Press **Next/Previous** keys to navigate.

Active Outside Air Temperature	70.0°F
Low Ambient Comp Lockout Temp:	50°F

Used With: DX Cooling

Possible Values:

Active Outside Air Temp: -40 to 200.0°F Lockout Temp: -20 to 80°F
Default(s):
Standard: 50°F
Low-Amb. w/Hot Gas Bypass: 0°F
Low-Amb. w/o Hot Gas Bypass: 10°F

- Press **Next/Previous** keys to navigate.

End of Submenu (NEXT) to Enter STATUS

- Press **Next/Previous** keys to navigate.

ECONOMIZER STATUS SUBMENU SCREENS

Economizer Status Submenu
Press ENTER to View Data in This Submenu

Used With: Units w/Economizer

- Press the **Next** key to skip this Submenu.

Air Economizing:	ENABLED
Outside Air Damper Pos: Closing to	10%

Used With: Units w/Economizer

Possible Values:

Economizing: ENABLED/DISABLED
Damper Pos: 0 to 100%

or

Air Economizing: LIMITED By SA Low Limit	
Outside Air Damper Pos:	30%

"Opening to" and "Closing to" indicates direction.
"LIMITED By SA Low Limit" indicates economizer sub-cooling prevention is activated and the OA Damper is limited.

- Press Next/Previous keys to navigate.



STATUS Menu

Active Outside Air Enthalpy	29.5 BTU/LB
ECEM Return Air Enthalpy	34.0 BTU/LB

"Return Air Enthalpy" is displayed if Comparative Enthalpy or Energy Recovery is installed.

- Press **Next/Previous** keys to navigate.

Used With: Units w/Economizer

Possible Values:

OA Enthalpy: 10 to 35 BTU/LB
RA Enthalpy: 10 to 35 BTU/LB

Active Outside Air Temperature	86.0°F
ECEM Return Air Temperature	78.0°F

"Return Air Temperature" is displayed if Comparative Enthalpy or Energy Recovery is installed.

- Press **Next/Previous** keys to navigate.

Used With: Units w/Economizer

Possible Values:

OA Temp: -40 to 200°F
RA Temp: -40 to 200°F

Active Outside Air Humidity	30 %RH
ECEM Return Air Humidity	62 %RH

"Return Air Humidity" is displayed if Comparative Enthalpy or Energy Recovery is installed.

- Press **Next/Previous** keys to navigate.

Used With: Units w/Economizer

Possible Values:

OA Humidity: 10 to 90%
RA Humidity: 10 to 90%

End of Submenu (NEXT) to Enter STATUS

- Press **Next/Previous** keys to navigate.

OUTSIDE AIR VENTILATION STATUS SUBMENU SCREENS

Outside Air Ventilation Status Submenu
Press ENTER to View Data in this Submenu

- Press the **Next** key to skip this Submenu.

Used With: Units w/Fresh Air Options

Demand Control Ventilation is	ENABLED
Space CO ₂ Level:	600 PPM

"Space CO₂ Level" is shown only if "Demand Control Ventilation" is ENABLED

- Press **Next/Previous** keys to navigate.

Used With: All Units

Possible Values:

DCV: ENABLED, DISABLED
CO₂ Level: 50 to 2200 PPM

Note: One of the three following screens will be shown based on fresh air measurement and DCV options.

DCV Min OA Flow Target:	250.0 CCFM
Deadband: 5.0 CCFM	OA Flow 234.3 CCFM

Used With: Fresh Air Measurement (VCM) w/DCV and Demand Control Ventilation ENABLED

Possible Values:

Target: 0 to 650 CCFM
 Deadband: 5.0 to 200 CCFM
 OA Flow: 0 to 650 CCFM

OR

Active Min OA Flow Setpoint:	140.3 CCFM
Deadband: 6.8 CCFM	OA Flow 143.5 CCFM

Used With: Fresh Air Measurement (VCM) w/DCV and Demand Control Ventilation DISABLED

Possible Values:

Setpoint: 0 to 650 CCFM
 Deadband: 5.0 to 200 CCFM
 OA Flow: 0 to 650 CCFM

OR

Active Min OA Flow Setpoint:	140.3 CCFM
CO2 Level 1100 PPM	OA Damper Pos: 99 %

Used With: Fresh Air Measurement (VCM) w/o DCV and CO2 Reset ENABLED

Possible Values:

Setpoint: 0 to 650 CCFM
 CO2 Level: 50 to 2000 PPM
 OA Damper Pos: 0 to 650 CCFM

- Press **Next/Previous** keys to navigate.

Outside Air Flow	Total: 335.4 CCFM
Left: 167.2 CCFM	Right: 168.2 CCFM

Used With: Fresh Air Measurement (VCM) w/DCV

Possible Values: 0 to 650 CCFM

- Press **Next/Previous** keys to navigate.

Outside Air Damper Target:	27 %
Outside Air Damper Position:	24 %

Used With: Units w/Fresh Air Options

Possible Values: 0 to 100%

- Press **Next/Previous** keys to navigate.

VCM Preheater Output Control:	OFF
VCM Module Aux Temp Input:	47.2 °F

Used With: Fresh Air Measurement (VCM) w/DCV or OA Damper Min Position (VCM) w/DCV and Preheat ENABLED

Possible Values:

Output Control: ON, OFF
 Aux Temp Input: -40.0 to 200.0°F

- Press **Next/Previous** keys to navigate.

End of Submenu (NEXT) to Enter STATUS

- Press **Next/Previous** keys to navigate.



STATUS Menu

RETURN FAN STATUS SUBMENU SCREENS

Return Fan Status Submenu
Press ENTER to View Data in This Submenu

- Press the **Next** key to skip this Submenu.

Used With: Units w/Return Fan Option

Return Fan Relay: ON
Return Airflow Proving: ON

- Press **Next/Previous** keys to navigate.

Used With: Units w/Return Fan Option
Possible Values: ON, OFF

Return Fan VFD Command: 45 %
Return Plenum Pressure: 0.8 IWC

Top line shown only if Return Fan VFD is installed.

- Press **Next/Previous** keys to navigate.

Used With: Units w/Return Fan Option
Possible Values:
Command: 0 to 100%
Pressure: -0.7 to 3.5 IWC

Return Plenum Pressure Target: 0.8 IWC
Return Fan VFD Pos: Opening to 45 %

"Opening to" and "Closing to" indicates direction.
"Limited to" indicates an active override.

- Press **Next/Previous** keys to navigate.

Used With: Units w/Return Fan Option
Possible Values:
Target: -0.5 IWC, or 0.1 to 2.5 IWC
VFD Pos: 0 to 100%

Max Return Plenum Pressure Stp: 1.2 IWC
High Limit: 3.5 IWC Deadband: 0.2 IWC

- Press **Next/Previous** keys to navigate.

Used With: Units w/Return Fan Option
Possible Values:
Pressure Stp: 0.1 to 2.5 IWC
Deadband: 0.1 to 1.0 IWC
High Limit: 3.5 IWC (*non-adjustable*)

End of Submenu (NEXT) to Enter STATUS

- Press **Next/Previous** keys to navigate.

SINGLE ZONE VAV STATUS SUBMENU SCREENS

Single Zone VAV Control Status Submenu
Press ENTER to View Data in this Section

- Press **Next/Previous** keys to navigate.

Used With: Units w/SZVAV(VVZT)
Option

Active SA Target High Limit: 123.0 °F
Active SA Max Target Setpoint: 100.0 °F

The Target High Limit is a calculated value which corresponds to the Maximum Fan Speed during heating (see SA Target Setpoint on following screen). The Max Target Setpoint reflects the SA Heating Setpoint value and corresponds to the Minimum Fan Speed during heating.

- Press **Next/Previous** keys to navigate.

Used With: Units w/SZVAV(VVZT)
Option

Possible Values:

- High Limit: (calculated)
- Max Target: Equal to SA Cooling Setpoint

Fan speed modulation in heating occurs when the Target Setpoint modulates between the Max Setpoint and High Limit Setpoint.

Active SA Target Setpoint: 74.0 °F
Active SA Temperature: 73.9 °F

The SA Target Setpoint is a calculated discharge setpoint based on zone temperature conditions. Heating and Cooling is staged to maintain SA Temperature to this setpoint. The range is clamped on the high end to Max Target Setpoint (see previous screen) and to the low end to Min Target Setpoint (see next screen).

- Press **Next/Previous keys to navigate.**

Used With: Units w/SZVAV(VVZT)
Option

Possible Values:

- SA Target: Max Target – Min Target
- SA Temp: See SA Temp status.

Active SA Min Target Setpoint: 50.0 °F
Active SA Target Low Limit: 38.4 °F

The Target Low Limit is a calculated value which corresponds to the Maximum Fan Speed during cooling (see SA Target Setpoint on previous screen). The Min Target Setpoint reflects the SA Cooling Setpoint value and corresponds to the Minimum Fan Speed during cooling.

- Press **Next/Previous keys to navigate.**

Used With: Units w/SZVAV(VVZT)
Option

Possible Values:

- MinTarget: Equal to SA Heating Setpoint
- Low Limit: (calculated)

Fan speed modulation in cooling occurs when the Target Setpoint modulates between the Min Setpoint and Low Limit Setpoint.

End of Submenu (NEXT) to Enter STATUS
--

- Press **Next/Previous** keys to navigate.

ENERGY RECOVERY STATUS SUBMENU SCREENS

Energy Recovery Status Submenu
Press ENTER to View Data in This Submenu

- Press the **Next** key to skip this Submenu.

Used With: Units w/Energy Recovery
Option



STATUS Menu

Energy Wheel Relay:	ON
Energy Wheel Proving:	ON

- Press **Next/Previous** keys to navigate.

Used With: Units w/Energy Recovery Option
Possible Values: ON, OFF

Outside Air Bypass Damper Pos:	0%
Exhaust Air Bypass Damper Pos:	15%

- Press **Next/Previous** keys to navigate.

Used With: Units w/Energy Recovery Option
Possible Values: 0 to 100%

Energy Wheel Frost Avoidance:	INACTIVE
Leaving Recovery Exhaust Temp:	45.0°F

- Press **Next/Previous** keys to navigate.

Used With: Units w/Energy Recovery Option
Possible Values:
 Frost Avoidance: ACTIVE, INACTIVE;
 Exhaust Temp: -40.0 to 200.0°F

MPM Preheat Relay:	OFF
--------------------	-----

- Press **Next/Previous** keys to navigate.

Used With: Units w/Energy Recovery Option w/Preheat
Possible Values: ON, OFF

End of Submenu (NEXT) to Enter STATUS

- Press **Next/Previous** keys to navigate.

CONTROLLING SETPOINT STATUS SUBMENU SCREENS

Controlling SETPOINT Status Submenu
Press ENTER to View Data in This Submenu

- Press the **Next** key to skip this Submenu.

Used With: All Units

Active Supply Air Cooling STP From	
HI (KEYPAD) SETPOINT MENU Is	55°F

- Press **Next/Previous** keys to navigate.

Used With: VVDA or CVDA Units
Possible Values:
 HI (KEYPAD) SETPOINT MENU
 ZONE SENSOR SETPOINT INPUT
 NSB PANEL SETPOINT INPUT
 GBAS 0-5 VDC MODULE
 GBAS 0-10 VDC MODULE
 BAS/NETWORK
 Range: 40 to 90°F

Active Supply Air Heating STP From
 HI (KEYPAD) SETPOINT MENU Is 100°F

- Press **Next/Previous** keys to navigate.

Used With: VVDA or CVDA Units w/ Hydronic Heat, Modulating Gas Heat, or IpakII w/Electric Heat

Possible Values:

HI (KEYPAD) SETPOINT MENU
 ZONE SENSOR SETPOINT INPUT
 GBAS 0-5 VDC MODULE
 GBAS 0-10 VDC MODULE
 BAS/NETWORK

Range: 40 to 180°F

Active Daytime Warmup Setpoints
 Initiate: 67 °F Terminate: 71 °F

- Press **Next/Previous** keys to navigate.

Used With: Units w/DWU ENABLED

Possible Values:

Initiate: 50 to 87°F
 Terminate: 53 to 90°F

Active Occupied Zone Cooling STP From
 HI (KEYPAD) SETPOINT MENU is 71°F

- Press **Next/Previous** keys to navigate.

Used With: CVZT Units w/DX Cooling

Possible Values:

HI (KEYPAD) SETPOINT MENU
 ZONE SENSOR SETPOINT INPUT
 NSB PANEL SETPOINT INPUT
 GBAS 0-5 VDC MODULE
 GBAS 0-10 VDC MODULE
 BAS/NETWORK

Range: 52 to 90°F

Active Occupied Zone Heating STP From
 HI (KEYPAD) SETPOINT MENU is 71°F

- Press **Next/Previous** keys to navigate.

Used With: CVZT w/Heat, VV/CVDA w/ DWU or MWU Installed

Possible Values:

HI (KEYPAD) SETPOINT MENU
 ZONE SENSOR SETPOINT INPUT
 NSB PANEL SETPOINT INPUT
 GBAS 0-5 VDC MODULE
 GBAS 0-10 VDC MODULE
 BAS/NETWORK

Range: 50 to 88°F

Active Unoccupied Zone Cooling STP From
 HI (KEYPAD) SETPOINT MENU is 85°F

- Press **Next/Previous** keys to navigate.

Used With: All Units

Possible Values:

HI (KEYPAD) SETPOINT MENU
 ZONE SENSOR SETPOINT INPUT
 NSB PANEL SETPOINT INPUT
 GBAS 0-5 VDC MODULE
 GBAS 0-10 VDC MODULE
 BAS/NETWORK

Range: 52 to 90°F



STATUS Menu

Active Unoccupied Zone Heating STP From
HI (KEYPAD) SETPOINT MENU is 60°F

- Press **Next/Previous** keys to navigate.

Active Morning Warmup Setpoint From
HI (KEYPAD) SETPOINT MENU is 72°F

- Press **Next/Previous** keys to navigate.

Active Rapid Restart Critical Stpt From
HI (KEYPAD) SETPOINT MENU is 90°F

- Press **Next/Previous** keys to navigate.

Active Occ Dehumidification Setpt From
HI (KEYPAD) SETPOINT MENU is 60%

- Press **Next/Previous** keys to navigate.

Active Unocc Dehumidification Setpt From
HI (KEYPAD) SETPOINT MENU is 60%

- Press **Next/Previous** keys to navigate.

Used With: Units w/Heat Installed

Possible Values:

HI (KEYPAD) SETPOINT MENU
ZONE SENSOR SETPOINT INPUT
NSB PANEL SETPOINT INPUT
GBAS 0-5 VDC MODULE
GBAS 0-10 VDC MODULE
BAS/NETWORK

Range: 50 to 88°F

Used With: Units w/MWU ENABLED

Possible Values:

HI (KEYPAD) SETPOINT MENU
ZONE SENSOR SETPOINT INPUT
NSB PANEL SETPOINT INPUT
GBAS 0-5 VDC MODULE
GBAS 0-10 VDC MODULE
BAS/NETWORK

Range: 52 to 90°F

Used With: Units w/Rapid Restart

Possible Values:

HI (KEYPAD) SETPOINT MENU

Range: 75 to 95°F

Used With: Units w/Dehumid. Option

Possible Values:

HI (KEYPAD) SETPOINT MENU
GBAS 0-5 VDC MODULE
GBAS 0-10 VDC MODULE
BAS/NETWORK

Range: 40 to 65%

Used With: Units w/Dehumid. Option

Possible Values:

HI (KEYPAD) SETPOINT MENU
GBAS 0-5 VDC MODULE
GBAS 0-10 VDC MODULE
BAS/NETWORK

Range: 40 to 65%

Active Supply Air Reheat Setpoint From
HI (KEYPAD) SETPOINT MENU is 70.0°F

- Press **Next/Previous** keys to navigate.

Used With: Units w/Dehumid. Option

Possible Values:

HI (KEYPAD) SETPOINT MENU
GBAS 0-5 VDC MODULE
GBAS 0-10 VDC MODULE
BAS/NETWORK

Range: 60 to 80F

Active Occ Humidification Setpt From
HI (KEYPAD) SETPOINT MENU is 40%

- Press **Next/Previous** keys to navigate.

Used With: Units w/Humid. Option

Possible Values:

HI (KEYPAD) SETPOINT MENU
GBAS 0-5 VDC MODULE
GBAS 0-10 VDC MODULE
BAS/NETWORK

Range: 20 to 50%

Active Unocc Humidification Setpt From
HI (KEYPAD) SETPOINT MENU is 20%

- Press **Next/Previous** keys to navigate.

Used With: Units w/Humid. Option

Possible Values:

HI (KEYPAD) SETPOINT MENU
GBAS 0-5 VDC MODULE
GBAS 0-10 VDC MODULE
BAS/NETWORK

Range: 20 to 50%

Active Econ DB Enable Setpoint From
HI (KEYPAD) SETPOINT MENU is 75°F

- Press **Next/Previous** keys to navigate.

Used With: Units w/Economizer

Possible Values:

HI (KEYPAD) SETPOINT MENU
GBAS 0-5 VDC MODULE
GBAS 0-10 VDC MODULE
BAS/NETWORK

Range: 40 to 90°F

Active OA Damper Min Position STP From
HI (KEYPAD) SETPOINT MENU is 25%

- Press **Next/Previous** keys to navigate.

Used With: Units w/0-25% Motorized Damper, or Economizer and OA CFM Compensation Function DISABLED or OA Damper Min Position Setpoint Source Selection is Not "HI (KEYPAD) SETPOINT"

Possible Values:

HI (KEYPAD) SETPOINT MENU
GBAS 0-5 VDC MODULE
GBAS 0-10 VDC MODULE
BAS/NETWORK

Range: 0 to 100%



STATUS Menu

Active Min OA Flow Setpoint From
HI (KEYPAD) SETPOINT MENU is 34.2 CCFM

- Press **Next/Previous** keys to navigate.

Used With: Units w/Fresh Air Measurement (VCM) w/o DCV Option

Possible Values:

HI (KEYPAD) SETPOINT MENU
GBAS 0-5 VDC MODULE
GBAS 0-10 VDC MODULE
BAS/NETWORK SETPOINT

Range: 0 to *Max Unit Airflow*

[See "[Table 7. Max Unit Airflows](#)" on page 91" in the *Setpoints* Section Below]

Active Design Min OA Flow Setpoint From HI
(KEYPAD) SETPOINT MENU is 34.2 CCFM

- Press **Next/Previous** keys to navigate.

Used With: Units w/Fresh Air Measurement (VCM) w/DCV Option

Possible Values:

HI (KEYPAD) SETPOINT MENU
GBAS 0-5 VDC MODULE
GBAS 0-10 VDC MODULE
BAS/NETWORK SETPOINT

Range: 0 to *Max Unit Airflow*

[See "[Table 7. Max Unit Airflows](#)" on page 91" in the *Setpoints* Section]

Active Min OA Flow Target From
VCM Module is 120.5 CCFM

- Press **Next/Previous** keys to navigate.

Used With: Units w/Fresh Air Measurement (VCM) w/DCV Option

Possible Values:

VCM Module
BAS/NETWORK

Range: 0 to *Max Unit Airflow*

[See "[Table 7. Max Unit Airflows](#)" on page 91" in the *Setpoints* Section]

Active Supply Air Pressure STP From
HI (KEYPAD) SETPOINT MENU is 2.0 IWC

- Press **Next/Previous** keys to navigate.

Used With: VVDA Units

Possible Values:

HI (KEYPAD) SETPOINT MENU
GBAS 0-5 VDC MODULE
GBAS 0-10 VDC MODULE
BAS/NETWORK SETPOINT

Range: 0.7 to 5.1 IWC

Active Supply Air Pressure Setpoints
High Limit: 4.0 IWC Deadband: 0.5 IWC

- Press **Next/Previous** keys to navigate.

Used With: VVDA or Units w/Supply Air Pressure Sensor Present

Possible Values:

High Limit: 1.2 to 4.7 IWC
Deadband: 0.1 to 2.0 IWC

Active Space Pressure Setpoint From
HI (KEYPAD) SETPOINT MENU is 0.08 IWC

- Press **Next/Previous** keys to navigate.

Used With: Units w/Statitrac

Possible Values:

HI (KEYPAD) SETPOINT MENU
GBAS 0-5 VDC MODULE
GBAS 0-10 VDC MODULE
BAS/NETWORK SETPOINT
Range: -0.2 to 0.30 IWC

Active Space Pressure Deadband 0.1 IWC

- Press **Next/Previous** keys to navigate.

Used With: Units w/Statitrac

Possible Values: 0.02 to 0.20 IWC

End of Submenu (NEXT) to Enter STATUS

- Press **Next/Previous** keys to navigate.

CONTROLLING SENSOR STATUS SUBMENU SCREENS

ControllingSensorStatusSubmenu
Press ENTER to View Data in This Submenu

- Press the **Next** key to skip this Submenu.

Used With: All Units

Active Supply Air Temp Sensv Input From
BAS/NETWORK is 50.0°F

- Press **Next/Previous** keys to navigate.

Used With: All Units

Possible Values:

RTM Supply Air Temp Input
BAS/Network

Active Daytime WU Temp Sensor Input From
RTM ZONE TEMP INPUT is 82.0°F

- Press **Next/Previous** keys to navigate.

Used With: Units w/DWU ENABLED

Possible Values:

RTM ZONE TEMP INPUT
NSB PANEL TEMP SENSOR INPUT
RTM AUX TEMP INPUT
HEAT MODULE AUX TEMP INPUT
ECEM RETURN AIR TEMP INPUT BAS/
NETWORK SENSOR

Range: -40 to 200°F



STATUS Menu

Active Occ Zone Temp Sensor Input From
RTM ZONE TEMP INPUT is 75.0°F

- Press **Next/Previous** keys to navigate.

Used With: CV or SZVAV Units
Possible Values:
[See "**Possible Values:**" Above]

Active Unocc Zone Temp Sensor Input From
RTM ZONE TEMP INPUT is 75.0°F

- Press **Next/Previous** keys to navigate.

Used With: All Units
Possible Values:
[See "**Possible Values:**" Above]

Active Morning WU Temp Sensor Input From
RTM ZONE TEMP INPUT is 82.0°F

- Press **Next/Previous** keys to navigate.

Used With: Units w/MWU ENABLED
Possible Values:
[See "**Possible Values:**" Above]

Active Space Humidity Sensor Input From
RTM SPACE HUMIDITY INPUT is 55%

- Press **Next/Previous** keys to navigate.

Used With: Units w/Dehumid. or Humid.
Option
Possible Values:
RTM SPACE HUMIDITY INPUT
ECEM RA HUMIDITY INPUT
BAS/NETWORK
Range: 10 to 90%

Active Rapid Restart Sensor Input From
ECEM RETURN AIR TEMP INPUT is 82.0°F

- Press **Next/Previous** keys to navigate.

Used With: Units w/Rapid Restart.
Possible Values:
[See "**Possible Values:**" Above]

Active Space CO₂ Sensor Input From
VCM SPACE CO₂ INPUT is 600 PPM

- Press **Next/Previous** keys to navigate.

Used With: Units w/Fresh Air
Measurement (VCM) w/DCV, or CO₂
Reset ENABLED
Possible Values:
VCM SPACE CO₂ INPUT
BAS/NETWORK
Range: 50 to 2000 PPM

Active Dehumid OVRD Temp Input From
RTM ZONE TEMP INPUT is 73.5°F

- Press **Next/Previous** keys to navigate.

Used With: Units w/Dehumid. Option
Possible Values:
RTM ZONE TEMP INPUT
NSB PANEL TEMP SENSOR INPUT
RTM AUX TEMP INPUT
HEAT MODULE AUX TEMP INPUT
ECEM RETURN AIR TEMP INPUT
BAS/NETWORK SENSOR
Range: -40 to 200°F

Active Zone Reset Temp Sensor Input From
RTM ZONE TEMP INPUT is 82.0°F

- Press **Next/Previous** keys to navigate.

Used With: All Units with Reset Select not selected as None.

Possible Values:
[See "**Possible Values:**" Above]

Active OA Temperature Sensor Input From
RTM OUTSIDE AIR TEMP INPUT is 86.0°F

- Press **Next/Previous** keys to navigate.

Used With: All Units

Possible Values:
RTM OUTSIDE AIR TEMP INPUT BAS/
NETWORK
Range: -40 to 200°F

Active Outside Air Humidity Input From
OA HUMIDITY SENSOR INPUT is 30 %

- Press **Next/Previous** keys to navigate.

Used With: Units w/Economizer Option

Possible Values:
OA HUMIDITY SENSOR INPUT
BAS/NETWORK SENSOR
Range: 10 to 90%

Active Supply Air Press Input From
RTM SA PRESSURE INPUT is 2.1 IWC

- Press **Next/Previous** keys to navigate.

Used With: VVDA or Units w/Supply Air Pressure Sensor Present

Possible Values:
RTM SA PRESSURE INPUT
BAS/NETWORK
Range: 0 to 7.9 IWC

Active Space Pressure Input From
ECEM SPACE PRESSURE INPUT is 0.08 IWC

- Press **Next/Previous** keys to navigate.

Used With: Units w/Statitrac Option

Possible Values:
ECEM SPACE PRESSURE INPUT
BAS/NETWORK
Range: -0.67 to 0.67 IWC

Temp Sensor Input Being Monitored:
RTM ZONE TEMP INPUT is 82.0°F

- Press **Next/Previous** keys to navigate.

Used With: All Units

Possible Values:
RTM ZONE TEMP INPUT
NSB PANEL TEMP SENSOR INPUT
RTM AUX TEMP INPUT
HEAT MODULE AUX TEMP INPUT
ECEM RETURN AIR TEMP INPUT
BAS/NETWORK SENSOR
Range: -40 to 200°F



STATUS Menu

End of Submenu (NEXT) to Enter STATUS

- Press **Next/Previous** keys to navigate.

TEMPERATURE INPUT STATUS SUBMENU SCREENS

Temperature Input Status Submenu
Press ENTER to View Data in This Submenu

Used With: All Units

- Press the **Next** key to skip this Submenu.

Temp Measured By Sensor Connected To
RTM SUPPLY AIR TEMP INPUT 50.0°F

Used With: All Units

- Press **Next/Previous** keys to navigate.

Temp Measured By Sensor Connected To
RTM ZONE TEMP INPUT 82.0°F

Used With: All Units

- Press **Next/Previous** keys to navigate.

Temp Measured By Sensor Connected To
NSB PANEL TEMP SENSOR INPUT 79.5°F

Used With: Units w/NSB Panel Installed

- Press **Next/Previous** keys to navigate.

Temp Measured By Sensor Connected To
RTM AUX TEMP INPUT 62.0°F

Used With: All Units

- Press **Next/Previous** keys to navigate.

Temp Measured By Sensor Connected To
RTM OUTSIDE AIR TEMP INPUT 86.0°F

Used With: All Units

- Press **Next/Previous** keys to navigate.

Temp Measured By Sensor Connected To
HEAT MODULE AUX TEMP INPUT 82.0°F

Used With: Units w/Heat Installed

- Press **Next/Previous** keys to navigate.

Temp Measured By Sensor Connected To ECEM RETURN AIR TEMP INPUT	78.0°F
--	--------

Used With: Units w/Comparative Enthalpy Installed

- Press **Next/Previous** keys to navigate.

Temp Measured By Sensor Connected To VCM MODULE AUX TEMP INPUT	50.0°F
---	--------

Used With: Units w/VCM Module Installed

- Press **Next/Previous** keys to navigate.

End of Submenu (NEXT) to Enter STATUS

- Press **Next/Previous** keys to navigate.

LOCAL HARDWIRED INPUT STATUS SUBMENU SCREENS

Local Hardwired Input Status Submenu Press ENTER to View Data in This Submenu
--

Used With: All Units

- Press the **Next** key to skip this Submenu.

IntelliPak II Config Input:	CLOSED
Dehumidification Config Input:	OPEN

Used With: All Units
Possible Values: OPEN/CLOSED

- Press **Next/Previous** keys to navigate.

RTM Supply Airflow Proving:	FLOW
RTM Exhaust Airflow Proving:	FLOW

Used With: All Units
Possible Values: Flow, No Flow
Bottom Left Field:

- "RTM Exhaust..." shown for Power Exhaust w/o Return Fan.
- "RTM Return..." shown for Power Exhaust w/ Return Fan.

RTM Exhaust Airflow Proving
RTM Return Airflow Proving

- Press **Next/Previous** keys to navigate.

RTM Remote Min Position Pot Input	0 %
-----------------------------------	-----

Note: If potentiometer input is out of range (> 350 ohms) this screen will not appear.

Used With: Units w/Outside Air Damper and Minimum Position Source is RTM.
Possible Values: 0 to 100%

- Press **Next/Previous** keys to navigate.

RTM Supply Air Pressure Input	2.1 IWC
-------------------------------	---------

Used With: VVDA or Units w/Supply Air Pressure is present.
Possible Values: 0 to 5.0 IWC

- Press **Next/Previous** keys to navigate.



STATUS Menu

RTM Outside Air Humidity	55 %
ECEM Return Air Humidity	46 %

Used With: Units w/Economizer Option
Possible Values: 10 to 90%

"OA Humidity" shown only if comparative enthalpy installed.
"RA Humidity" shown only if comparative enthalpy installed, or non-IPakII units with humidification control.

- Press **Next/Previous** keys to navigate.

RTM Space Humidity	10 %
--------------------	------

Used With: Units w/Dehumid. or Humid. Option
Possible Values: 10 to 90%

- Press **Next/Previous** keys to navigate.

ECEM Space Pressure Input	0.08 IWC
---------------------------	----------

Used With: Units w/Statitrac Option
Possible Values: -0.67 to 0.67 IWC

- Press **Next/Previous** keys to navigate.

VCM Outside Air Flow Input	350.0 CCFM
----------------------------	------------

Used With: Units w/Fresh Air Measurement (VCM)
Possible Values: 0 to *Max Unit Air Flow*
[See "Table 7. Max Unit Airflows" on page 91" in the *Setpoints* Section]

- Press **Next/Previous** keys to navigate.

VCM CO ₂ Level Input	1512 PPM
---------------------------------	----------

Used With: Units w/Fresh Air Measurement (VCM) w/DCV, or CO₂ Reset is ENABLED
Possible Values: 50 to 2000 PPM

- Press **Next/Previous** keys to navigate.

MPM Return Plenum Pressure Input	0.0 IWC
----------------------------------	---------

Screen shown only if unit with Return Fan installed
Possible Values: -0.7 to 3.5 IWC

- Press **Next/Previous** keys to navigate.

Compr Diff Pressure Control is Installed	
--	--

Used With: Units with high compressor pressure differential control.
Installed or [screen not shown]
Possible Values: Installed or [screen not shown]

- Press **Next/Previous** keys to navigate.

End of Submenu (NEXT) to Enter STATUS	
---------------------------------------	--

- Press **Next/Previous** keys to navigate.

GBAS (5VDC) MODULE STATUS SUBMENU SCREENS

GBAS (5VDC) Module Status Submenu
 Press ENTER to View Data in This Submenu

- Press the **Next** key to skip this Submenu.

Used With: Units w/GBAS (5VDC)
 Installed

GBAS 0-5VDC Module Input 1 0.00 VDC
 Assigned: Not Assigned

Note: There will be **4** screens shown for this configuration. The first screen will be for **Input 1** setpoint assignment. The next screens will be identical and will show setpoint assignments for **Input 2**, **Input 3**, and **Input 4**.

- Press **Next/Previous** keys to navigate.

Used With: Units w/GBAS (5VDC)
 Installed
Possible Values: Input: 0.0 to 5 VDC

Bottom Right Field:

- Not Assigned
- OCC ZONE COOLING SETPOINT
- UNOCC ZONE COOLING SETPOINT
- OCC ZONE HEATING SETPOINT
- UNOCC ZONE HEATING SETPOINT
- SUPPLY AIR COOLING SETPOINT
- SUPPLY AIR HEATING SETPOINT
- SPACE PRESSURE SETPOINT
- SA PRESSURE SETPOINT
- MIN OA FLOW SETPOINT
- MWU SETPOINT
- ECON DRY BULB ENABLE SETPOINT
- MINIMUM POSITION SETPOINT
- OCC DEHUMIDIFICATION SETPOINT
- UNOCC DEHUMIDIFICATION SETPOINT
- SUPPLY AIR REHEAT SETPOINT
- OCC HUMIDIFICATION SETPOINT
- UNOCC HUMIDIFICATION SETPOINT

GBAS (0-5VDC) DemandLimit Input Status
 OPEN

- Press **Next/Previous** keys to navigate.

Used With: Units w/GBAS (5VDC)
 Installed

Possible Values: OPEN, CLOSED

GBAS 0-5VDC Module Relay Output Status
 Output 1 OFF

Used With: Units w/GBAS (5VDC)
 Installed



STATUS Menu

Note: There will be **5** screens shown for this configuration. The first screen shows the relay status for **Output 1** and indicates the associated Alarm Diagnostic has tripped. The next screens are identical and will show **Output 2, Output 3, Output 4** and **Output 5** relay status.

- Press **Next/Previous** keys to navigate.

GBAS (5VDC) Hardware Configuration
The Value Returned From This Input: XXX

- Press **Next/Previous** keys to navigate.

End of Submenu (Next) to enter Status

- Press **Next/Previous** keys to navigate.

GBAS (10VDC) MODULE STATUS SUBMENU SCREENS

GBAS (10VDC) Module Status Submenu
Press ENTER to View Data in This Submenu

- Press the **Next** key to skip this Submenu.

GBAS (10VDC) Analog Input 1 0.00 VDC
Assigned: NOT ASSIGNED

Note: There will be **4** screens shown for this configuration. The first screen will be for **Input 1** setpoint assignment. The next screens will be identical and will show setpoint assignments for **Input 2, Input 3, and Input 4.**

- Press **Next/Previous** keys to navigate.

GBAS (0-10VDC) Demand Limit Input Status
Open

- Press **Next/Previous** keys to navigate.

Possible Values: ON, OFF

Note: Please review the "Diagnostics Troubleshooting Chart" in the "DIAGNOSTICS Menu" section to see the list of diagnostics associated with each module. (Refer to the "Diagnostics Displayed" column for the specified module.)

Used With: Units w/GBAS (5VDC) Installed

Possible Values: 0-255

Used With: Units w/GBAS (10VDC) Installed

Used With: Units w/GBAS (10VDC) Installed

Possible Values:

Input: 0.0 to 10.0 VDC

Bottom Right Field:

[See **GBAS(5VDC)** Above for Assignments]

Used With: Units w/GBAS (10VDC) Installed

Possible Values: Open, Closed

GBAS (0-10VDC) Binary Output 1 OFF
Assigned: OUTPUT IS NOT ASSIGNED

Used With: Units w/GBAS (10VDC)
Installed

Possible Values: Output: ON, OFF

Bottom Right Field:

OUTPUT IS NOT ASSIGNED
INDICATE ANY COMP IS RUNNING
INDICATE UNIT AT MAX CAPACITY
INDICATE SELECTED DIAG ALARMS

[See "**Alarm Listings**" in *RTM Alarm Outputs* Below]

- Press **Next/Previous** keys to navigate.

GBAS (10VDC) Analog Output 1 0.00 VDC
Assigned: NOT ASSIGNED

Used With: Units w/GBAS (10VDC)
Installed

Possible Values:

Output: 0.0 to 10.0 VDC

Bottom Right Field:

NOT ASSIGNED
OUTSIDE AIR TEMPERATURE
ACTIVE ZONE TEMPERATURE
ACTIVE SUPPLY AIR TEMPERATURE
ACTIVE SUPPLY AIR PRESSURE
ACTIVE SPACE PRESSURE
ACTIVE SPACE RELATIVE HUMIDITY
ACTIVE OA RELATIVE HUMIDITY
ACTIVE SPACE CO₂ LEVEL
ACTIVE COOLING CAPACITY
ACTIVE HEATING CAPACITY
ACTIVE OA DAMPER POSITION
ACTIVE OUTDOOR AIRFLOW

- Press **Next/Previous** keys to navigate.

End of Submenu (NEXT) to Enter STATUS

- Press **Next/Previous** keys to navigate.



SETUP Menu

After the unit is installed, the control modules must be programmed with certain setup information in order to operate and function properly. The data necessary for unit operation will vary depending on certain factors such as unit size, type, and installed options.

The setup menu is used to input initial operating information such as control parameters, setpoint source selection, sensor source selections, ventilation override definitions, functions enable/disable, text display (Language), units displayed (English or SI), unit diagnostic assignments, and system tuning parameters. When a setup screen is displayed for 30 minutes without a key being pressed, the LCD screen will revert to the appropriate power-up display. If this happens, press the **Setup** key again to return to the setup menu.

Information that pertains to when the screens are shown, the possible values that may be designated, and the factory presets for these values is located to the right of each programmable screen.

Note:

1. Many of the screens displayed in this section are applicable only for the options that are installed in the unit and may not be visible on your unit.
2. If a screen is not visible on the Unit Human Interface Module, refer to the "Used With" information listed to the right of each screen in this book.

Modifying Selections: Starting with the first setup screen program the necessary information by using the appropriate keys to navigate (Next and Previous) and make changes (+ and -) to the selections. Once the selection has been changed to the desired value, the user has the following options to either *Cancel* or *Accept* the pending change:

- To *Cancel*, press the **Cancel** key to remove the change, the display will revert to the original value.
- To *Accept*, press the **Enter** key to confirm the new choice.

Press the **Setup** key to begin viewing or modifying the setup screens.

TOP LEVEL SETUP SCREEN

Display Text in:	ENGLISH LANGUAGE
Display Units Using:	ENGLISH NOTATION

Used With: All Units

Factory Presets:

Text Language: ENGLISH
Units Notation: ENGLISH

Possible Values:

Language: ENGLISH, FRENCH, SPANISH
Notation: ENGLISH, SI

- Press **Next/Previous** keys to navigate.

GENERAL UNIT FUNCTIONS SETUP SUBMENU SCREENS

General Unit Functions Setup Submenu Press ENTER to Review or Adjust

Used With: All Units

- Press the **Next** key to skip this Submenu.

If Remote Panel Mode Input Not Present:
System Mode: AUTO Supply Fan Mode: AUTO

- Press **Next/Previous** keys to navigate.

Used With:

System Mode: All Units
Supply Fan Mode: CV SZVAV

Factory Presets:

System: AUTO
Supply Fan: AUTO

Possible Values:

System: OFF, AUTO
Supply Fan: ON, AUTO

Reduce Multi-Unit Startup Power Demand
After Power-Up, Delay Unit Start 0 Sec

- Press **Next/Previous** keys to navigate.

Used With: All units.**Factory Presets:** 0 Sec**Possible Values:** 0 to 255 Sec

Single Zone VAV Econ Control: **ENABLED**
Single Zone VAV Heat Control: **DISABLED**

- Press **Next/Previous** keys to navigate.

Used With: SZVAV Units**Factory Presets:**

Econ: ENABLED
Heat: DISABLED

Possible Values:

ENABLED, DISABLED

Daytime Warmup Function: **ENABLED**

- Press **Next/Previous** keys to navigate.

Used With: VV/CVDA Units w/Heat Installed**Factory Presets:** ENABLED**Possible Values:** ENABLED, DISABLED

Morning Warmup Function: **ENABLED**
Morning Warmup Type: **FULL CAPACITY**

- Press **Next/Previous** keys to navigate.

Used With: Units w/Heat Installed**Factory Presets:**

Function: ENABLED
Type: CYCLING CAPACITY

Possible Values:

Function: ENABLED, DISABLED
Type: FULL CAPACITY, CYCLING CAP.

Supply Air Tempering Function: **ENABLED**
Warm Up Outside Air Used For Ventilation

- Press **Next/Previous** keys to navigate.

Used With: VV/CVDA Units w/Modulating Heat (w/Electric Heat if IPakII), or CVZT Units w/Staged Heat Installed.**Factory Preset:** ENABLED**Possible Values:** ENABLED, DISABLED



SETUP Menu

Unocc Mech Cooling Function:	ENABLED
Unocc Heating Function:	ENABLED

"Unocc Heating Function" only shown if unit has heat installed.

- Press **Next/Previous** keys to navigate.

Used With: Units w/DX Cooling, or Air Handler w/Chilled Water, and w/Heat Installed

Factory Presets: ENABLED

Possible Values: ENABLED, DISABLED

Occupied Dehumid Function:	ENABLED
Unoccupied Dehumid Function:	ENABLED

- Press **Next/Previous** keys to navigate.

Used With: Units w/Dehumidification

Possible Values: ENABLED, DISABLED

Occ Humidification Function:	DISABLED
Unocc Humidification Function:	DISABLED

- Press **Next/Previous** keys to navigate.

Used With: Units w/Humidification

Factory Presets: DISABLED

Possible Values: ENABLED, DISABLED

Rapid Restart Economizer Ctrl:	DISABLED
Compressors Used for Cooling Control:	

- Press **Next/Previous** keys to navigate.

Used With: Rapid Restart Units

Factory Presets: DISABLED

Possible Values: ENABLED, DISABLED

VCM Preheater Output Control:	ENABLED
Activate If Preheat Temp Below Setpoint	

- Press **Next/Previous** keys to navigate.

Used With: Units w/Fresh Air Measurement (VCM) Option

Factory Preset: DISABLED

Possible Values: ENABLED, DISABLED

Demand Limit Definition:	
Cooling: None	Heating: None

"Heating" only shown if unit has heat installed.

A selection of "None" indicates the unit will not limit the cooling or heating capacity of the unit. A selection of "25%" indicates that 1 of the 4 compressors will be inhibited from operation.

- Press **Next/Previous** keys to navigate.

Used With: Units w/DX Cooling and/or Heat, and GBAS(5VDC), GBAS(10VDC) or BAS/Network Installed

Factory Presets: None

Possible Values:

Cooling: None, 25*, 50, 75*, 100%

Heating: None, 50% or 100%

*allowed only w/DX Cooling \geq 40Ton

**Evap Temperature Limit. Shut Off Circuit
if (Leaving - Entering) Exceeds: 35°F**

Used With: All Units
Factory Preset: 35°F
Possible Values: 25 to 40°F

Note: On units with Dehumidification installed a non-adjustable Evap Temperature Limit of 40°F is used for the Reheat Circuit only.

- Press **Next/Previous** keys to navigate.

**Coil Frost Cutout Temperature. Shut off
Compressors If Evap Temp Is Below: 30°F**

Used With: Units w/DX Cooling
Factory Preset: 30°F
Possible Values: 25 to 35°F

- Press **Next/Previous** keys to navigate.

**Isolation Damper Interlock: ENABLED
SA Proving Must Open Before Fan Start**

Used With: All Units
Factory Preset: DISABLED
Possible Values: DISABLED, ENABLED

If ENABLED, "SA Proving Must Open Before Fan Start" is shown. If DISABLED, the bottom line is blank.

- Press **Next/Previous** keys to navigate.

End of Submenu (NEXT) to Enter SETUP

- Press **Next/Previous** keys to navigate.

VAV CONTROL FUNCTIONS SUBMENU SCREENS

**VAV Control Functions Submenu
Press ENTER to Review or Adjust**

Used With: All Units

Press the **Next** key to skip this Submenu.

**Supply Air Temp Reset type:
Cooling: NONE Heating: NONE**

Used With: VV/CVDA Units w/Cooling
and Heat Installed
Factory Preset: NONE
Possible Values: NONE, ZONE, OA

"Heating" only shown if unit has heat installed.

- Press **Next/Previous** keys to navigate.



SETUP Menu

Supply Air Temp Zone Reset For Cooling:
Start Temp: 72°F End Temp: 69°F

- Press **Next/Previous** keys to navigate.

Supply Air Temp OA Reset For Cooling:
Start Temp: 90°F End Temp: 70°F

- Press **Next/Previous** keys to navigate.

Supply Air Temp Zone Reset For Cooling:
Maximum Amount of Reset Applied: 5°F

- Press **Next/Previous** keys to navigate.

Supply Air Temp OA Reset For Cooling:
Maximum Amount of Reset Applied: 5°F

- Press **Next/Previous** keys to navigate.

Supply Air Temp Zone Reset For Heating:
Start Temp: 65°F End Temp: 68°F

- Press **Next/Previous** keys to navigate.

Supply Air Temp OA Reset For Heating:
Start Temp: 10°F End Temp: 60°F

- Press **Next/Previous** keys to navigate.

Used With: Units w/SA Cooling Reset
Type Set to "ZONE"

Factory Presets:

Start Temp: 72°F
End Temp: 69°F

Possible Values:

Start Temp: 51 to 90°F
End Temp: 50 to 89°F

Used With: Units w/SA Cooling Reset
Type Set to "OA"

Factory Presets:

Start Temp: 90°F
End Temp: 70°F

Possible Values:

Start Temp: 1 to 95°F
End Temp: 0 to 94°F

Used With: Units w/SA Cooling Reset
Type Set to "ZONE"

Factory Presets: 5°F

Possible Values: 0 to 20°F

Used With: Units w/SA Cooling Reset
Type Set to "OA"

Factory Presets: 5°F

Possible Values: 0 to 20°F

Used With: Units w/SA Heating Reset
Type Set to "ZONE"

Factory Presets:

Start Temp: 65°F
End Temp: 68°F

Possible Values:

Start Temp: 50 to 89°F
End Temp: 51 to 90°F

Used With: Units w/SA Heating Reset
Type Set to "OA"

Factory Presets:

Start Temp: 10°F
End Temp: 60°F

Possible Values:

Start Temp: 0 to 94°F
End Temp: 1 to 95°F

**Supply Air Temp Zone Reset For Heating:
Maximum Amount of Reset Applied: 10°F**

- Press **Next/Previous** keys to navigate.

Used With: Units w/SA Heating Reset
Type Set to "ZONE"

Factory Presets: 10°F

Possible Values: 10 to 90°F

**Supply Air Temp OA Reset For Heating:
Maximum Amount of Reset Applied: 10°F**

- Press **Next/Previous** keys to navigate.

Used With: Units w/SA Heating Reset
Type Set to "OA"

Factory Presets: 10°F

Possible Values: 10 to 90°F

VAV Box Max Stroke Time: 6 Min

- Press **Next/Previous** keys to navigate.

Used With: VVDA Units

Factory Presets: 6 Min

Possible Values: 0 to 10 Min

Max Occupied IGV/VFD Command: 100%

- Press **Next/Previous** keys to navigate.

Used With: VVDA

Factory Presets: 100%

Possible Values: 0 to 100%

End of Submenu (NEXT) to Enter SETUP

- Press **Next/Previous** keys to navigate.



SETUP Menu

ECONOMIZER CONTROL FUNCTIONS SUBMENU SCREENS

Economizer Control Functions Submenu
Press ENTER to Review or Adjust

- Press **Next/Previous** keys to navigate.

Used With: Units w/Economizer Option

Economizer Ctrl Enable Type: REFERENCE
When Comparative Enthalpy Not Available

- Press **Next/Previous** keys to navigate.

Used With: Units w/Economizer Option

Factory Presets: REFERENCE

Possible Values: REFERENCE,
DRYBULB

Unocc Air Economizer Function: ENABLED

- Press **Next/Previous** keys to navigate.

Used With: Units w/Economizer Option

Factory Presets: ENABLED

Possible Values: ENABLED, DISABLED

End of Submenu (NEXT) to Enter SETUP

- Press **Next/Previous** keys to navigate.

HEAD PRESSURE CTRL SETUP SUBMENU SCREENS

Head Pressure Ctrl Setup Submenu
Press ENTER to Review or Adjust

- Press the **Next** key to skip this Submenu.

Used With: Units w/DX Cooling

Sump Drain Valve Relay Control is: DRAIN
During Unit Power Loss Conditions

- Press **Next/Previous** keys to navigate.

Used With: Units w/Water-Cooled
Condensers Installed

Factory Preset: DRAIN

Possible Values: HOLD, DRAIN

Sump Water Purge Timers
Interval: 3 Hrs. Duration 60 Sec

"Sump Purge Duration Timer" only shown if *Interval Timer* is not set to DISABLED.

- Press **Next/Previous** keys to navigate.

Used With: Units w/Water-Cooled
Condensers Installed

Factory Preset:

Interval Timer: 3 Hrs

Duration Timer: 30 Sec

Possible Values:

Interval Timer: 1 to 12 Hrs, DISABLED

Duration Timer: 5 to 255 Sec

Sump Water Heater Setpoint: 38°F
Low Sump Temp Activates Heater Output

- Press **Next/Previous** keys to navigate.

Used With: Units w/Water-Cooled Condensers and Sump Heat Installed
Factory Preset: 38°F
Possible Values: 38 to 43°F

Cond Temp Control Band
Lower Limit: 80°F Upper Limit: 120°F

- Press **Next/Previous** keys to navigate.

Used With: Units w/DX Cooling
Factory Presets:
Upper Limit: 120°F
Lower Limit: 80°F
Possible Values:
Upper Limit: 110 to 130°F
Lower Limit: 70 to 90°F

Cond Temp Control Band
Temporary Low Limit Suppression: 10°F

- Press **Next/Previous** keys to navigate.

Used With: Units w/DX Cooling
Factory Presets: 10°F
Possible Values: 0 to 20°F

Cond Temp
Efficiency Check Point: 105°F

- Press **Next/Previous** keys to navigate.

Used With: Units w/DX Cooling
Factory Presets: 105°F
Possible Values: 95 to 115°F

Cond Temp
Low Ambient Control Point: 90°F

Low Ambient Dampers control condensing temperature to this value.

- Press **Next/Previous** keys to navigate.

Used With: Units w/DX Cooling w/Low Ambient Option
Factory Presets: 90°F
Possible Values: 80 to 100°F

Alternate Unit Refrigerant Type: ENABLED

Units w/R22 should have this set to ENABLED

- Press **Next/Previous** keys to navigate.

Used With: Units w/DX Cooling
Factory Presets: DISABLED
Possible Values: ENABLED/DISABLED

End of Submenu (NEXT) to Enter SETUP

- Press **Next/Previous** keys to navigate.



SETUP Menu

SENSOR SOURCE SELECTIONS SUBMENU SCREENS

Sensor Source Selections Submenu
Press ENTER to Review or Adjust

- Press the **Next** key to skip this Submenu.

Used With: All Units.

For Daytime Warmup Temp Ctrl, Use sensor
Connected to: RTM ZONE TEMP INPUT

- Press **Next/Previous** keys to navigate.

Used With: Units w/DWU ENABLED
Factory Preset: RTM ZONE TEMP INPUT
Possible Values:
RTM ZONE TEMP INPUT
NSB PANEL TEMP SENSOR INPUT
RTM AUX TEMP INPUT
HEAT MODULE AUX TEMP INPUT
ECEM RETURN AIR TEMP INPUT

For Unoccupied Zone Temp Ctrl, Use Sensor
Connected To: RTM ZONE TEMP INPUT

- Press **Next/Previous** keys to navigate.

Used With: All CV or SZVAV Unit, or
VAV w/DWU Installed
Factory Preset: RTM ZONE TEMP INPUT
Possible Values:
[See "DWU Source Selection" Above]

For Unoccupied Zone Temp Ctrl, Use Sensor
Connected To: RTM ZONE TEMP INPUT

- Press **Next/Previous** keys to navigate.

Used With: All Units
Factory Preset: RTM ZONE TEMP INPUT
Possible Values:
[See "DWU Source Selection" Above]

For Morning Warmup Temp Ctrl, Use Sensor
Connected To: RTM ZONE TEMP INPUT

- Press **Next/Previous** keys to navigate.

Used With: Units w/MWU ENABLED
Factory Preset: RTM ZONE TEMP INPUT
Possible Values:
[See "DWU Source Selection" Above]

For Space Humidity Control, Use Sensor
Connected To: RTM SPACE HUMIDITY INPUT

- Press **Next/Previous** keys to navigate.

Used With: Units w/Dehumidification or
Humidification Options
Factory Preset:
RTM SPACE HUMID INPUT
Possible Values:
RTM SPACE HUMIDITY INPUT
ECEM RA HUMIDITY INPUT

For Dehumid OVRD Zone Temp, Use Sensor
Connected To: RTM ZONE TEMP INPUT

- Press **Next/Previous** keys to navigate.

Used With: Units w/Dehumid. Option
Factory Preset: RTM ZONE TEMP INPUT
Possible Values:
[See "DWU Source Selection" Above]

For Zone Reset Function, Use Sensor
Connected To: RTM ZONE TEMP INPUT

- Press **Next/Previous** keys to navigate.

Used With: All Units
Factory Preset: RTM ZONE TEMP INPUT
Possible Values:
[See "DWU Source Selection" Above]

For Rapid Restart Function, Use Sensor
Connected To: RTM ZONE TEMP INPUT

- Press **Next/Previous** keys to navigate.

Used With: Units w/Rapid Restart
Factory Preset: RTM ZONE TEMP INPUT
Possible Values:
[See "DWU Source Selection" Above]

Monitor Specific Temp Input, Use Sensor
Connected To: RTM ZONE TEMP INPUT

- Press **Next/Previous** keys to navigate.

Used With: All Units
Factory Preset: RTM ZONE TEMP INPUT
Possible Values:
[See "DWU Source Selection" Above]

End of Submenu (NEXT) to Enter SETUP

- Press **Next/Previous** keys to navigate.

OUTSIDE AIR VENTILATION SETUP SUBMENU SCREENS

Outside Air Ventilation Setup Submenu
Press ENTER to Review or Adjust

- Press the **Next** key to skip this Submenu.

Used With: Units w/Fresh Air Option

Demand Controlled Ventilation: ENABLED
DCV Setpoint Modified By Space CO₂ Level

- Press **Next/Previous** keys to navigate.

Used With: Units w/ Fresh Air Measurement (VCM) w/DCV or OA Damper Min Position w/DCV Installed
Factory Preset: DISABLED
Possible Values: ENABLED, DISABLED
Bottom Field:
If ENABLED: "DCV Setpoint Modified By Space CO₂ Level"
If DISABLED: (blank)



SETUP Menu

DCV Active Supply Fan Control: ENABLED
Allow Supply Fan to Energize for DCV

Used With: CVZT or VVZT Units w/DCV set to ENABLED.

Factory Preset: DISABLED

Possible Values: DISABLED, ENABLED,

Bottom Field:

If ENABLED: "Allow Supply Fan to Energize for DCV"

If DISABLED: (blank)

- Press **Next/Previous** keys to navigate.

OA Flow Compensation Function: DISABLED
Use fixed OA Damper Minimum Position

Used With: VVDA or VVZT Units w/Economizer

Factory Preset: DISABLED

Possible Values: ENABLED, DISABLED

Bottom Field:

If ENABLED: "OA Damper Min Pos Depends on IGV/VFD Pos"

If DISABLED: "Use Fixed OA Damper Minimum Position"

- Press **Next/Previous** keys to navigate.

OA Flow CO ² Reset Function: ENABLED
CO ² Start: 800 PPM CO ² Max: 1000 PPM

Note: Bottom line will not be shown if function is DISABLED.

Used With: IPak-I Units w/Fresh Air Measurement (VCM) w/o DCV Option

Factory Preset:

Function: DISABLED

Start: 800, Max: 1000

Possible Values:

Function: ENABLED, DISABLED

Start: 50 to 1900

Max: 150 to 2000

- Press **Next/Previous** keys to navigate.

OA Flow Calibration Data	(Left)
Gain 1.0 Offset 0 CCFM	

"Left" refers to the flow station on the left side of the unit when looking into the unit's airstream.

- Press **Next/Previous** keys to navigate.

Used With: Units w/Fresh Air Measurement (VCM) w/DCV Option

Factory Preset: Gain 1.0, Offset 0 CCFM

Possible Values:

Gain: 0.5 to 1.5

Offset: -25 to 25 CCFM

OA Flow Calibration Data	(Right)
Gain 1.0 Offset 0 CCFM	

"Right" refers to the flow station on the right side of the unit when looking into the unit's airstream.

- Press **Next/Previous** keys to navigate.

Used With: Units w/Fresh Air Measurement (VCM) w/DCV Option

Factory Preset: Gain 1.0, Offset 0 CCFM

Possible Values:

Gain: 0.5 to 1.5

Offset: -25 to 25 CCFM

Maximum OA Flow at Design Conditions
OA Normalization: 350 CCFM

Used With: Units w/Return Fan and Fresh Air Measurement (VCM) w/DCV, Units w/Energy Recovery Wheel Option
Factory Preset: 1 CCFM
Possible Values: 0 to *Max Unit Airflow*
 [See "**Max Unit Airflows**" in *Setpoints* Section Below]

- Press **Next/Previous** keys to navigate.

OA Flow Calibration Data
Altitude: 0 Ft.

Used With: Units w/Return Fan and Fresh Air Measurement (VCM)
Factory Preset: 0 Ft (0 m)
Possible Values:
 [See "[Table 5. Flow Calibration - Altitude Correction Factor C.F.](#)" for assignments below.]

This correction factor is used to adjust airflow calculations due to density of air at different altitudes.

Table 5. Flow Calibration - Altitude Correction Factor C.F.

Feet	Meters	C.F.	Feet	Meters	C.F.
0	0	1.00	5500	1650	0.91
500	150	0.99	6000	1800	0.90
1000	300	0.98	6500	2000	0.89
1500	450	0.97	7000	2150	0.88
2000	600	0.97	7500	2300	0.87
2500	750	0.96	8000	2450	0.86
3000	900	0.95	8500	2600	0.85
3500	1050	0.94	9000	2750	0.85
4000	1200	0.93	9500	2900	0.84
4500	1350	0.92	10000	3050	0.83
5000	1500	0.91			

- Press **Next/Previous** keys to navigate.

End of Submenu (NEXT) to Enter SETUP

- Press **Next/Previous** keys to navigate.

Emergency Override Definitions (with LCI or BCI module installed)

When an LCI or BCI module is installed, the user can initiate one of five (5) Emergency Override sequences that have the following predefined unit operation via LonTalk or BACnet Communication:

PRESSURIZE

- Supply Fan – On
- Inlet Vanes - Open (if equipped)
- Return Fan VFD – Min
- Return Fan / Exhaust Damper - Off / Closed (if equipped)
- OA Dampers – Open
- Heat - All heat stages Off (staged gas and elec.); Hydronic heat & Mod Gas Heat output at 0%.
- Occupied / Unoccupied output – Energized
- VO Relay - Energized (with VOM module installed)
- VCM Preheater State - Off (with VCM installed)

DEPRESSURIZE

- Supply Fan – Off
- Inlet Vanes - Closed (if equipped)
- Return Fan VFD – Max
- Return Fan / Exhaust Damper - On / Open (if equipped)
- OA Dampers – Closed
- Heat - All heat stages Off (staged gas and elec.); Hydronic heat & Mod Gas Heat output at 0%.
- Occupied / Unoccupied output - De-energized
- VO Relay - Energized (with VOM module installed)
- VCM Preheater State - Off (with VCM installed)

PURGE

- Supply Fan – On
- Inlet Vanes - Open (if equipped)
- Return Fan / Exhaust Damper - On / Open (if equipped)
- Return Fan VFD – Max
- OA Dampers – Open
- Heat - All heat stages Off (staged gas and elec.); Hydronic heat & Mod Gas Heat output at 0%.
- Occupied / Unoccupied output – Energized
- VO Relay - Energized (with VOM module installed)
- VCM Preheater State - Off (with VCM installed)

SHUTDOWN

- Supply Fan – Off
- Inlet Vanes - Closed (if equipped)
- Return Fan / Exhaust Damper - Off / Closed (if equipped)
- Return Fan VFD – Min
- OA Dampers – Closed

- Heat - All heat stages Off (staged gas and elec.); Hydronic heat & Mod Gas Heat output at 0%.
- Occupied/Unoccupied output - De-energized
- VO Relay - Energized (with VOM module installed)
- VCM Preheater State - Off (with VCM installed)

FIRE

- Supply Fan – Off
- Inlet Vanes - Closed (if equipped)
- Return Fan / Exhaust Damper - Off / Closed (if equipped)
- Return Fan VFD – Min
- OA Dampers – Closed
- Heat - All heat stages Off (staged gas and elec.); Hydronic heat & Mod Gas Heat output at 0%.
- Occupied / Unoccupied output - De-energized
- VO Relay - Energized (with VOM module installed)
- VCM Preheater State - Off (with VCM installed)

Ventilation Override Mode Definitions (with VOM installed)

Each of the five VOM modes have factory presets, that when initiated by a VOM contact closure, will accomplish five predefined operations (listed below). Any of the five sequences may be user-redefined by changing the factory presets at the unit mounted Human Interface or through Tracer.

Ventilation Override Mode A - (Unit Off)

- Supply Fan – Off
- Inlet Vanes / VFD - Closed / 0%
- Return Fan VFD – Min
- Return Fan / Exhaust Damper – Off / Closed (if equipped)
- OA Dampers – Closed
- Heat - All heat stages Off (staged gas and elec.); Hydronic heat & Mod Gas Heat output at 0%.
- Occupied / Unoccupied output – Deenergized
- VO Relay – Energized
- VCM Preheater State - Off (with VCM installed)

Ventilation Override Mode B - (Pressurize)

- Supply Fan – On
- Inlet Vanes / VFD - Open / 100%
- Return Fan VFD – Min
- Return Fan / Exhaust Damper - Off / Closed (if equipped)
- OA Dampers – Open
- Heat - All heat stages Off (staged gas & elec.); Hydronic heat & Mod Gas Heat output at 0%.
- Occupied / Unoccupied output – Energized
- VO Relay – Energized
- VCM Preheater State - Off (with VCM installed)

SETUP Menu

Ventilation Override Mode C - (Exhaust)

- Supply Fan – Off
- Inlet Vanes - Closed (if equipped)
- Return Fan / Exhaust Damper – On / Open (if equipped)
- Return Fan VFD – Max
- OA Dampers – Closed
- Heat - All heat stages Off (staged gas and elec.); Hydronic heat & Mod Gas Heat output at 0%.
- Occupied / Unoccupied output – Deenergized
- VO Relay – Energized
- VCM Preheater State - Off (with VCM installed)

Ventilation Override Mode D - (Purge)

- Supply Fan – On
- Inlet Vanes / VFD - Open / 100%
- Return Fan VFD – Max
- Return Fan / Exhaust Damper - On / Open (if equipped)
- OA Dampers – Open
- Heat - All heat stages Off (staged gas and elec.); Hydronic heat & Mod Gas Heat output at 0%.
- Occupied / Unoccupied output – Energized
- VO Relay – Energized
- VCM Preheater State - Off (with VCM installed)

Ventilation Override Mode E - (Purge with Duct Pressure Control)

- Supply Fan – On
- Return Fan VFD – Max
- Inlet Vanes / VFD - Open/100% (Ctrl'd by SA Press control function, SA Press High Limit is disabled)
- Return Fan / Exhaust Damper - On / Open (if equipped)
- OA Dampers – Open
- Heat - All heat stages Off (staged gas and elec.) Hydronic & Mod Gas Heat output at 0%.
- Occupied / Unoccupied output – Energized
- VO Relay – Energized
- VCM Preheater State - Off (with VCM installed)

Note:

1. The five VOM modes A, B, C, D, E will have the factory defaults set to the above defined values.
2. "OFF" - will appear in the Ventilation Override screen after all VOM binary inputs have been reset (opened).

VENTILATION OVERRIDE MENU SCREENS

- | | |
|--|---|
| <p>Ventilation Override Definitions
Press ENTER to Review or Adjust</p> | <p>Used With: Units w/VOM Installed</p> |
| <ul style="list-style-type: none"> • Press the Next key to skip this Submenu. | |
| <p>Ventilation Override Definition Mode A
Supply Fan ON</p> | <p>Used With: Units w/VOM Installed
Possible Values: ON, OFF</p> |
| <ul style="list-style-type: none"> • Press Next/Previous keys to navigate. | |
| <p>Ventilation Override Definition Mode A
Supply Fan IGV/VFD MIN</p> | <p>Used With: Units w/VOM Installed
Possible Values: IN CONTROL, MIN, MAX</p> |
| <ul style="list-style-type: none"> • Press Next/Previous keys to navigate. | |
| <p>Ventilation Override Definition Mode A
Exhaust Fan/Dampers ON/OPEN</p> | <p>Used With: Units w/VOM and Power Exhaust w/Statitrac
Possible Values: ON/OPEN, OFF/CLOSED</p> |
| <ul style="list-style-type: none"> • Press Next/Previous keys to navigate. | |
| <p>Ventilation Override Definition Mode A
Return Fan/Exhaust Dampers OFF/CLOSED</p> | <p>Used With: Units w/VOM and Return Fan
Possible Values: OFF/CLOSED, ON/OPEN</p> |
| <ul style="list-style-type: none"> • Press the Next key to navigate forward. | |
| <p>Ventilation Override Definition Mode A
Exhaust Fan ON</p> | <p>Used With: Units w/VOM and Power Exhaust w/o Statitrac Installed
Possible Values: ON, OFF</p> |
| <ul style="list-style-type: none"> • Press Next/Previous keys to navigate. | |
| <p>Ventilation Override Definition Mode A
Return Fan VFD Command Min</p> | <p>Used With: Units w/VOM and Return Fan with Statitrac Installed
Possible Values: Return Fan VFD Command: MIN, MAX</p> |
| <ul style="list-style-type: none"> • Press Next/Previous keys to navigate. | |
| <p>Ventilation Override Definition Mode A
Outside Air Dampers OPEN</p> | <p>Used With: Units w/VOM and Economizer Option
Possible Values: OPEN, CLOSED</p> |
| <ul style="list-style-type: none"> • Press Next/Previous keys to navigate. | |
| <p>Ventilation Override Definition Mode A
VAV Box Relay DEENERGIZED</p> | <p>Used With: Units w/VOM Installed
Possible Values: ENERGIZED, DEENERGIZED</p> |
| <ul style="list-style-type: none"> • Press Next/Previous keys to navigate. | |



SETUP Menu

Ventilation Override Definition Mode A
Heat OFF

Used With: Units w/VOM and Heat Installed
Possible Values: OFF, IN CONTROL

- Press **Next/Previous** keys to navigate.

Ventilation Override Definition Mode A
VCM Preheater State IN CONTROL

Used With: Units w/ and OA Preheater Function Enabled
Possible Values: OFF, IN CONTROL

- Press **Next/Previous** keys to navigate.

Ventilation Override Definition Mode A
Ventilation Override Relay ENERGIZED

Used With: Units w/VOM Installed
Possible Values: ENERGIZED, DEENERGIZED

- Press **Next/Previous** keys to navigate.

Ventilation Override Definition Mode A
Enter Password to Lock Definition:

Used With: Units w/VOM Installed and Mode Not Locked

Note: After locking a MODE (by entering the password), the displays for that MODE becomes "Reporting" only and the definition cannot be changed unless the Ventilation Override Module is replaced. If the password was entered, pressing the NEXT key will scroll through the previous screens to confirm the selected choices for each mode as follows:

- Press **Next/Previous** keys to navigate.

Ventilation Override Mode A Is Locked
Supply Fan ON

Used With: Units w/VOM Mode Locked
Factory Presets: See Definitions Above
Possible Values: N/A

Note: This is "Reporting Only" display. After all of the "VOM A" entries have been viewed or modified, the following screen will be displayed:

- Press **Next/Previous** keys to navigate.

Ventilation Override Mode B
Supply Fan OFF

Used With: All Units
Factory Presets: See Definitions Above
Possible Values: ON, OFF

Note: Follow the preceding steps, used in programming Mode "A", to program VOM Mode "B", "C", "D", and "E" if modifications are needed.

- Press **Next/Previous** keys to navigate.

End of Submenu (NEXT) to Enter SETUP

- Press **Next/Previous** keys to navigate.

GBAS 0-5VDC MODULE I/O ASSIGNMENTS SCREENS

GBAS (5VDC) Module I/O Assignments
 Press **ENTER** to Review or Adjust

Used With: Units w/GBAS(5VDC) Installed

Press the **Next** key to skip this Submenu.

GBAS (5VDC) Analog Input 1 Assignment
 NOT ASSIGNED

Used With: Units w/GBAS(5VDC) Installed.

Factory Presets: NOT ASSIGNED

Possible Values:

Note: There are 3 additional screens associated with Input Assignments; "Analog Input 2", "Analog Input 3", and "Analog Input 4". Press the Next key to proceed through the remaining assignments.

- NOT ASSIGNED
- OCC ZONE COOLING SETPOINT
- UNOCC ZONE COOLING SETPOINT
- OCC ZONE HEATING SETPOINT
- UNOCC ZONE HEATING SETPOINT
- SPACE STATIC PRESSURE SETPOINT
- SA STATIC PRESSURE SETPOINT
- MIN OA FLOW SETPOINT
- MORNING WARMUP SETPOINT
- ECON DRY BULB ENABLE SETPOINT
- MINIMUM POSITION SETPOINT
- OCC DEHUMID SETPOINT
- UNOCC DEHUMID SETPOINT
- SUPPLY AIR REHEAT SETPOINT
- OCC HUMIDIFICATION SETPOINT
- UNOCC HUMIDIFICATION SETPOINT

- Press **Next/Previous** keys to navigate.

GBAS (5VDC) Output 1 Alarm Assignments
 Press **ENTER** to Review or Adjust

Used With: Units w/GBAS(5VDC) Installed

Factory Presets:

Press the **Next** key to skip this Submenu.

Note: There are 4 additional screens associated with Alarm Output Assignments: "Alarm Output 2", "Alarm Output 3", "Alarm Output 4", and "Alarm Output 5". The process of assigning diagnostics to those outputs is identical to what is described here for "Alarm Output 1".

- Output 1 = Dirty Filters
- Output 2 = Compressor Trip
- Compressor Trip - Ckt 1
- Compressor Trip - Ckt 2
- Low Pressure Control Open
- Low Pressure Control Open - Ckt 1
- Low Pressure Control Open - Ckt 2
- Comp Contactor/Drive Fail
- Comp Contactor/Drive Fail - Ckt 1
- Comp Contactor/Drive Fail - Ckt 2
- Output 3 = Heat Fail
- Output 4 = Supply Fan Failure
- Output 5 = Any Active Diagnostic

Possible Values: Refer to the list of diagnostics that can be assigned to each of the five (5) output definitions in the "DIAGNOSTICS Menu" section.

If **Enter** was pressed, proceed to the following 3 screens.



SETUP Menu

**Assign Diagnostic to Alarm Output 1?
Any Active Diagnostic (Yes)**

Used With: All Units w/GBAS(5VDC) Installed
Possible Values: Yes, No

Note: If "Yes" is selected at this screen, any active diagnostic will activate this output. A selection of "No" will allow the user to choose, from the following menus, which diagnostics activate the Alarm Output.

If **No** was entered, proceed to the following 2 screens.

**Assignment Submenu - RTM Alarms
Press ENTER To Review Or Adjust**

Used With: Units w/GBAS(5VDC) Installed and Any Active Diagnostic Set to "No"

Pressing the **Next** key will allow the user to skip this submenu.

Pressing the **Enter** key will allow the user to select any of the diagnostics associated with the RTM module to activate the associated Alarm Output.

Note: The user will be presented with similar Assignment Submenus for the following alarm sources: "SCM/MCM Alarms", "HEAT Alarms", "ECEM Alarms", "VOM Alarms", "VCM Alarms", "GBAS Alarms", "MDM Alarms", "MPM Alarms" and "BAS/Network Alarms".

Note: Please review the "Diagnostics Troubleshooting Chart" in the "DIAGNOSTICS Menu" section to see the list of diagnostics associated with each module. (Refer to the "Diagnostics Displayed" column for the specified module.)

If **Enter** was pressed, proceed to the following screen.

**Assign Diagnostic to Alarm Output 1?
RTM Zone Temp Sensor Failure (Yes)**

Used With: Units w/GBAS(5VDC)

Selecting "Yes" for each of the diagnostics displayed will activate the associated Alarm Output when that diagnostic is activated.

Note: The list of diagnostics displayed here will be dependent upon the module assignments selected. See the "Diagnostics Table" in the diagnostics menu section for the complete list displayed for each module.

- Press **Next/Previous** keys to navigate.

End of Submenu (NEXT) to Enter GBAS

- Press **Next/Previous** keys to navigate.

GBAS 0-10VDC MODULE I/O ASSIGNMENTS SCREENS

**GBAS (10VDC) Module I/O Assignments
Press ENTER to Review or Adjust**

Used With: Units w/GBAS(10VDC) Installed

- Press the **Next** key to skip this Submenu.

**GBAS (10VDC) Analog Input 1 Assignment
NOT ASSIGNED**

Note: *There are 3 additional screens associated with Input Assignments; "Analog Input 2", "Analog Input 3", and "Analog Input 4". Press the Next key to proceed through the remaining assignments.*

- Press **Next/Previous** keys to navigate.

The following screen will display if "Indicate selected diag alarms" is assigned.

**GBAS (10VDC) Binary Alarm Assignments
Press ENTER to Review or Adjust**

- Press the **Next** key to skip this Submenu.

If **Enter** was pressed, proceed to the following 3 screens.

**Assign Diagnostic To Alarm Output
Any Active Diagnostic (Yes)**

Note: *If "Yes" is selected at this screen, any active diagnostic will activate this output. A selection of "No" will allow the user to choose, from the following menus, which diagnostics activate the Alarm Output.*

If **No** was entered, proceed to the following 2 screens.

**Assignment Submenu - RTM Alarms
Press ENTER To Review Or Adjust**

Pressing the **Next** key will allow the user to skip this submenu.

Pressing the **Enter** key will allow the user to select any of the diagnostics associated with the RTM module to activate the associated Alarm Output.

Note: *The user will be presented with similar Assignment Submenus for the following alarm sources: "SCM/MCM Alarms", "HEAT Alarms", "ECEM Alarms", "VOM Alarms", "VCM Alarms", "GBAS Alarms", "MDM Alarms", "MPM Alarms" and "BAS/Network Alarms".*

If **Enter** was pressed, proceed to the following screen.

Used With: Units w/GBAS(10VDC)
Installed

Factory Presets: NOT ASSIGNED

Possible Values:

[See "**Possible Values**" in GBAS(5VDC) Above]

Used With: Units w/GBAS(10VDC)
Installed

Used With: Units w/GBAS(10VDC)
Installed

Factory Presets: Yes

Possible Values: Yes, No

Used With: Units w/GBAS(10VDC)
Installed and Any Active Diagnostic Set to "No"

Note: *Please review the "Diagnostics Troubleshooting Chart" in the "DIAGNOSTICS Menu" section to see the list of diagnostics associated with each module. (Refer to the "Diagnostics Displayed" column for the specified module.)*



SETUP Menu

**Assign Diagnostic to Alarm Output 1?
RTM Zone Temp Sensor Failure (Yes)**

Used With: Units w/GBAS(10VDC)

Selecting "Yes" for each of the diagnostics displayed will activate the associated Alarm Output when that diagnostic is activated.

Note: The list of diagnostics displayed here will be dependent upon the module assignments selected. See the "Diagnostics Table" in the diagnostics menu section for the complete list displayed for each module.

- Press **Next/Previous** keys to navigate.

End of Submenu (NEXT) to Enter GBAS

- Press **Next/Previous** keys to navigate.

**GBAS (0-10 VDC) Analog Output 1 Assignment
NOT ASSIGNED**

Used With: Units w/GBAS(10VDC)
Installed

Factory Presets: NOT ASSIGNED

Possible Values:

Note: There are 3 additional screens associated with Output Assignments; "Analog Output 2", "Analog Output 3", and "Analog Output 4". Press the Next key to proceed through the remaining assignments.

NOT ASSIGNED
ACTIVE COOLING CAPACITY
ACTIVE HEATING CAPACITY
OUTSIDE AIR TEMPERATURE
ACTIVE ZONE TEMPERATURE
ACTIVE SUPPLY AIR TEMPERATURE
ACTIVE SUPPLY AIR PRESSURE
ACTIVE SPACE PRESSURE
ACTIVE SPACE RELATIVE HUMIDITY
ACTIVE OUTDOOR AIR HUMIDITY
ACTIVE SPACE CO₂ LEVEL
ACTIVE OA DAMPER POSITION
ACTIVE OUTDOOR AIR FLOW

- Press **Next/Previous** keys to navigate.

End of Submenu (NEXT) to enter SETUP

- Press **Next/Previous** keys to navigate.

RTM ALARM OUTPUT DIAGNOSTIC ASSIGNMENTS SCREENS

RTM Alarm Output Setup Submenu
Press ENTER to Review or Adjust

Used With: All Units

- Press the **Next** key to skip this Submenu.

If **Enter** was pressed, proceed to the following 3 screens.

Assign Diagnostic to Alarm Output?
Any Active Diagnostic (Yes)

Used With: All Units

Possible Values: Yes, No

Note: If "Yes" is selected at this screen, any active diagnostic will activate this output. A selection of "No" will allow the user to choose, from the following menus, which diagnostics activate the Alarm Output.

If **No** was entered, proceed to the following 2 screens.

Assignment Submenu - RTM Alarms
Press ENTER to Review or Adjust

Used With: All Units and Any Active Diagnostic Set to "No"

Pressing the **Next** key will allow the user to skip this submenu.

Pressing the **Enter** key will allow the user to select any of the diagnostics associated with the RTM module to activate the associated Alarm Output.

Note: The user will be presented with similar Assignment Submenus for the following alarm sources: "SCM/MCM Alarms", "HEAT Alarms", "ECM Alarms", "VOM Alarms", "VCM Alarms", "GBAS Alarms", "MDM Alarms", "MPM Alarms" and "BAS/Network Alarms".

Note: Please review the "Diagnostics Troubleshooting Chart" in the "DIAGNOSTICS Menu" section to see the list of diagnostics associated with each module. (Refer to the "Diagnostics Displayed" column for the specified module.)

If **Enter** was pressed, proceed to the following screen.

Assign Diagnostic to Alarm Output?
RTM Zone Temp Sensor Failure (Yes)

Used With: All Units and the ENTER Key Was Pressed At The Prior Screen

Selecting "Yes" for each of the diagnostics displayed will activate the associated Alarm Output when that diagnostic is activated.

Note: The list of diagnostics displayed here will be dependent upon the Assignment Submenu selected. See the "Diagnostics Troubleshooting Table" in the diagnostics menu section for the list of diagnostics displayed for each module.

- Press **Next/Previous** keys to navigate.

End of Submenu (NEXT) to Enter SETUP

- Press the **Next** key to navigate forward.



SETUP Menu

Temperature Input Calibration Screens

The following five (5) Offset screens are used only if calibration of a sensor designated to perform the listed function is necessary.

Example: If the temperature sensor for Morning Warm Up (MWU) is checked and a difference between the actual measured room temperature and the corresponding measured sensor value is found, by programming the amount of error into the Temperature Input Offset for Morning Warm Up (MWU) Heat — The sensor can be calibrated.

CALIBRATION AND OFFSET SUBMENU SCREENS

<p>Calibration and Offset Submenu Press ENTER to Review or Adjust</p>	<p>Used With: All Units</p>
<p>• Press the Next key to skip this Submenu.</p>	
<p>Temperature Calibration Offset For RTM Zone Temperature Input 0.0°F</p>	<p>Used With: All Units Factory Presets: 0.0°F Possible Values: -5.0 to 5.0°F</p>
<p>• Press Next/Previous keys to navigate.</p>	
<p>Temperature Calibration Offset For RTM Aux Temperature Input 0.0°F</p>	<p>Used With: All Units Factory Presets: 0.0°F Possible Values: -5.0 to 5.0°F</p>
<p>• Press Next/Previous keys to navigate.</p>	
<p>Temperature Calibration Offset For RTM Outside Air Temperature Input 0.0°F</p>	<p>Used With: All Units Factory Presets: 0.0°F Possible Values: -5.0 to 5.0°F</p>
<p>• Press Next/Previous keys to navigate.</p>	
<p>Temperature Calibration Offset For Heat Module Aux Temp Input 0.0°F</p>	<p>Used With: Units w/Heat or Chilled Water Installed Factory Presets: 0.0°F Possible Values: -5.0 to 5.0°F</p>
<p>• Press Next/Previous keys to navigate.</p>	
<p>Temperature Calibration Offset For ECEM Return Air Temperature Input 0.0°F</p>	<p>Used With: Units w/Comparative Enthalpy Installed Factory Presets: 0.0°F Possible Values: -5.0 to 5.0°F</p>
<p>• Press Next/Previous keys to navigate.</p>	
<p>End of Submenu (NEXT) to Enter SETUP</p>	
<p>• Press Next/Previous keys to navigate.</p>	

DEVICE CHARACTERISTICS SETUP DEFINITIONS SCREENS

Device Characteristic Setup Definitions
Press ENTER to review or Adjust

Used With: All Units

- Press **Next/Previous** keys to navigate.

Actuator Setup	OA Damper
Max Stroke Time	30 Sec

Used With: Units w/OA Damper

Factory Presets: 30 Sec

Possible Values: 1 to 255 Sec

- Press **Next/Previous** keys to navigate.

Actuator Setup	OA Damper
Min Voltage	2.0 VDC

Used With: Units w/OA Damper

Factory Presets: 2.0 VDC

Possible Values: 0 to 10.0 VDC

- Press **Next/Previous** keys to navigate.

Actuator Setup	OA Damper
Max Voltage	10.0 VDC

Used With: Units w/OA Damper

Factory Presets: 10.0 VDC

Possible Values: 0 to 10.0 VDC

- Press **Next/Previous** keys to navigate.

Actuator Setup	OA Damper
Direct/Reverse Act	DIRECT ACTING

Used With: Units w/OA Damper

Factory Presets: DIRECT ACTING

Possible Values: DIRECT ACTING, REVERSE ACTING

- Press **Next/Previous** keys to navigate.

Actuator Setup	Supply Fan IGV/VFD	
Max Stroke Time	30 Sec	

Used With: VVDC Units

Factory Preset: 30 Sec

Possible Values: 1 to 255 Sec

- Press **Next/Previous** keys to navigate.

Actuator Setup	Supply Fan IGV/VFD Cmd	
Min Voltage	0.0 VDC	

Used With: VVDC Units

Factory Presets: 0 VDC

Possible Values: 0 to 10.0 VDC

Note: If the unit is configured for a Supply Fan VFD, initial setting should be 0.0 VDC. If the unit is configured with IGV set this value to 2.0 VDC.

- Press **Next/Previous** keys to navigate.



SETUP Menu

Actuator Setup	Supply Fan IGV/VFD Cmd
Max Voltage	10.0 VDC

- Press **Next/Previous** keys to navigate.

Used With: VVDC Units
Factory Presets: 10.0 VDC
Possible Values: 0 to 10.0 VDC

Actuator Setup	Supply Fan IGV/VFD Cmd
Direct/Reverse Act	DIRECT ACTING

- Press **Next/Previous** keys to navigate.

Used With: VVDC Units
Factory Presets: DIRECT ACTING
Possible Values: DIRECT ACTING, REVERSE ACTING

Actuator Setup	Return Fan VFD
Max Stroke Time	30 Sec

- Press **Next/Previous** keys to navigate.

Used With: Units w/Return Fan Option
Factory Presets: 30 Sec
Possible Values: 1 to 255 Sec

Actuator Setup	Return Fan VFD
Min Voltage	0.0 VDC

- Press **Next/Previous** keys to navigate.

Used With: Units w/Return Fan Option
Factory Presets: 0 VDC
Possible Values: 0 to 10.0 VDC

Actuator Setup	Return Fan VFD
Max Voltage	10.0 VDC

- Press **Next/Previous** keys to navigate.

Used With: Units w/Return Fan Option
Factory Presets: 10.0 VDC
Possible Values: 0 to 10.0 VDC

Actuator Setup	Return Fan VFD
Direct/Reverse Act	DIRECT ACTING

- Press **Next/Previous** keys to navigate.

Used With: Units w/Return Fan Option
Factory Presets: Direct Acting
Possible Values: Direct, Reverse

Actuator Setup	Exhaust Damper/VFD
Max Stroke Time	60 Sec

- Press **Next/Previous** keys to navigate.

Used With: Units w/Power Exhaust
Factory Presets: 60 Sec
Possible Values: 1 to 255 Sec

Actuator Setup	Exhaust Damper/VFD
Min Voltage	2.0 VDC

Note: If the unit is configured for a Exhaust Fan VFD, initial setting should be 0.0 VDC. If the unit is configured w/o VFD set this value to 2.0 VDC.

- Press **Next/Previous** keys to navigate.

Used With: Units w/Power Exhaust
Factory Presets: 2.0 VDC
Possible Values: 0 to 10.0 VDC

Actuator Setup	Exhaust Damper/VFD
Max Voltage	10.0 VDC

- Press **Next/Previous** keys to navigate.

Used With: Units w/Power Exhaust
Factory Presets: 10.0 VDC
Possible Values: 0 to 10.0 VDC

Actuator Setup	Exhaust Damper/VFD
Direct/Reverse Act	DIRECT ACTING

- Press **Next/Previous** keys to navigate.

Used With: Units w/Power Exhaust
Factory Presets: DIRECT ACTING
Possible Values: DIRECT ACTING, REVERSE ACTING

Actuator Setup	Hydronic
Max Stroke Time	60 Sec

- Press **Next/Previous** keys to navigate.

Used With: Units w/Hydronic Heat and/or Chilled Water Installed
Factory Presets: 60 Sec
Possible Values: 1 to 255 Sec

Actuator Setup	Hydronic
Min Voltage	2.0 VDC

- Press **Next/Previous** keys to navigate.

Used With: Units w/Hydronic Heat and/or Chilled Water Installed
Factory Presets: 2.0 VDC
Possible Values: 0 to 10.0 VDC

Actuator Setup	Hydronic
Max Voltage	10.0 VDC

- Press **Next/Previous** keys to navigate.

Used With: Units w/Hydronic Heat and/or Chilled Water Installed
Factory Presets: 0 VDC
Possible Values: 0 to 10.0 VDC

Actuator Setup	Hydronic
Direct/Reverse Act	DIRECT ACTING

- Press **Next/Previous** keys to navigate.

Used With: Units w/Hydronic Heat and/or Chilled Water Installed
Factory Presets: DIRECT ACTING
Possible Values: DIRECT ACTING, REVERSE ACTING

Note: Only one of the following two screens will be shown

Actuator Setup	Num 1 Low Ambient
Max Stroke Time	60 Sec

Used With: Units w/DX Cooling, w/Air-Cooled Condensers
Factory Presets: 60 Sec
Possible Values: 1 to 255 Sec

OR

Actuator Setup	Cond Fan VFD Ckt 1
Max Stroke Time	60 Sec

Used With: Units w/DX Cooling, w/Water-Cooled Condensers
Factory Preset: 60 Sec
Possible Values: 1 to 255 Sec

- Press the **Next** key to navigate forward.



SETUP Menu

Note: Only one of the following two screens will be shown based on condenser type.

Actuator Setup	Num 1 Low Ambient
Min Voltage	2.0 VDC

Used With: Units w/DX Cooling, w/Air-Cooled Condensers

Factory Presets: 2.0 VDC

Possible Values: 0 to 10.0 VDC

OR

Actuator Setup	Cond Fan VFD Ckt 1
Min Voltage	0.0 VDC

Used With: Units w/DX Cooling, w/Water-Cooled Condensers

Factory Preset: 0 VDC

Possible Values: 0 to 10.0 VDC

- Press **Next/Previous** keys to navigate.

Note: Only one of the following two screens will be shown based on condenser type.

Actuator Setup	Num 1 Low Ambient
Max Voltage	10.0 VDC

Used With: Units w/DX Cooling, w/Air-Cooled Condensers

Factory Presets: 10.0 VDC

Possible Values: 0 to 10.0 VDC

OR

Actuator Setup	Cond Fan VFD Ckt 1
Max Voltage	10.0 VDC

Used With: Units w/DX Cooling, w/Water-Cooled Condensers

Factory Preset: 10.0 VDC

Possible Values: 0 to 10.0 VDC

- Press **Next/Previous** keys to navigate.

Note: Only one of the following two screens will be shown based on condenser type.

Actuator Setup	Num 1 Low Ambient
Direct/Reverse Act	DIRECT ACTING

Used With: Units w/DX Cooling, w/Air-Cooled Condensers

Factory Presets: Direct Acting

Possible Values: Direct Acting, Reverse Acting

OR

Actuator Setup	Cond Fan VFD Ckt 1
Direct/Reverse Act	DIRECT ACTING

Used With: Units w/DX Cooling, w/Water-Cooled Condensers

Factory Preset: DIRECT

Possible Values: DIRECT, REVERSE

- Press **Next/Previous** keys to navigate.

Note: Only one of the following two screens will be shown based on condenser type.

Actuator Setup	Num 2 Low Ambient
Max Stroke Time	60 Sec

Used With: Units w/DX Cooling, w/Air-Cooled Condensers
Factory Presets: 60 Sec
Possible Values: 1 to 255 Sec

OR

Actuator Setup	Cond Fan VFD Ckt 2
Max Stroke Time	60 Sec

Used With: Units w/DX Cooling, w/Water-Cooled Condensers
Factory Preset: 60 Sec
Possible Values: 1 to 255 Sec

- Press **Next/Previous** keys to navigate.

Note: Only one of the following two screens will be shown based on condenser type.

Actuator Setup	Num 2 Low Ambient
Min Voltage	2.0 VDC

Used With: Units w/DX Cooling, w/Air-Cooled Condensers
Factory Presets: 2.0 VDC
Possible Values: 0 to 10.0 VDC

OR

Actuator Setup	Cond Fan VFD Ckt 2
Min Voltage	0.0 VDC

Used With: Units w/DX Cooling, w/Water-Cooled Condensers
Factory Preset: 0 VDC
Possible Values: 0 to 10.0 VDC

- Press **Next/Previous** keys to navigate.

Note: Only one of the following two screens will be shown based on condenser type.

Actuator Setup	Num 2 Low Ambient
Max Voltage	10.0 VDC

Used With: Units w/DX Cooling, w/Air-Cooled Condensers
Factory Presets: 10.0 VDC
Possible Values: 0 to 10.0 VDC

OR

Actuator Setup	Cond Fan VFD Ckt 2
Max Voltage	10.0 VDC

Used With: Units w/DX Cooling, w/Water-Cooled Condensers
Factory Preset: 10.0 VDC
Possible Values: 0 to 10.0 VDC

- Press **Next/Previous** keys to navigate.

Note: Only one of the following two screens will be shown based on condenser type.

Actuator Setup	Num 2 Low Ambient
Direct/Reverse Act	DIRECT ACTING

Used With: Units w/DX Cooling, w/Air-Cooled Condensers
Factory Presets: Direct Acting
Possible Values: Direct Acting, Reverse Acting



SETUP Menu

OR

Actuator Setup	Cond Fan VFD Ckt 2
Direct/Reverse Act	DIRECT ACTING

- Press **Next/Previous** keys to navigate.

Used With: Units w/DX Cooling, w/ Water-Cooled Condensers
Factory Preset: DIRECT
Possible Values: DIRECT, REVERSE

Actuator Setup	Modulating Gas Heat
Max Stroke Time	90 Sec

- Press **Next/Previous** keys to navigate.

Used With: All Rooftop Units and Air Handlers when Modulating Gas is installed
Factory Presets: 90 Sec
Possible Values: 1 to 255 Sec

Actuator Setup	Modulating Gas Heat
Min Voltage	2.0 VDC

- Press **Next/Previous** keys to navigate.

Used With: All Rooftop Units and Air Handlers when Modulating Gas is installed
Factory Presets: 2 VDC
Possible Values: 0 to 10.0 VDC

Actuator Setup	Modulating Gas Heat
Max Voltage	10 VDC

- Press **Next/Previous** keys to navigate.

Used With: All Rooftop Units and Air Handlers when Modulating Gas is installed
Factory Presets: 10 VDC
Possible Values: 0 to 10.0 VDC

Actuator Setup	Modulating Gas Heat
Direct/Reverse Act	DIRECT ACTING

- Press **Next/Previous** keys to navigate.

Used With: All Rooftop Units and Air Handlers Modulating Gas is installed
Factory Presets: Direct Acting
Possible Values: Direct Acting, Reverse Acting

Actuator Setup	Exh Bypass Damper
Max Stroke Time	60 Sec

- Press **Next/Previous** keys to navigate.

Used With: All IntelliPak II units with Energy Recovery installed.
Factory Preset: 60 Sec
Possible Values: 1 to 255 Sec

Actuator Setup	Exh Bypass Damper
Min Voltage	2.0 VDC

- Press **Next/Previous** keys to navigate.

Used With: All IntelliPak II units with Energy Recovery installed.
Factory Preset: 2.0 VDC
Possible Values: 0 to 10.0 VDC

Actuator Setup	Exh Bypass Damper
Max Voltage	10.0 VDC

- Press **Next/Previous** keys to navigate.

Used With: All IntelliPak II units with Energy Recovery installed.

Factory Preset: 10.0 VDC

Possible Values: 0 to 10.0 VDC

Actuator Setup	Exh Bypass Damper
Direct/Reverse Act	DIRECT ACTING

- Press **Next/Previous** keys to navigate.

Used With: All IntelliPak II units with Energy Recovery installed.

Factory Preset: DIRECT

Possible Values: DIRECT, REVERSE

Actuator Setup	OA Bypass Damper
Max Stroke Time	60 Sec

- Press **Next/Previous** keys to navigate.

Used With: All IntelliPak II units with Energy Recovery installed.

Factory Preset: 60 Sec

Possible Values: 1 to 255 Sec

Actuator Setup	OA Bypass Damper
Min Voltage	2.0 VDC

- Press **Next/Previous** keys to navigate.

Used With: All IntelliPak II units with Energy Recovery installed.

Factory Preset: 2.0 VDC

Possible Values: 0 to 10.0 VDC

Actuator Setup	OA Bypass Damper
Max Voltage	10.0 VDC

- Press **Next/Previous** keys to navigate.

Used With: All IntelliPak II units with Energy Recovery installed.

Factory Preset: 10.0 VDC

Possible Values: 0 to 10.0 VDC

Actuator Setup	OA Bypass Damper
Direct/Reverse Act	DIRECT ACTING

- Press **Next/Previous** keys to navigate.

Used With: All IntelliPak II units with Energy Recovery installed.

Factory Preset: DIRECT

Possible Values: DIRECT, REVERSE

Actuator Setup	Variable Speed Comp
Max Stroke Time	30 Sec

- Press **Next/Previous** keys to navigate.

Used With: Units w/Variable Speed Compressor Installed.

Factory Preset: 30 Sec

Possible Values: 1 to 255 Sec

Actuator Setup	Variable Speed Comp
Min Voltage	0.0 VDC

- Press **Next/Previous** keys to navigate.

Used With: Units w/Variable Speed Compressor Installed.

Factory Preset: 0.0 VDC

Possible Values: 0 to 10.0 VDC

Actuator Setup	Variable Speed Comp
Max Voltage	10.0 VDC

- Press **Next/Previous** keys to navigate.

Used With: Units w/Variable Speed Compressor Installed.

Factory Preset: 10.0 VDC

Possible Values: 0 to 10.0 VDC



SETUP Menu

Actuator Setup Variable Speed Comp
Direct/Reverse Act DIRECT ACTING

- Press **Next/Previous** keys to navigate.

Used With: Units w/Variable Speed Compressor Installed.

Factory Preset: DIRECT ACTING

Possible Values: DIRECT ACTING, REVERSE ACTING

End of Submenu (NEXT) to Enter SETUP

- Press **Next/Previous** keys to navigate.

CONTROL ALGORITHM TUNING PARAMETERS SCREENS (Partial)

Control Algorithm Tuning Parameters
Press ENTER to Review or Adjust

Note: Contact the Trane Company before making any adjustment to these settings.

- Press **Next/Previous** keys to navigate.

SZVAV Cooling Control Gains
Proportional 6.0 %/F Reset Time 1200 Sec

Note: This screen must be changed on field replacement of the RTM Module.

- Press **Next/Previous** keys to navigate.

Used With: All IntelliPak units with SZVAV Installed.

Factory Preset:

Prop: 6.0

Reset: 1200

Possible Values:

Prop: 0.2 - 50

Reset: 90 - 3600, DISABLED

SZVAV Heating Control Gains
Proportional 8.0 %/F Reset Time 1200 Sec

Note: This screen must be changed on field replacement of the RTM Module.

- Press **Next/Previous** keys to navigate.

Used With: All IntelliPak units with SZVAV Installed.

Factory Preset:

Prop: 8.0

Reset: 1200

Possible Values:

Prop: 0.2 - 50

Reset: 90 - 3600, DISABLED

Zone Control Occupied Heating Gains
Proportional 30.0 %/F Reset Time 1800 Sec

Note: This screen must be changed on field replacement of the RTM Module.

Used With: All IntelliPak units with Staged Heat Installed.

Range: 2.0 - 200

Possible Values:

[See "Table 6. Proportional Parameter - Staged Heat" on page 85 for assignments.]

Table 6. Proportional Parameter - Staged Heat

Product	Staged Heat Type	No of Stages	Proportional Gain
IPak I	Gas	2	30.0
IPak I	Electric	3	45.0
IPak II	Gas	2	30.0
IPak II	Electric 90 kw	3	45.0
IPak II	Electric 140 kw	4	60.0
IPak II	Electric 265 kw	5	75.0
IPak II	Electric 300 kw	5	75.0

- Press Next/Previous keys to navigate.

Rapid DX Interstage Timing:	30 Sec
------------------------------------	---------------

Note: *This screen must be changed on field replacement of the RTM Module.*

- Press **Next/Previous** keys to navigate.

Used With: All IntelliPak units w/ Dehumidification or Rapid Restart.

Factory Presets: Range: 30

Possible Values: 15 - 50

End of Submenu (NEXT) to Enter SETUP

- Press **Next/Previous** keys to navigate.



SETPOINT Menu

The setpoint menu is used to designate default zone temperature setpoints, supply air and space pressure setpoints, and low ambient compressor lockout setpoints.

These setpoints will be active (in use) for the "Setpoint Source Selection" designated as "DEFAULT" for these inputs.

When a setpoint screen is displayed for 30 minutes without a key being pressed, the LCD screen will revert to the general operating status display. If this happens, press the **Setpoint** key again to return to the setpoint menu.

Note: Many of the screens displayed in this section are applicable only for the options that are installed in the unit and may not be visible on your unit.

Modifying Selections: Starting with the first setpoint screen program the necessary information by using the appropriate keys to navigate (Next and Previous) and make changes (+ and -) to the selections. Once the selection has been changed to the desired value, the user has the following options to either *Cancel* or *Accept* the pending change:

- To *Cancel*, press the **Cancel** key to remove the change, the display will revert to the original value.
- To *Accept*, press the **Enter** key to confirm the new choice.

Press the **Setpoint** key to begin viewing or modifying the unit setpoints.

TOP LEVEL SETPOINTS SCREEN

Default Supply Air Temp Setpoints	
Cooling: 55°F	Heating: 100°F

Note: These values must be reset on field replacement of the RTM Module if the unit is configured for SZVAV (VVZT).

"Heating" setpoint only shown if units are configured with hydronic or modulating gas heat, or if IpaKII w/electric heat.

- Press **Next/Previous** keys to navigate.

Used With: VV/CVDA or VVZT Units
Factory Presets: **Factory Presets:**
 Cooling: 55°F (VVZT: 50°F)
 Heating: 100°F (VVZT: 105°F)

Possible Values:
 Cool: 40 to 90°F
 Heat: 40 to 180°F

Supply Air Temperature Deadband	
Cooling: 8.0°F	Heating: 4.0°F

"Heating" setpoint only shown if units are configured with hydronic or modulating gas heat, or if IpaKII w/electric heat.

- Press **Next/Previous** keys to navigate.

Used With: VV/CVDA Units
Factory Presets:
 Cooling: 8°F
 Heating: 4°F

Possible Values:
 Cool: 1 to 20°F
 Heat: 2 to 10°F

Default Daytime Warmup Setpoints	
Initiate: 67°F	Terminate: 71°F

- Press **Next/Previous** keys to navigate.

Used With: VV/CVDA Units w/DWU Enabled
Factory Presets:
 Initiate: 67°F
 Terminate: 71°F

Possible Values:
 DWU Initiate: 50 to 87°F
 DWU Terminate: 53 to 90°F

Default Occupied Zone Temp Setpoints

Cool: 74°F Heat: 71°F

"Cool" setpoint shown for CVZT units. "Heat" setpoint shown for CVZT w/heat installed, or VV/CVDA units with DWU or MWU enabled.

- Press **Next/Previous** keys to navigate.

Used With: CVZT or VVZT Units, or VV/CVDA Units w/DWU or MWU Enabled

Factory Presets:

Cool: 74°F

Heat: 71°F

Possible Values:

Heat: 50 to 90°F

Derived Zone Setpoint Deadband: 2.0°F
Used When Only One Setpoint is Available

- Press **Next/Previous** keys to navigate.

Used With: CVZT or VVZT Units w/Zone Sensor Supporting Only One Setpoint

Factory Preset: 4.0°F**Possible Values:** 2.0 to 10.0°F**Default Unoccupied Zone Temp Setpoints**
Cool: 85°F Heat: 60°F Morn Warmup: 72°F

Note: Minimum difference of 2°F maintained between Heating & Cooling Setpoints. Morning warmup cannot be lower than Heating Setpoints.

"Heat" and "Morn Warmup" shown for units w/heat installed.
"Morn Warmup" shown if MWU is enabled.

- Press **Next/Previous** keys to navigate.

Used With: All Units

Factory Presets:

Cool: 85°F

Heat: 60°F

MWU: 72°F

Possible Values:

Cool: 52 to 90°F

Heat: 50 to 88°F

MWU: 50 to 90°F

Dflt Rapid Restart Critical Temp: 90°F

Return temperature relative to this setpoint determines target DX stage during a Rapid Restart event.

- Press **Next/Previous** keys to navigate.

Used With: All IntelliPak Units w/Rapid Restart Installed

Factory Preset: 90°F**Possible Values:** 75, 80, 85, 90, 95 °F**HUMIDITY CONTROL SETPOINT SUBMENU SCREENS****Humidity Control Setpoint Submenu**
Press ENTER to Review or Adjust

- Press the **Next** key to skip this Submenu.

Used With: Units w/Dehumidification or Humidification Option

Dehumidify if Space Humidity Above
Occ Dehumidification Setpoint: 60%

- Press **Next/Previous** keys to navigate.

Used With: Units w/Dehumidification Option

Factory Preset: 60 %**Possible Values:** 40 to 65 %



SETPOINT Menu

Stop Dehumid if Space RH Below STP Minus
Occ Dehumid Hysteresis Offset: 5%

- Press **Next/Previous** keys to navigate.

Used With: Units w/Dehumidification Option
Factory Preset: 5 %
Possible Values: 3 to 10 %

Dehumidify if Space Humidity Above
Unocc Dehumidification Setpoint: 60%

- Press **Next/Previous** keys to navigate.

Used With: Units w/Dehumidification Option and Unocc Dehumid. Enabled
Factory Preset: 60 %
Possible Values: 40 to 65 %

Stop Dehumid if Space RH Below STP Minus
Unocc Dehumid Hysteresis Offset: 5%

- Press **Next/Previous** keys to navigate.

Used With: Units w/Dehumidification Option and Unocc Dehumid. Enabled
Factory Preset: 5 %
Possible Values: 3 to 10 %

Default Supply Air Reheat Stpt: 70°F
Supply Air Reheat Deadband: 4°F

- Press **Next/Previous** keys to navigate.

Used With: Units w/Dehumidification Option
Factory Preset:
Reheat Setpoint: 70°F
Reheat Deadband: 4°F
Possible Values:
Reheat Setpoint: 60 to 80°F
Reheat Deadband: 2 to 10°F

In Active Dehumidification Mode, Limit
Maximum Reheat Valve Position To: 85%

- Press **Next/Previous** keys to navigate.

Used With: Units w/Dehumidification Option
Factory Preset: 85 %
Possible Values: 50 to 85 %

Dehumid Ovr High Zone Temp Stpt: 75°F
Dehumid Ovr Low Zone Temp Stpt: 68°F

- Press **Next/Previous** keys to navigate.

Used With: VV/CVDA Units w/Dehumidification Option
Factory Preset:
Ovr High Temp: 75°F
Ovr Low Temp: 68°F
Possible Values:
Ovr High Temp: 70 to 85°F
Ovr Low Temp: 60 to 75°F

Cond Coil Purge Interval Setpt: 90 Min

- Press **Next/Previous** keys to navigate.

Used With: Units w/Dehumidification Option
Factory Preset: 90 Minutes
Possible Values: 60 to 120 Minutes

Humidify if Space Humidity Below
Occ Humidification Setpoint: 30%

- Press **Next/Previous** keys to navigate.

Used With: Units w/Humidification Option

Factory Preset: 30 %

Possible Values: 20 to 50 %

Stop Humid if Space RH Above STP Plus
Occ Humid Hysteresis Offset: 5%

- Press **Next/Previous** keys to navigate.

Used With: Units w/Humidification Option

Factory Preset: 5 %

Possible Values: 3 to 10 %

Humidify if Space Humidity Below
Unocc Humidification SETPOINT: 30%

- Press **Next/Previous** keys to navigate.

Used With: Units w/Humidification Option and Unocc. Humid. Enabled

Factory Preset: 30 %

Possible Values: 20 to 50 %

Stop Humid if Space RH Above STP Plus
Unocc Humid Hysteresis Offset: 5%

- Press **Next/Previous** keys to navigate.

Used With: Units w/Humidification Option and Unocc. Humid. Enabled

Factory Preset: 5 %

Possible Values: 3 to 10 %

End Of Submenu (NEXT) to Enter SETPOINT

- Press **Next/Previous** keys to navigate.

OUTSIDE AIR CONTROL SETPOINT SUBMENU SCREENS

Outside Air Control Setpoint Submenu
Press ENTER to Review or Adjust

- Press the **Next** key to skip this Submenu.

Used With: Units w/Fresh Air Option

When Economizer Cooling, Reduce Zone
Temperature Cooling Setpoint By: 1.5°F

- Press **Next/Previous** keys to navigate.

Used With: CVZT Units w/Economizer Option

Factory Preset: 1.5°F

Possible Values: 0.0 to 3.0°F



SETPOINT Menu

Reference Enthalpy. Enable Air Econ
When OA Enthalpy is Below: 25 BTU/LB

Note: This Setpoint is used when Comparative Enthalpy is not installed or is invalid due to return air humidity or temperature is out of range or failed.

- Press **Next/Previous** keys to navigate.

Default Econ Drybulb Enable Setpoint
Enable Economizer Below: 75°F

Note: This setpoint is used when Comparative Enthalpy is not installed, or is invalid, and Drybulb is selected for alternate economizer enable/disable decision.

- Press **Next/Previous** keys to navigate.

Supply Air Low Limit-Modulate Economizer
Toward Min Pos if SA Temp below: 50°F

- Press **Next/Previous** keys to navigate.

VCM Preheat ON If VCM Aux Temp Below
Ventilation Preheat Setpoint: 35°F

- Press **Next/Previous** keys to navigate.

Default Design Min CO₂ Setpt: 1000 PPM
Default DCV Min CO₂ Setpoint: 400 PPM

- Press **Next/Previous** keys to navigate.

Note: The following 2 screens are only shown if DCV is enabled.

Used With: Units w/Economizer
Factory Presets: 25 BTU/LB
Possible Values: 19 to 28 BTU/LB

Used With: Units w/Economizer
Factory Presets: 75°F
Possible Values: 50 to 140°F

Used With: CVZT Units, or non-VVZT Units Operating in Unoccupied Economizer Cooling Mode
Factory Presets: 50°F
Possible Values: 40 to 65°F

Used With: Units w/Fresh Air Measurement (VCM) w/DCV, or OA Damper Min Position w/DCV, and Preheat Enabled
Factory Presets: 35°F
Possible Values: 35 to 75°F

Used With: Units w/Fresh Air Measurement (VCM) w/DCV, or OA Damper Min Position w/DCV
Factory Presets:
Design Min CO₂: 1000 PPM
DCV Min CO₂: 400 PPM
Possible Values:
Design Min CO₂: 150 to 2000 PPM
DCV Min CO₂: 50-1900 PPM

Default Design Min OA Flow Stp: 350 CCFM
 Default DCV Min OA Flow Setpt: 150 CCFM

Used With: Units w/Fresh Air Measurement (VCM) w/DCV
Factory Preset: 220 CCFM
 Ovr to 112 CCFM for 90 and 105 Ton
 Ovr to 146 CCFM for 120 and 130 Ton
Possible Values:
 Design Min OA Flow: 0 to 585 CCFM
 DCV Min OA Flow: 0 to 585 CCFM

- Press **Next/Previous** keys to navigate.

Demand Controlled Ventilation
 Min OA Flow deadband: 5 CCFM

Used With: Units w/Fresh Air Measurement (VCM) w/DCV
Factory Presets: 5 CCFM
Possible Values: 5 to 20 CCFM

- Press **Next/Previous** keys to navigate.

OR

Note: The following screen is only shown if DCV is disabled.

Default Min OA Flow Setpoint: 40 CCFM
 Min OA Flow Deadband: 5.0 CCFM

Used With: Units w/Fresh Air Measurement (VCM) w/o DCV
Factory Presets:
 Setpoint: 40 CCFM
 Deadband: 5 CCFM
Possible Values:
 [See "Table 7. Max Unit Airflows" for assignments.]

Table 7. Max Unit Airflows

Product	Capacity (Tons)	Max Airflow Range (CFM)	Deadband Range (CFM)
IPak	20 to 25	0 to 14000	500 to 2000
IPak	30	0 to 17000	500 to 2000
IPak	40	0 to 22000	500 to 2000
IPak	50 to 55	0 to 28000	500 to 2000
IPak	60 to 75	0 to 33000	700 to 2000
IPak	90 to 130	0 to 46000	1000 to 2000
IPak II	90 to 105	0 to 45000	500 to 2000
IPak II	120 to 150	0 to 58500	500 to 2000

- Press **Next/Previous** keys to navigate.



SETPOINT Menu

Default Design Min OA Damper Pos:	15%
Default DCV Min OA Damper Pos Stp:	10%

- Press **Next/Previous** keys to navigate.

Used With: Units w/OA Damper, And OA Damper Min Pos w/DCV Option, and OA CFM Compensation Disabled.

Factory Presets:

Design Min OA Damper: 15 %
DCV Min OA Damper: 10 %

Possible Values: 0 to 100 %

Default OA Damper Min Position: With IGV/VFD Command At Minimum (0%)	15%
---	-----

Note: OA Damper Min Pos...At Minimum (0%) must be > OA Damper Min Pos...At Maximum (100%) if VVDA, or at Medium (50%) if VVZT.

- Press **Next/Previous** keys to navigate.

Used With: VVDA or VVZT Units w/OA Damper, And OA CFM Compensation Enabled

Factory Presets:

VVDA: 15 %
VVZT: 25 %

Possible Values: 0 to 100 %

Default OA Damper Min Position: With IGV/VFD Command At Medium (50%)	20%
---	-----

Note: OA Damper Min Pos...At Minimum (50%) must be > OA Damper Min Pos...At Maximum (100%) and must be < OA Damper Min Pos...At Minimum (0%).

- Press **Next/Previous** keys to navigate.

Used With: VVZT Units w/OA Damper, And OA CFM Compensation Enabled

Factory Presets: 20%

Possible Values: 0 to 100 %

Default OA Damper Min Position: With IGV/VFD Command At Maximum (100%)	10%
---	-----

Note: OA Damper Min Pos...At Minimum (100%) must be < OA Damper Min Pos...At Maximum (100%) if VVDA, or At Medium (50%) if VVZT.

- Press **Next/Previous** keys to navigate.

Used With: VVDA or VVZT Units w/OA Damper, And OA CFM Compensation Enabled

Factory Presets:

VVDA: 10 %
VVZT: 5 %

Possible Values: 0 to 100 %

OR

Default OA Damper Min Position:	15%
---------------------------------	-----

Note: If unit has TRAQ, this setpoint is only used in case of flow station failure.

- Press **Next/Previous** keys to navigate.

Used With: Units w/OA Damper Option, DCV Disabled, OACFM Compensation Disabled

Factory Presets: 15 %

Possible Values: 0 to 100 %

End Of Submenu (NEXT) To Enter SETPOINT

- Press **Next/Previous** keys to navigate.

Used With: All units

Default Supply Air Pressure:	2.0 IWC
High Limit: 4.0 IWC	Deadband: 0.5 IWC

"Default Supply Air Pressure" and "Deadband" shown for VVDA.
"High Limit" shown for all VVDA, VVZT and CVDA units if present.

Note: "Default Supply Air Pressure" will not adjust higher than:
(High Limit - 0.1 - 1/2 Deadband).

- Press **Next/Previous** keys to navigate.

Max Return Plenum Pressure Stp:	0.8 IWC
	Deadband: 0.2 IWC

- Press **Next/Previous** keys to navigate.

Default Space Pressure Setpoint:	0.08 IWC
Space Pressure Deadband:	0.10 IWC

OR

Default Space Pressure Setpt:	0.08 IWC
Deadband: 0.10 IWC	Low Limit: -0.02 IWC

- Press **Next/Previous** keys to navigate.

Used With: VV/CVDA or VVZT Units

Factory Presets:

Setpoint: 2.0 IWC
High Limit: 4.0 IWC
Deadband: 0.5 IWC

Possible Values: (IPak II)

Setpoint: 0.7 to 5.1 IWC
High Limit: 1.2 to 5.7 IWC
Deadband: 0.1 to 2.0 IWC

Possible Values: (IPak-I)

Setpoint: 0.7 to 4.3 IWC
High Limit: 1.2 to 4.7 IWC
Deadband: 0.1 to 2.0 IWC

Used With: Units w/Return Fan VFD
Installed (Statitrac)

Factory Presets:

Setpoint: 0.8 IWC
Deadband: 0.2 IWC

Possible Values:

Setpoint: 0.1 to 2.5 IWC
Deadband: 0.1 to 1.0 IWC

Used With: Units w/Statitrac Installed,
w/o Return Fan Option

Factory Presets:

Setpoint: 0.08 IWC
Deadband: 0.04 IWC

Possible Values:

Setpoint: -0.2 to 0.3 IWC
Deadband: 0.02 to 0.2 IWC

Used With: Units w/Statitrac Installed,
w/Return Fan Option

Factory Presets:

Setpoint: 0.08 IWC
Deadband: 0.04 IWC
Low Limit: -0.05 IWC

Possible Values:

Setpoint: -0.2 to 0.3 IWC
Deadband: 0.02 to 0.2 IWC
Low Limit: -0.4 to 0.2 IWC



SETPOINT Menu

**Exhaust Enable Point. Enable Exhaust Fan
When Outside Air damper is Above: 25%**

- Press **Next/Previous** keys to navigate.

Used With: Units w/Power Exhaust Option

Factory Presets: 25 %

Possible Values: 0 to 100 %

**Exhaust Disabled When OA Damper is Below
Exhaust Inhibit Point: 15%**

“Exhaust Disabled When OA Damper is Below” is shown when set to anything other than DISABLED. If set to DISABLED, “Exhaust Function Not Disabled By” is shown on top line.

- Press **Next/Previous** keys to navigate.

Used With: Units w/Power Exhaust, w/Return Fan Option

Factory Presets: DISABLED

Possible Values: 0 to 25 %, DISABLED

**Low Ambient Comp Lockout Temp: 50°F
Comp(s) OFF if OA Temp Below This Value**

- Press **Next/Previous** keys to navigate.

Used With: Units w/DX Cooling

Factory Presets: 50°F

Possible Values: -20 to 80°F

**For Standby Freeze Avoidance, Open the
Hydronic Heat Valve(s) To: 0%**

Note: When the supply fan is OFF, and the active outside air temperature drops below 45F, the hydronic valve output will be driven to the value specified here.

- Press **Next/Previous** keys to navigate.

Used With: Units w/Hydronic Heat

Factory Preset: Disabled

Possible Values: Disabled, 1 to 100 %

**Frost Avoidance ON When LRE Temp Below
Recovery Frost Avoidance Setpoint: 27°F**

- Press **Next/Previous** keys to navigate.

Used With: Units w/Energy Recovery Option

Factory Preset: 27°F

Possible Values: 0 to 60°F

SETPOINT SOURCE SELECTIONS SUBMENU SCREENS

**Setpoint Source Selections Submenu
Press ENTER to Review or Adjust**

Note: For GBAS selections to be shown, either the GBAS(5VDC) or GBAS(10VDC) module must be installed.

- Press the **Next** key to skip this Submenu.

Used With: All Units

Factory Presets: For All Setpoint Source Selections the Factory Presets will be:

HI (KEYPAD) SETPOINT MENU

**For Supply Air Temp Cooling Control, Use
Setpoint From: HI (KEYPAD) SETPOINT MENU**

- Press **Next/Previous** keys to navigate.

Used With: VV/CVDA or VVZT Units

Possible Values:

HI (KEYPAD) SETPOINT MENU
ZONE SENSOR SETPOINT INPUT
NSB PANEL SETPOINT INPUT
GBAS (5VDC) MODULE
GBAS (10VDC) MODULE

**For Supply Air Temp Heating Control, Use
Setpoint From: HI (KEYPAD) SETPOINT MENU**

- Press **Next/Previous** keys to navigate.

Used With: VV/CVDA or VVZT Units w/
Hydronic or Modulating Gas Heat, or
IpakII w/Electric Heat

Possible Values:

HI (KEYPAD) SETPOINT MENU
NSB PANEL SETPOINT INPUT
GBAS(5VDC) Module
GBAS(10VDC) Module

**For Occ Zone Temp Cooling Control, Use
Setpoint From: HI (KEYPAD) SETPOINT MENU**

- Press **Next/Previous** keys to navigate.

Used With: CVZT Units or VVZT w/
Cooling

Possible Values:

HI (KEYPAD) SETPOINT MENU
ZONE SENSOR SETPOINT INPUT
NSB PANEL SETPOINT INPUT
GBAS (5VDC) MODULE
GBAS (10VDC) MODULE

**For Occ Zone Temp Heating Control, Use
Setpoint From: HI (KEYPAD) SETPOINT MENU**

- Press **Next/Previous** keys to navigate.

Used With: CVZT or VVZT Units w/Heat,
And VV/CVDA Units w/Heat and DWU
Enabled

Possible Values:

[Same as "**Possible Values**" Above]

**For Unocc Zone Temp Cooling Control, Use
Setpoint From: HI (KEYPAD) SETPOINT MENU**

- Press **Next/Previous** keys to navigate.

Used With: Units w/Cooling

Possible Values:

[Same as "**Possible Values**" Above]

**For Unocc Zone Temp Heating Control, Use
Setpoint From: HI (KEYPAD) SETPOINT MENU**

- Press **Next/Previous** keys to navigate.

Used With: Units w/Heat Installed

Possible Values:

[Same as "**Possible Values**" Above]



SETPOINT Menu

For Morning Warmup Temp Control, Use
Setpoint From: HI (KEYPAD) SETPOINT MENU

- Press **Next/Previous** keys to navigate.

Used With: Units w/Heat Installed

Possible Values:

HI (KEYPAD) SETPOINT MENU
NSB PANEL SETPOINT INPUT
GBAS (5VDC) MODULE
GBAS (10VDC) MODULE

For Economizer Dry Bulb Enable, Use
Setpoint From: HI (KEYPAD) SETPOINT Menu

- Press **Next/Previous** keys to navigate.

Used With: Units w/Economizer Option

Possible Values:

HI (KEYPAD) SETPOINT MENU
GBAS(5VDC) MODULE
GBAS(10VDC) MODULE

For Default OA Damper Min Position, Use
Setpoint From: HI (KEYPAD) SETPOINT MENU

- Press **Next/Previous** keys to navigate.

Used With: Units w/Economizer Option

Possible Values:

HI (KEYPAD) SETPOINT MENU
REMOTE MIN POS POT INPUT
GBAS(5VDC) MODULE
GBAS(10VDC) MODULE

HUMIDITY CTRL STPT SOURCE SELECT SUBMENU SCREENS

Humidity Ctrl Stpt Source Select Submenu
Press ENTER to Review or Adjust

- Press the **Next** key to skip this Submenu.

Used With: All Units

For Occ Dehumidification Control, Use
Setpoint From: HI (KEYPAD) SETPOINT MENU

- Press **Next/Previous** keys to navigate.

Used With: Units w/Dehumidification Option

Possible Values:

HI (KEYPAD) SETPOINT MENU
GBAS(5VDC) MODULE
GBAS(10VDC) MODULE

For Unocc Dehumidification Control, Use
Setpoint From: HI (KEYPAD) SETPOINT MENU

- Press **Next/Previous** keys to navigate.

Used With: Units w/Dehumidification Option

Possible Values:

[Same as "**Possible Values**" Above]

For Occ Humidification Control, Use
Setpoint From: HI (KEYPAD) SETPOINT MENU

- Press **Next/Previous** keys to navigate.

Used With: Units w/Humidification Option

Possible Values:

[Same as "**Possible Values**" Above]

For Unocc Humidification Control, Use
Setpoint From: HI (KEYPAD) SETPOINT MENU

- Press **Next/Previous** keys to navigate.

Used With: Units w/Humidification Option

Possible Values:

[Same as "**Possible Values**" Above]

For Supply Air Reheat Control, Use
Setpoint From: HI (KEYPAD) SETPOINT MENU

- Press **Next/Previous** keys to navigate.

Used With: Units w/Dehumidification Option

Possible Values:

[Same as "**Possible Values**" Above]

End Of Submenu (NEXT) To ENTER SRC SEL

- Press **Next/Previous** keys to navigate.

Used With: All units.

For Min Outside Air Flow Rate Ctrl, Use
Setpoint From: HI (KEYPAD) SETPOINT MENU

- Press **Next/Previous** keys to navigate.

Used With: Units w/Fresh Air Measurement (VCM) Option

Possible Values:

HI (KEYPAD) SETPOINT MENU

GBAS 0-5 VDC MODULE

GBAS 0-10VDC Module

For Supply Air Pressure Control, Use
Setpoint From: HI (KEYPAD) SETPOINT MENU

- Press **Next/Previous** keys to navigate.

Used With: VVDA Units

Possible Values:

[Same as "**Possible Values**" Above]

For Space Pressure Control, Use
Setpoint From: HI (KEYPAD) SETPOINT MENU

- Press **Next/Previous** keys to navigate.

Used With: Units w/Statitrac Option

Possible Values:

[Same as "**Possible Values**" Above]

End Of Submenu (NEXT) To Enter SETPOINT

- Press Next/Previous keys to navigate.



CONFIGURATION Menu

The electronically controlled unit has many operating functions whose settings are preset at the factory. The following configuration programming steps are provided for those cases where the modules have been replaced after the unit has been in operation and must be reconfigured.

Refer to the Model number stamped on the unit nameplate located on the control panel door while scrolling through the configuration screens. Certain digits of this alpha/numeric model number provide information that must be entered at the Human Interface (HI) in order for the UCM network to operate properly.

Notes:

1. Prior to making any changes to these Configuration Menus, the **Stop** key must be pressed on the Local Human Interface.
2. Many of the screens displayed in this section are applicable only for the options that are installed in the unit and may not be visible on your unit. All screens displayed with "CONFIG REQ'D" are required to be changed prior to unit operation.
3. Pay close attention to the notes throughout this section of the document. The notes describe additional essential messages and other intermediate screen information.

Modifying Selections: Starting with the first configuration screen program the necessary information by using the appropriate keys to navigate (**Next** and **Previous**) and make changes (+ and -) to the selections. Once the selection has been changed to the desired value, the user has the following options to either *Cancel* or *Accept* the pending change:

- To *Cancel*, press the **Cancel** key to remove the change, the display will revert to the original value.
- To *Accept*, press the **Enter** key to confirm the new choice.

Press the **Configuration** key to begin viewing or modifying the configuration screens.

TOP LEVEL CONFIGURATION SCREEN

Unit Product Family is: INTELLIPAK II
Press (NEXT) or (PREVIOUS) to Continue

Used With: All Units

Possible Values:

- INTELLIPAK
- INTELLIPAK II

Note: "Product Family" is based on the absence (INTELLIPAK), or presence (INTELLIPAK II), of a configuration jumper in the wire harness of the RTM module.

Note: This screen is not adjustable.

- Press **Next/Previous** keys to navigate.

Configuration - Model Num Digit	1
Unit Type:	ROOFTOP UNIT

Used With: All Units

Possible Values:

- ROOFTOP UNIT
- AIR HANDLER

Note:

1. For INTELLIPAK II products, if "Unit Type" is changed "Unit Capacity" below is set to CONFIG REQ'D.
2. If "Heating Type" below is Electric Heat, the "Electric Heat Capacity" below is also set to CONFIG. REQ'D.

- Press **Next/Previous** keys to navigate.

CONFIGURATION Menu

Configuration - Model Num Digit	2
Heating Type:	GAS

Used With: All Units.

Possible Values:

ELECTRIC
GAS
HYDRONIC
EXTERNAL HEAT
NONE (COOLING ONLY)

- Press **Next/Previous** keys to navigate.

Configuration - Model Num Digit 5, 6, 7	
Unit Capacity:	90

Used With: All Units w/DX Cooling

Possible Values:

Multiple Selections: 20 through 162 Tons

OR

Configuration - Model Num Digit 5, 6, 7	
Unit Capacity CFM:	16100-45000

Used With: Air Handler Units w/o DX Cooling

Possible Values:

Multiple Selections: 4000 through 45000

- Press **Next/Previous** keys to navigate.

Configuration - Model Num Digit	6
Cooling Type:	NO COOLING

Used With: Air Handler Units

Possible Values:

NO COOLING
DX COOLING
CHILLED WATER

- Press **Next/Previous** keys to navigate.

Configuration - Model Num Digit	9
Electric Heat Capacity:	90 KW

Used With: Units w/Electric Heat Option

Possible Values:

30, 50, 70, 110, 130, 150, 170, 190 KW

OR

Configuration - Model Num Digit	9
Gas Heat Type:	STAGED

Used With: Units w/Gas Heat Option

Possible Values:

STAGED
MODULATING

- Press **Next/Previous** keys to navigate.

Configuration - Model Num Digit 17 or 11	
Exhaust/Return:	NONE

Used With: All Units

Possible Values:

NONE
EXH FAN_W/ STATITRAC
EXH FAN_W/O STATITRAC
RET FAN W/ STATITRAC
RET FAN W/O STATITRAC

Note: "RET FAN..." (All Return Fan) selections are not permitted to be installed here if the "Energy Recovery" option below is set to *INSTALLED*.

- Press **Next/Previous** keys to navigate.



CONFIGURATION Menu

Configuration - Model Num Digit 17 or 20
Single Zone VAV VVZT: INSTALLED

Note: *Single Zone VAV (VVZT) functionality can be inhibited by setting this parameter to NOT INSTALLED. If set to NOT INSTALLED the unit will perform CVZT control.*

- The following screens will be shown if there is a GBAS(5VDC) SZSVAV hardware configuration failure. Otherwise press **Next/Previous** keys to navigate.

GBAS Configuration Hardware Has Failed
Press Enter to Reset, CANCEL to Ignore

Note: *This screen is shown if the unit was configured for SZVAV and the hardware configuration input on the GBAS(5VDC) has failed or has been changed.*

- Press the **ENTER** key to accept, and review the following screen.

Check GBAS Config Hardware, Cycle Power
RETURN HERE TO CONFIRM CONFIGURATION

Note: *This screen instructs the user to:*

1. Turn OFF the power to the unit.
2. Inspect the GBAS(5VDC) hardware configuration input.
3. Restore the power to the Unit.
4. Return to this configuration screen and verify entry.

- Press **Next/Previous** keys to navigate.

Configuration - Model Num Digit 20 or 17
System Control: ZONE TEMP CTRL (CV)

Note: *Zone Temp Ctrl (CV) - (CVZT)
Disch Temp Ctrl (VAV) - (VVDA) - (Indicates w/ IGV/VFD)
Disch Temp Ctrl (CV) - (CVDA) - (Indicates w/o IGV/VFD)*

- Press **Next/Previous** keys to navigate.

Configuration - Model Num Digit 21 or 16
Fresh Air Section: No Fresh Air

- Press **Next/Previous** keys to navigate.

Used With: Units with GBAS(5VDC) Hardware Configuration - SZVAV.

Possible Values:
INSTALLED
NOT INSTALLED

Used With: All Units not configured w/ Single Zone VAV (VVZT).

Possible Values:
ZONE TEMP CTRL (CV)
DISCH TEMP CTRL (VAV)
DISCH TEMP CTRL (CV)

Used With: All Units

Possible Values:
NO FRESH AIR
0-100% ECONOMIZER
0-25% MOTORIZED DAMPER

CONFIGURATION Menu

Configuration - Model Num Digit 21 or 16
Economizer FDD Installed

- Press **Next/Previous** keys to navigate.

Used With: All Units w/ 0-100%
ECONOMIZER

Possible Values:
NOT INSTALLED
INSTALLED

Configuration - Model Num Digit 21 or 31
Ventilation Ctrl (VCM) CONFIG REQ'D

Notes:

1. A VCM module will be required installed if: "Fresh Air Measurement (VCM) w/DCV OPTION" is selected, or
2. "OA Damper Min Pos (VCM) w/DCV Option" is selected and DCV Control in the setup menu is set to ENABLED.

- Press **Next/Previous** keys to navigate.

Used With: All Units

Possible Values:
Vent. Ctrl (VCM) NOT INSTALLED
Fresh Air Meas. (VCM)w/DCV OPTION
OA Damp Min Pos (VCM)w/DCV
OPTION

Configuration - Model Num Digit 21 or 23
Comparative Enthalpy: INSTALLED

- Press **Next/Previous** keys to navigate.

Used With: All Units

Possible Values:
NOT INSTALLED
INSTALLED

Configuration - Model Num Digit 24
Final Filters: INSTALLED

- Press **Next/Previous** keys to navigate.

Used With: All Units

Possible Values:
NOT INSTALLED
INSTALLED

Configuration - Model Num Digit 25
Energy Recovery: NOT INSTALLED

Note: "Energy Recovery" is not permitted to be installed here if "Return Fan..." option above is set to INSTALLED.

- Press **Next/Previous** keys to navigate.

Used With: All Units

Possible Values:
NOT INSTALLED
INSTALLED W/O PREHEAT
INSTALLED W/ PREHEAT

Configuration - Model Num Digit 26
Variable Speed Compressor CONFIG REQ'D

Note: "Variable Speed Compressor" is not permitted to be installed if unit is to be configured with "CV Zone Temp Control", "Hot Gas Bypass", or "Evaporative Condensers".

- Press **Next/Previous** keys to navigate.

Used With: 40 to 70 Ton Ipak I Units w/
VVDA, CVDA, or VVZT

Possible Values:
NOT INSTALLED
INSTALLED



CONFIGURATION Menu

Configuration - Model Num Digit 27
Condenser Type: Air-Cooled

Note: This selection must match the physical unit configuration or improper operation and unit damage may occur. "Sump HT" refers to the Sump Heater installation. "Water-Cooled" condenser not allowed with "Variable Speed Compressor" option.

- Press **Next/Previous** keys to navigate.

Used With: IPak II Units

Possible Values:

AIR-COOLED
WATER-COOLED W/O SUMP HT
WATER-COOLED WITH SUMP HT

Configuration - Model Num Digit 30 or 22
Dehumid w/ Hot Gas Reheat: NOT INSTALLED

Note: "Dehumid w/Hot Gas Reheat" is INSTALLED if the configuration jumper in the wire harness of the RTM module is installed.

- Press **Next/Previous** keys to navigate.

Used With: All IntelliPak Units

Possible Values:

NOT INSTALLED
INSTALLED

Note: This screen is not adjustable.

Configuration - Model Num Digit 30 or 22
Hot Gas Bypass: INSTALLED

Note: If "Hot Gas Bypass" is INSTALLED, Low Charge Protection functions will be automatically disabled. "Hot Gas Bypass" not allowed with "Variable Speed Compressor" option.

- Press **Next/Previous** keys to navigate.

Used With: All Units

Possible Values:

NOT INSTALLED
INSTALLED

Configuration - Model Num Digit 31 or 19
Ambient Control: STANDARD

Note: When set to "STANDARD" the Low Ambient Compressor Lockout setpoint may not be set less than 40°F. When set to "0 DEGREE F" the setpoint can be set down to -20°F.

- Press **Next/Previous** keys to navigate.

Used With: All Units

Possible Values:

STANDARD
0 DEGREE F

Configuration - Model Num Digit 33 or 30
Remote Human Interface INSTALLED

- Press **Next/Previous** keys to navigate.

Used With: All Units

Possible Values:

NOT INSTALLED
INSTALLED

Configuration - Model Num Digit 34 or 35
BAS Communication Module INSTALLED

- Press **Next/Previous** keys to navigate.

Used With: All Units

Possible Values:

NOT INSTALLED
INSTALLED

Configuration - Model Num Digit 34 or 28
GBAS 0-5 VDC Module INSTALLED

- Press **Next/Previous** keys to navigate.

Used With: All Units

Possible Values:
NOT INSTALLED
INSTALLED

Configuration - Model Num Digit 34 or 28
GBAS 0-10 VDC Module INSTALLED

- Press **Next/Previous** keys to navigate.

Used With: All Units

Possible Values:
NOT INSTALLED
INSTALLED

Configuration - Model Num Digit 21 or 34
Rapid Restart: INSTALLED

Note: *Rapid Restart functionality can be inhibited by setting this parameter to NOT INSTALLED. If set to NOT INSTALLED the unit will perform DX staging at restart.*

- The following screens will be shown if there is a GBAS(5VDC) Rapid Restart hardware configuration failure. Otherwise press **Next/Previous** keys to navigate.

Used With: Units with GBAS(5VDC)
Hardware Configuration - Rapid Restart

Possible Values:
INSTALLED
NOT INSTALLED

GBAS Configuration Hardware Has Failed
Press Enter to Reset, CANCEL to Ignore

Note: *This screen is shown if the unit was configured for Rapid Restart and the hardware configuration input on the GBAS(5VDC) has failed or has been changed.*

- Press the **ENTER** key to accept, and review the following screen.

Check GBAS Config Hardware, Cycle Power
RETURN HERE TO CONFIRM CONFIGURATION

Note: *This screen instructs the user to:*

1. Turn OFF the power to the unit.
2. Inspect the GBAS(5VDC) hardware configuration input.
3. Restore the power to the Unit.
4. Return to this configuration screen and verify entry.

- Press **Next/Previous** keys to navigate.

Configuration - Model Num Digit 34 or 31
Ventilation Override (VOM) INSTALLED

- Press **Next/Previous** keys to navigate.

Used With: All Units

Possible Values:
NOT INSTALLED
INSTALLED

Software Revision Number:	INVALID
Exhaust/Comp Enthalpy Module	11.00

Used With: All Units
Possible Values:
[See "RTM Possible Values" Above]

Note: See RTM above for discussion on INVALID.

- Press **Next/Previous** keys to navigate.

Software Revision Number:	INVALID
Heat Module	11.00

Used With: All Units
Possible Values:
[See "RTM Possible Values" Above]

Note: See RTM above for discussion on INVALID.

- Press **Next/Previous** keys to navigate.

Software Revision Number:	INVALID
Unit Human Interface (HI)	32.00

Used With: All Units
Possible Values:
[See "RTM Possible Values" Above]

Note: See RTM above for discussion on INVALID.

- Press **Next/Previous** keys to navigate.

Software Revision Number:	INVALID
Remote Human Interface (RHI)	32.00

Used With: All Units
Possible Values:
[See "RTM Possible Values" Above]

Note: See RTM above for discussion on INVALID.

- Press **Next/Previous** keys to navigate.

Software Revision Number:	INVALID
Ventilation Control Module (VCM)	4.00

Used With: All Units
Possible Values:
[See "RTM Possible Values" Above]

Note: See RTM above for discussion on INVALID.

- Press **Next/Previous** keys to navigate.

Software Revision Number:	INVALID
BAS Communications: Comm5	14.00

Used With: All Units
Possible Values:
[See "RTM Possible Values" Above]

Note: See RTM above for discussion on INVALID.

- Press **Next/Previous** keys to navigate.
-



CONFIGURATION Menu

Software Revision Number:	INVALID
Multi-Purpose Module (MPM)	1.0

Note: See RTM above for discussion on INVALID.

- Press **Next/Previous** keys to navigate.

Software Revision Number:	INVALID
Modulating Dehumid Module (MDM)	1.0

Note: See RTM above for discussion on INVALID.

- Press **Next/Previous** keys to navigate.

Software Revision Number:	INVALID
VSM Module	1.0

Note: See RTM above for discussion on INVALID.

- Press **Next/Previous** keys to navigate.

Used With: All Units

Possible Values:

[See "RTM Possible Values" Above]

Used With: All Units

Possible Values:

[See "RTM Possible Values" Above]

Used With: 40 to 70 Ton Ipak I Units w/
VVDA, CVDA, or VVZT w/ VSC Installed

Possible Values:

[See "RTM Possible Values" Above]



SERVICE MODE Menu (Local Human Interface only)

The SERVICE MODE menu is used to input operating parameters for unit operation during a service test. Depending on the particular test being conducted, the user will cycle through all unit outputs (compressors, fans, dampers, heaters, etc.) and selectively turn them "On" or "Off" for the test. After designating the operating status for each unit component, the operator will designate the "TEST START" delay time.

When a service mode screen is displayed for 30 minutes without a key being pressed, the LCD screen will revert to the general operating status display. If this happens, press the **Service Mode** key again to return to the service menu.

Notes:

1. All "Factory Peristalses are either OFF, CLOSED, or 0% unless otherwise stated.
2. Many of the screens displayed in this section are applicable only for the options that are installed in the unit and may not be visible on your unit.

Modifying Selections: Starting with the first service test screen program the necessary information by using the appropriate keys to navigate (Next and Previous) and make changes (+ and -) to the selections. Once the selection has been changed to the desired value, the user has the following options to either *Cancel* or *Accept* the pending change:

- To *Cancel*, press the **Cancel** key to remove the change, the display will revert to the original value.
- To *Accept*, press the **Enter** key to confirm the new choice.

To operate the system in the TEST MODE, press the **Service Mode** key to enter into the service mode menu and scroll through all of the system outputs and selectively turn them "On" or "Off". After the outputs are set, press the **Test Start** key.

NOTICE

Compressor Failure!

Unit must be powered and crankcase heaters energized at least 8 hours BEFORE compressors are started. This will protect the compressors from premature failure.

TOP LEVEL SERVICE MODE SCREEN

Note: One of the three following screens will be shown based on supply air pressure options.

Supply Air Controls Supply Fan OFF

Used With: CVDA or CVZT Units, w/o Return Fan Option
Possible Values: ON, OFF, AUTO

OR

Supply Air Controls Supply Fan OFF	IGV/VFD Cmd 35%
---------------------------------------	-----------------

Used With: VVDA or VVZT Units w/o Return Fan Option
Possible Values:
Fan: ON, OFF, AUTO
IGV/VFD Cmd: 0 to 100 %

OR



SERVICE MODE Menu (Local Human Interface only)

Supply Fan OFF	IGV/VFD Cmd	0%
Return Fan OFF	VFD Cmd	0%

Note:

The "Return Fan" field is not manually settable but will automatically change as the "Supply Fan" field is changed. This is to insure proper airflow through the unit.
 "IGV/VFD" shown for VVDA or VVZT units.
 "VFD" shown for units with Statirac.

- Press **Next/Previous** keys to navigate.

Used With: Units w/Return Fan Option

Possible Values:

Fan: OFF, ON, AUTO
 IGV/VFD: 0 to 100%
 VFD: 0 to 100%

Note: Fans must be ON, and IGV/VFD command must be 100% if staged heat is being tested.

RTM VAV Box Relay	DRIVE MAX
RTM Alarm Output	ON

- Press **Next/Previous** keys to navigate.

Used With: All Units

Possible Values:

RTM VAV Box Relay: Drive Max, Auto
 Alarm Output: On, Off

Humidification Relay	ON
----------------------	----

Note: The "Humidification Relay" can only be set to ON if the supply fan output is set ON. A message will display indicating such and operation will be prevented.

- Press **Next/Previous** keys to navigate.

Used With: All Units

Possible Values: ON, OFF

ENERGY RECOVERY CONTROL SUBMENU SCREENS

Energy Recovery Control Submenu
Press ENTER to Review or Adjust

- Press the **Next** key to skip this Submenu.

Used With: Units w/Energy Recovery Option

Energy Recovery Wheel Operation:	OFF
Energy Recovery Preheat Relay:	OFF

Note: The "ER Preheat Relay" can only be set to ON if the supply fan output is set to ON. A message will display indicating such and operation will be prevented.

- Press **Next/Previous** keys to navigate.

Used With: Units w/Energy Recovery Option

Possible Values:

Wheel Operation: ON, OFF
 Preheat Relay: ON, OFF

Exhaust Air Bypass Damper Pos:	0%
Outside Air Bypass Damper Pos:	0%

- Press **Next/Previous** keys to navigate.

Used With: Units w/Energy Recovery Option

Possible Values: 0 to 100%

SERVICE MODE Menu (Local Human Interface only)

End Of Submenu (NEXT) For Service Mode

- Press **Next/Previous** keys to navigate.

Used With: Units w/Energy Recovery Option

Notice Compressor Failure!

Unit must be powered and crankcase heaters energized at least 8 hours **BEFORE** compressors are started. This will protect the compressors from premature failure.

COMPRESSOR AND CONDENSER CONTROL SUBMENU SCREENS

Compressor and Condenser Fan Submenu
Press **ENTER** to Review or Adjust

- Press the **Next** key to skip this Submenu.

Used With: Units w/DX Cooling

Head Pressure Control: AUTO
Enables Automatic Sump and Fan Control

Note: The bottom line will display "Enables Automatic Sump and Fan Control" when the control is set to AUTO, and will display "Manual Sump and Fan Control Allowed" when the control is set to MANUAL.

- Press **Next/Previous** keys to navigate.

Used With: Units w/Water-Cooled Condensers

Factory Preset: AUTO

Possible Values: AUTO, MANUAL

Condenser Fan Relay K1: OFF
Condenser Fan Speed Ckt1: 0%

- Press **Next/Previous** keys to navigate.

Used With: Units w/Water-Cooled Condensers

Possible Values:

Fan Relay: ON, OFF

Fan Speed: 0 to 100%

Condenser Fan Relay K5: OFF
Condenser Fan Speed Ckt2: 0%

- Press **Next/Previous** keys to navigate.

Used With: Units > 75 Tons, w/Water-Cooled Condensers

Possible Values:

Fan Relay: ON, OFF

Fan Speed: 0 to 100%



SERVICE MODE Menu (Local Human Interface only)

Condenser Sump Drain Relay:	OFF
Condenser Sump Drain Valve:	CLOSED

Table 7: Sump Drain Valve States

Drain Relay Cmd	Power Loss Config	Valve State
OFF	HOLD	CLOSED
OFF	DRAIN	OPEN
ON	HOLD	OPEN
ON	DRAIN	CLOSED

Used With: Units w/Water-Cooled Condensers

Possible Values:

Relay: OFF, ON

Valve: CLOSED, OPEN (Display Only)

Note: The valve state is based on the power loss configuration of the drain valve. [See "Table 7: Sump Drain Valve States on Left"]

- Press Next/Previous keys to navigate.

Condenser Sump Fill Relay:	ON
Condenser Sump Fill Valve:	OPEN

- Press **Next/Previous** keys to navigate.

Used With: Units w/Water-Cooled Condensers

Possible Values:

Relay: OFF, ON

Valve: CLOSED, OPEN (Display Only)

Sump Heater Relay:	OFF
--------------------	-----

- Press **Next/Previous** keys to navigate.

Used With: Units w/Water-Cooled Condensers and Sump Heat Installed

Possible Values: ON, OFF

Condenser Sump Pump Relay:	OFF
----------------------------	-----

- Press **Next/Previous** keys to navigate.

Used With: Units w/Water-Cooled Condensers

Possible Values: ON, OFF

Condenser Fan Outputs
K1: OFF K2: OFF

Note: If either K1 or K2 is set to AUTO, the other will automatically be changed to AUTO.

- Press **Next/Previous** keys to navigate.

Used With: Units w/DX Cooling < 40 Tons, and Airside Condensers Installed

Possible Values: ON, OFF, AUTO

Condenser Fan Outputs (MCM 1)
K1: OFF K2: OFF K5: OFF K6: OFF

Note:

1. If either K1 or K2 is set to AUTO, the other will automatically be changed to AUTO.
2. If either K5 or K6 is set to AUTO, the other will automatically be changed to AUTO.

- Press **Next/Previous** keys to navigate.

Used With: Units w/DX Cooling \geq 40 Tons, and Airside Condensers Installed

Possible Values: ON, OFF, AUTO

SERVICE MODE Menu (Local Human Interface only)

Condenser Fan Speed (MCM 1)			
Circuit 1	0%	Circuit 2	0%

Note: "Circuit 2" only shown for DX Cooling > 40 Tons.

- Press **Next/Previous** keys to navigate.

Used With: Units w/DX Cooling and Airside Condensers Installed
Possible Values: AUTO, 0 to 100%

Compressor Relays	
K10: OFF	K11: OFF

- Press **Next/Previous** keys to navigate.

Used With: Units w/DX Cooling < 40 Tons
Possible Values: OFF, ON

Compressor Relays (MCM 1)			
K11: OFF	K12: OFF	K3: OFF	K4: OFF

- Press **Next/Previous** keys to navigate.

Used With: Units w/DX Cooling ≥ 40 Tons, w/o Variable Speed Compressor
Possible Values: OFF, ON

OR

Compressor Relays (MCM 1)			
K11: OFF	Spd: 100%	K3: OFF	K4: OFF

- Press **Next/Previous** keys to navigate.

Used With: Units w/DX Cooling ≥ 40 Tons, w/ Variable Speed Compressor
Possible Values:
 Relays: OFF, ON
 Spd: 0 to 100% (100% command correlates to Applied Design Capacity)

Note: Applied Design Capacity is the maximum cooling capacity of the variable speed compressor for this unit's tonnage design.

Reheat Coil Pumpout Relay:	ON
Reheat Pumpout Solenoid/Valve:	CLOSED

Note:

1. "Relay:" may be adjusted manually only when compressors are set to OFF. Otherwise the value is set automatically as a function of Reheat Valve Position set below.
2. "Solenoid/Valve:" is a display only field.

- Press **Next/Previous** keys to navigate.

Used With: Units w/Dehumidification Option
Factory Preset:
 Relay: ON
 Solenoid Valve: CLOSED (Display Only)
Possible Values:
 Reheat Relay: ON, OFF
 Solenoid Valve: (Display Only)
 OPEN – when Relay set to OFF
 CLOSED – when Relay set to ON



SERVICE MODE Menu (Local Human Interface only)

Dehumid Reheat Valve Position:	0%
Dehumid Cooling Valve Position:	100%

Note:

1. With all compressors on the reheat circuit set to OFF, the "Reheat Valve Position" can be set to any value between 0 and 100%. Once a compressor on the circuit is turned ON, the values allowed will be between 15 and 85%.
2. "Cooling Valve Position" is display only. This value is the reverse that of the "Reheat Valve Position"
ex. CVP = 100% - RVP

- Press **Next/Previous** keys to navigate.

End Of Submenu (NEXT) For Service Mode
--

- Press **Next/Previous** keys to navigate.

Relay State =	HEAT	ON
Hydro Heat/Chilled Water Output		0%

Table 8: Hydronic Heat/Chilled Water Relay

State/Relays	K11	K12	K1
OFF	OFF	OFF	OFF
Cool On	ON	ON	OFF
Heat On	OFF	OFF	Note 1
Override	ON	OFF	Note 2

Notes:

1. K1 turns ON when the output is commanded > 0%.
2. *Override occurs with Freezestat or service test request.*

- Press **Next/Previous** keys to navigate.

Used With: Units w/Dehumidification Option

Factory Preset:

- Reheat Valve: 0%
- Cooling Valve: 100% (Display Only)

Possible Values:

- Reheat Valve: 0 to 100%
- Cooling Valve: 100 to 0% (Display Only)

Used With: All Units w/DX Cooling

Used With: Air Handlers w/Chilled Water Cooling and Hydronic Heat

Possible Values:

- Relay State: HEAT ON, COOL ON, OVERRIDE
- Output: 0 to 100%

Note: *The relays on the HEAT module, and associated wiring, are used to route the 0 to 10VDC modulating output to the Chill Water and Hydronic Heat actuators. [See " Table 8: Hydronic Heat/Chilled Water Relay on Left"]*

SERVICE MODE Menu (Local Human Interface only)

Relay State =	HEAT ON
Mod Gas Heat/Chilled Water Output	0%

Table 9: Modulating Gas Heat / Chilled Water Relay

State/Relays	K11	K12	K1
OFF	OFF	OFF	OFF
Cool On	OFF	OFF	OFF
Heat On	ON	OFF	Note 1
Override	OFF	OFF	OFF

Note: K1 turns ON when the output is commanded > 0%.

- Press **Next/Previous** keys to navigate.

Chilled Water Actuator	0%
------------------------	----

- Press **Next/Previous** keys to navigate.

Hydronic Heat Actuator	0%
------------------------	----

- Press **Next/Previous** keys to navigate.

Modulating Gas Heat Actuator	0%
------------------------------	----

- Press **Next/Previous** keys to navigate.

Used With: Air Handlers w/Chilled Water Cooling and Modulating Gas Heat
Possible Values:

Relay State: HEAT ON, COOL ON
 Output: 0 to 100%

Note: The relays on the HEAT module, and associated wiring, are used to route the 0 to 10VDC modulating output to the Chill Water and Mod Gas Heat actuators. [see " [Table 9: Modulating Gas Heat / Chilled Water Relay on Left](#)"]

Used With: Air Handlers w/Chilled Water Cooling (If Heating Unit, Hydronic or Modulating Gas Is Not Installed)

Possible Values: 0 to 100%

Used With: Hydronic Heat Units, (If Air Handler Unit, Chill Water Is Not Installed)

Possible Values: 0 to 100%

Used With: Modulating Gas Heat Units, (If Air Handler Unit, Chill Water Is Not Installed)

Possible Values: 0 to 100%



SERVICE MODE Menu (Local Human Interface only)

Heat Stages: 0
 K11: OFF K12: OFF K1: OFF

Used With: Units w/Staged Gas or Electric Heat Option

Possible Values:
Stages: 0, 1, 2, 3, 4, 5
[Config. Dependent-see " Table 10: Electric Heat Relay States"]

Table 10: Electric Heat Relay States

Stage	All Units Gas Heat			IntelliPak I Electric Heat			IntelliPak II								
	K11	K12	K1	K11	K12	K1	90 KW			140 KW			265/300 KW		
	K11	K12	K1	K11	K12	K1	K11	K12	K1	K11	K12	K1	K11	K12	K1
OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
Stage 1	ON	ON	OFF	ON	OFF	OFF	ON	OFF	OFF	ON	OFF	OFF	ON	OFF	OFF
Stage 2	ON	ON	ON	ON	ON	OFF	ON	ON	OFF	OFF	ON	OFF	OFF	ON	OFF
Stage 3				ON	ON	ON	ON	ON	ON	ON	ON	OFF	ON	ON	OFF
Stage 4										ON	ON	ON	OFF	ON	ON
Stage 5													ON	ON	ON

- Press **Next/Previous** keys to navigate.

OA Damper: 0% Exhaust Damper: 0%
 Exhaust Fan: OFF

Used With: All Units

Possible Values:

OA Damper: 0 to 100% (Economizer Option)
 0 to 25% (Motorized Damper Option)
 Exhaust Damper: 0 to 100%
 Exhaust fan: OFF, ON

"OA Damper" shown if Economizer or 25% Damper installed.
 "Exhaust Damper" shown if Power Exhaust w/Statitrac installed.
 "Exhaust Fan" shown if Power Exhaust w/o Return Fan installed.

- Press **Next/Previous** keys to navigate.

Ventilation Override Module Output Relay
 OFF

Used With: Units w/VOM Option

Possible Values: ON, OFF

- Press **Next/Previous** keys to navigate.

VCM Preheater State OFF

Used With: Units w/Fresh Air Measurement (VCM) Option

Possible Values: ON, OFF

- Press **Next/Previous** keys to navigate.

GBAS 0-5VDC Module Relay Outputs
 #1 OFF #2 OFF #3 OFF #4 OFF #5 OFF

Used With: Units w/GBAS(5VDC) Option

Possible Values: ON, OFF

- Press **Next/Previous** keys to navigate.

GBAS 0-10VDC Module Relay Outputs
 #1 OFF

Used With: Units w/GBAS(10VDC) Option

Possible Values: ON, OFF

- Press **Next/Previous** keys to navigate.

SERVICE MODE Menu (Local Human Interface only)

GBAS 0-10VDC Module Analog Outputs
#1 0 v #2 0 v #3 0v #4 0v

Press the **Next** key to navigate forward.

Used With: Units w/GBAS(10VDC)
Option
Possible Values: 0 to 10.0 v (volts)

Status/Annunc Test Sys On (Blinking)
Heat: OFF Cool: OFF Service: OFF

• Press **Next/Previous** keys to navigate.

Used With: All Units
Possible Values:
HEAT: ON, OFF
COOL: ON, OFF
SERVICE: ON, OFF

Start Test In 5 Seconds
Press TEST START To Begin, STOP To Halt

Used With: All Units
Factory Presets: 5 Sec
Possible Values: 0 to 120 Sec



DIAGNOSTICS Menu

The DIAGNOSTICS menu is used to view diagnostics that have resulted from system failures within the unit. There are two lists where diagnostics reside; the *Active List*, and the *Diagnostic Event Log*.

The *Active List* is used for viewing all active diagnostics and for clearing diagnostics that can be manually reset. These lists of diagnostics are displayed after pressing the **Diagnos**tics key if active diagnostics are present.

Active manual diagnostics can be cleared in batch form at the unit mounted Human Interface. When an active diagnostic is manually or automatically cleared, it is removed from this buffer. Automatically resetting diagnostics cannot be reset by the Human Interface, because the condition that caused the diagnostic has to be corrected for the diagnostic to clear.

The word "MORE" is displayed on all screens if more than one diagnostic exist, except for the last diagnostic. Upon reaching the last diagnostic, the word "MORE" disappears. Pressing the **Next** key at this point causes the display to advance to the first diagnostic in the *Diagnostic Event Log*.

The *Diagnostic Event Log* screens are displayed after scrolling through the *Active List* or after pressing the **Diagnos**tics key when no active diagnostics are present. It's used to view the past 20 diagnostics. Diagnostics in this log are stacked in inverse chronological order, with the first diagnostic screen being the most recently reported diagnostic.

When a new diagnostic is displayed, the words "NOT VIEWED" are displayed with it. After viewing the last not viewed diagnostic, the words "NOTVIEWED" change to "VIEWED" for every diagnostic in the log. The diagnostic will remain this way as long as it is in the log. This allows the operator to distinguish between old and new diagnostics in the event log.

Pressing the **Next** key after reaching the last diagnostic in the event log advances the display to the first diagnostic in the *Active List* if any exist. If not, the display reverts back to the first event log diagnostic. If the *Diagnostic Event Log* is full (20 events), and another diagnostic occurs, the oldest diagnostic is pushed off the end of the list. If all 20 diagnostics in the list are active when the 21st occurs, then the oldest active diagnostic is pushed off the end of the list. When an active diagnostic is automatically or manually cleared in the active buffer, its status in the *Diagnostic Event Log* changes from "Active" to "History". If the operator does not clear an active diagnostic in the *Active List*, its status will still show as active in the *Diagnostic Event Log*.

When a diagnostic screen is displayed for more than four hours without a key being pressed, the screen will return to the operating status display.

One of the following screens will be the first screen displayed when the **Diagnostic** key is pressed.

Diagnostic Menu ---- Info
No Active Diagnostics (NEXT) History Log

OR

Press CANCEL to Clear All Active Manual
Diagnostics, or Press NEXT to View

Note: Pressing the **Cancel** key to clear the diagnostics will prompt the following screen...

Diagnostic Reset Is Password Protected
Please Enter Password:

Notes:

1. Press the + (plus) or - (minus) keys to enter the password.
2. Press the **Enter** key to confirm this choice. When the correct password is entered, the following screen will be displayed...

Used With: All Units
Factory Presets: N/A
Possible Values: + (Plus) and - (Minus)

**Resetting Active Manual Diagnostics
Sending Reset Request**

Note: Once the clear diagnostic request is sent to all the modules, the following screen will be displayed...

**Resetting Active Manual Diagnostics
Updating Unit Data, Please wait**

Note: Once the unit data has been updated, the following screen will be displayed...

**Active Diagnostic -- Info
Please Wait, Unit Is In Reset Mode**

Note: Once the control modules have reset, if there are reoccurring diagnostics the following screen will be displayed...

**Active Diagnostic -- Manual Reset
Low Pressure Control Open - Ckt 1 More**

Note: The word "More" will only appear if more than one failure is occurring. Press the **Next** key to view the remaining diagnostics if any exist.

- Used With:** All units
Factory Presets: N/A
Possible Values: [Manual Reset]
 Blocked Air Return
 Compressor Contactor/Drive Fail - Ckt 1
 Compressor Contactor/Drive Fail - Ckt 2
 Compressor Trip - Ckt 1
 Compressor Trip - Ckt 2
 Cond Sump Heater Failure
 Cond Sump Pump Manual Fail
 Cond Sump Min Level Short Cycling
 Emergency Stop
 Energy Recovery Wheel Proof Failure
 Exhaust Fan Failure
 High Comp Press Diff Failure - Ckt 1
 High Comp Press Diff Failure - Ckt 2
 Low Air Temperature Limit Trip
 Low Pressure Control Open - Ckt 1
 Low Pressure Control Open - Ckt 2
 Low Refrigerant Charge - Ckt 1
 Low Refrigerant Charge - Ckt 2
 Manual Reset Return Pressure Limit
 Manual Reset SA Static Pressure Limit
 Manual Reset Space Press Low Limit Trip
 Return Fan Failure
 Rooftop Module Data Storage Error
 Supply Fan Failure
 Supply Fan Proving Failure



DIAGNOSTICS Menu

Note: Pressing the **Next** key at the last Manual Reset Diagnostic will prompt the following screen if an "Auto Reset" failure has occurred.

Active Diagnostic -- Auto Reset	
OA Temp Sensor Failure	More

Note: The word "More" will only appear if more than one failure is occurring.
Press the Next key to view the remaining diagnostics if any exist.

Possible Values: (cont):

- Occ Zone Heat Setpoint Failure
- Outdoor Air Damper Not Modulating
- RTM AUX Temp Sensor Failure
- RTM Space Humidity Sensor Fail
- RTM Zone Temp Sensor Failure
- RA Humidity Sensor Failure
- Rapid Restart HW Config Failure
- Return Air Temp Sensor Failure
- Return Plenum Press Sensor Fail
- SCM Communications Failure
- Space Pressure Low Limit Trip
- Space Pressure Low Limit Warning
- Space Pressure Sensor Failure
- Space Static Pres Setpt Failure
- Supply Air Pres Sensor Failure
- Supply Air Pres Setpt Failure
- Supply Air Reheat Setpoint Failure
- Supply Air Temp Cool Setpt Fail
- Supply Air Temp Heat Setpt Fail
- Supply Air Temp Sensor Failure
- SZVAV HW Configuration Failure
- Unit Economizing When It Should Not
- Unit HI Communications Failure
- Unit Not Economizing When It Should
- Unocc Dehumidification Setpoint Fail
- Unocc Humidification Setpoint Fail
- Unocc Zone Cool Setpt Failure
- Unocc Zone Heat Setpt Failure
- VCM Aux. Temp Sensor Failure
- VCM Module Comm Failure
- Velocity Pressure Sensor Failure
- Velocity Press Sensor (Left) Fail
- Velocity Press Sensor (Right) Fail
- VOM Communications Failure
- VSM Module Comm Failure

Note: Pressing the **Next** key at the last Auto Reset Diagnostic will prompt the following screen if an "Info Only Reset" failure has occurred.

Used With: All units

Factory Presets: N/A

Possible Values: [Auto Reset]

- Auto Reset Return Pressure Limit
- Auto Reset SA Static Pres Limit
- BAS Module Comm Failure
- BAS/Network Comm Failure
- CO2 Sensor Failure
- Cond Pressure Sensor Fail Ckt
- Cond Pressure Sensor Fail Ckt
- Cond Sump Max Level Failure
- Cond Sump Min Level or Drain Failure
- Cond Sump Temp Sensor Failure
- Cond Temp Sensor Failure - Ckt 1
- Cond Temp Sensor Failure - Ckt 2
- ECEM Communications Failure
- Economizer Drybulb Setpoint Failure
- Entering Evap Temp Sensor Fail - Ckt 1
- Entering Evap Temp Sensor Fail - Ckt 2
- Evap Temp Sensor Failure - Ckt 1
- Evap Temp Sensor Failure - Ckt 2
- Excessive Outdoor Air
- GBAS 0-5VDC Module Comm Failure
- GBAS 0-10VDC Module Comm Failure
- Heat AUX Temp Sensor Fail
- Heat Module Comm Failure
- High Super Heat - Ckt 1
- High Super Heat - Ckt 2
- Leaving Recovery Exhaust Temp Failure
- MCM Communications Failure
- MDM Communications Failure
- MPM Communications Fail
- Min OA Flow Setpoint Fail
- Min Position Setpoint Fail
- Mode Input Failure
- Morning Warmup Setpoint Failure
- NSB Panel Comm Failure
- NSB Panel Zone Temp Sensor Fail
- OA Humidity Sensor Failure
- OA Temp Sensor Failure
- Occ Dehumidification Setpoint Failure
- Occ Humid Setpoint Fail
- Occ Zone Cool Setpoint Failure

(continued at left)

DIAGNOSTICS Menu

Active Diagnostic -- Info
 Dirty Recovery Filter More

Note: The word "More" will only appear if more than one failure is occurring. Press the **Next** key to view the remaining diagnostics if any exist.

Note: Pressing the **Next** key at the last Info Only Diagnostic will prompt the following screen...

Used With: All units
Factory Presets: N/A
Possible Values: [Information Only]
 Heat Fail
 Dirty Filter
 Dirty Final Filter
 Dirty Recovery Filter
 Ventilation Override Mode A, B, C, D, E

Log 1 (Viewed) History Manual
 Supply Air Pres Setpt Failure

- Notes:**
- Any diagnostic listed under the previous screens will be displayed here. This screen will show the last 20 diagnostics that have occurred with the latest being assigned to "Log 1", the prior being pushed to "Log 2" (and so on) with the last diagnostic in the list being removed if beyond the 20th position. No diagnostic will be logged consecutively, another diagnostic must occur prior to an older diagnostic being re-entered into the log.
 - Press the **Next** key to view any remaining diagnostic history items. Pressing the **Cancel** key, to clear the diagnostic history log, will prompt the following screen...

Used With: All units
Factory Presets: N/A
Possible Values: Log Number 1-20
Top Middle-Left Field:
 Viewed, Not Viewed
Top Middle-Right Field:
 Active, History
Top Right Field:
 Manual, Auto, Info.

Diagnostic Log Is Password Protected
 Please Enter Password:

- Notes:**
- Press the + (plus) or - (minus) keys to enter the password.
 - Press the **ENTER** key to confirm this choice. When the correct password is entered, the following screen will be displayed...

Used With: All units
Factory Presets: N/A
Possible Values: + (Plus) and - (Minus)

Active Diagnostics Manual
 Please Wait, Updating Diagnostic Log

OR

Note: If the **Cancel** key is pressed there are no diagnostics listed in the "DIAGNOSTIC LOG", the following screen will be displayed...

Used With: All units
Factory Presets: N/A
Possible Values: Manual, Auto, or Info



DIAGNOSTICS Menu

Active Diagnostics ---- Info
"Diagnostic Buffer Is Already Empty!"

Note: Press the **Auto** or **Stop** key to return to the top level status screen.

Used With: All units
Factory Presets: N/A
Possible Values: Manual, Auto, or Info

Communication Link Problems

Note: If one of the following 2 screens appear, the Human Interface is not communicating properly with the unit.

LOCAL HI COMMUNICATIONS LOSS
CHECK COMM LINK WIRING BETWEEN MODULES

Problem: The *Local Human Interface* has lost communications with the RTM module. See "Fail Diagnostic" for additional information.

Check: Wiring between the *Local Human Interface*, unit mounted communications terminal block, and RTM. Verify crimping and polarity of communications wiring. There should be no loose connections or crimps on wire insulation. See the appropriate unit wiring manual for additional information.

Used With: All Units

Note: The "Local HI" (*Local Human Interface*) is located at the unit.

OR

REMOTE HI COMMUNICATIONS LOSS
CHECK COMM LINK WIRING TO UNIT NUMBER 3

Problem: The *Remote Human Interface* has lost communications with the unit whose number is specified (#3 in this example).

Check: Field/unit wiring between Remote Human Interface and the IPCB on the unit number specified. Also, verify wiring between the IPCB and RTM of the unit whose number is specified. Verify crimping and polarity of communications wiring. There should be no loose connections or crimps on wire insulation.

Used With: Units w/Remote Human Interface Option

Possible Values:
Unit Number: 1, 2, 3, 4

Note: If one of the following 2 screens appear, the communications link is marginal or there is another Human Interface of the same type on the link.

IMPROPER HUMAN INTERFACE CONFIGURATION
MORE THAN ONE LOCAL HI ON LINK

Problem: Noisy Communications link or a second Local HI has been installed on the link.

Check: Wiring between the *Local Human Interface*, unit mounted communications terminal block, and RTM. Verify crimping and polarity of communications wiring. There should be no loose connections or crimps on wire insulation. See the appropriate unit wiring manual for additional information. Also, if a Remote HI was installed, verify that a Local HI was not installed by mistake.

Used With: All Units

OR

**IMPROPER HUMAN INTERFACE CONFIGURATION
MORE THAN ONE REMOTE HI ON LINK**

Used With: All Units w/Remote Human Interface Option

Problem: Noisy Communications link or a second Remote HI has been installed on the link.

Check: Field/Unit wiring between Remote Human Interface and the IPCB and RTM. Verify crimping of communications wiring. There should be no loose connections or crimps on wire insulation. Verify that no other Remote HI's have been connected to the same communications link/unit.

**MODULE SOFTWARE VERSION MISMATCH
PRESS CONFIG TO REVIEW, SEE LITERATURE**

Used With: All Units

Problem: One or more control modules are installed that have a version of software that does not match the required versions for the installed features.

Check: Use the HI Configuration Menu to check the software versions of the required modules. The ones that do not match will have the word "INVALID" in the upper right corner of the screen. Replace the software in those modules with the latest version.

DIAGNOSTICS Menu

Diagnostics

There are four types of diagnostics:

1. (PMR) Partial System Disable, Manual Reset
2. (PAR) Partial System Disable, Auto Reset
3. (INFO) Information Only
4. (HO) History Only

The *Troubleshooting Chart* below list all of the possible failure modes with the following columns:

Used With: *Diagnostic Displayed:* The string displayed at the HI, associated module, and "used with" info.

5. *Reason For Diagnostic:* The condition which caused the failure mode, and troubleshooting tips.
6. *UCM's Reaction:* The type of failure, and the unit's response to the failure w/additional information.
7. *Reset Required:* The conditions that must exist to clear the diagnostic.

Table 11: Diagnostics Troubleshooting Chart

DIAGNOSTIC DISPLAYED	REASON FOR DIAGNOSTIC	UCM'S REACTION	RESET REQUIRED
Auto Reset Return Pressure Limit Used With: Return Fan w/ Power Exhaust w/Statitrac. Module: MPM	Problem: The return plenum pressure exceeded the <i>Return Plenum Pressure High Limit Setpoint</i> (3.5 iwc non-adjustable) continuously for 1 second. Check: Return/Outside Damper, Exhaust Damper linkage. Return Plenum Pressure reading.	The unit will trip all outputs, de-energize dx cooling, staged heating, fans, etc., and will drive all analog outputs closed/stop fan speed, dampers, modulating heat, etc. The Return Pressure High Limit trip counter is incremented.	(PAR) An automatic reset occurs when the return plenum pressure drops below the <i>Return Plenum Pressure High Limit Setpoint</i> , the IGV/VFD have closed/stopped, and 15 seconds have elapsed since the shutdown command was issued.
Auto Reset SA Static Pressure Limit Used With: VVDA units, or CVDA/CVZT units with supply air pressure sensor installed. Module: RTM	Problem: The supply air static pressure exceeded the <i>SA Static Pressure High Limit Setpoint</i> for at least one second continuously. Check: SA Pressure Sensor Assembly, Isolation Dampers, ductwork, BAS system control of VAV Boxes.	The unit will trip all outputs, de-energize dx cooling, staged heating, fans, etc., and will drive all analog outputs closed/stop fan speed, dampers, modulating heat, etc. The Supply Pressure High Limit trip counter is incremented.	(PAR) An automatic reset occurs when the supply air pressure drops below the <i>SA Static Pressure High Limit Setpoint</i> , the IGV/VFD have closed/stopped, and 15 seconds have elapsed since the shutdown command was issued.
BAS Module Communications Failure Used With: BAS system control is expected. Module: BAS	Problem: The RTM has lost communications with the LCI or BCI. Check: Check all unit wiring and terminations between the RTM and LCI/BCI modules.	All active commands and control setpoints provided by the network, through the LCI or BCI, will be cancelled and/ or ignored. Setpoints will fall-back to the default designated sources, otherwise Human Interface setpoints will be used.	(PAR) An automatic reset occurs after communication has been restored.

Table 11: Diagnostics Troubleshooting Chart (continued)

DIAGNOSTIC DISPLAYED	REASON FOR DIAGNOSTIC	UCM'S REACTION	RESET REQUIRED
<p>BAS/Network Comm Failure</p> <p>Used With: BAS system control is expected.</p> <p>Module: BAS</p>	<p>Problem: The LCI or BCI has lost communications with the Network for > 15 minutes.</p> <p>Check: That the Network (Tracer or 3rd party building control panel) is powered up and running properly. If so, check unit wiring between LCI or BCI and network (Tracer or 3rd party building control panel).</p>	<p>All active commands and control setpoints provided by the network, through the LCI or BCI, will be cancelled and/ or ignored. Setpoints will fall-back to the default designated sources, otherwise Human Interface setpoints will be used.</p>	<p>(PAR) An automatic reset occurs after communication between the network and LCI or BCI has been restored.</p>
<p>Blocked Air Return Failure</p> <p>Used With: Option available w/Fresh Air Measurement (VCM), OA Damper w/DCV or CO₂ Reset installed.</p> <p>Module: VCM</p>	<p>Problem: The low pressure limit on the VCM module is detected closed for 1 second.</p> <p>Check: Mixed air section damper linkages and actuators for proper travel and operation and return duct for impediments to airflow. Check wiring between mixed air pressure sensor and VCM module. Check wiring between all damper actuators and control box.</p>	<p>The unit will trip all outputs, de-energize dx cooling, staged heating, fans, etc., and will drive all analog outputs closed/stop fan speed, dampers, modulating heat, etc.</p>	<p>(PMR) A manual reset is required after the diagnostic is set. It can be reset by the HI or Tracer, or by cycling power to the RTM.</p>
<p>CO₂ Sensor Failure</p> <p>Used With: DCV option or CO₂ reset function installed.</p> <p>Module: VCM</p>	<p>Problem: The CO₂ Sensor input is out of range.</p> <p>Check: Wiring between the VCM and customer terminal block, and between the terminal block and sensor.</p>	<p>All DCV (Demand Control Ventilation) functions, or CO₂ reset functions, will cease and the unit will fall-back to the default outside air damper minimum position arbitration logic.</p>	<p>(PAR) An automatic reset occurs after the CO₂ Sensor transducer input receives a signal that is within range for 10 continuous seconds.</p>
<p>Compressor Contactor/ Drive Fail (Ckt-1 or Ckt-2)</p> <p>Used With: See compressor protection devices on MCM control wiring schematic.</p> <p>Module: MCM</p>	<p>Problem: The compressor contactor for the given circuit has malfunctioned. The circuit's compressor proving input is detected closed continuously for more than 3 seconds while neither compressor is on.</p> <p>Check: The circuits contactor, side contacts, wiring, etc.</p>	<p>All compressors on the associated circuit will be locked out and prevented from operation.</p>	<p>(PMR) A manual reset is required after the diagnostic is set. It can be reset by the HI or Tracer, or by cycling power to the RTM.</p>

DIAGNOSTICS Menu

Table 11: Diagnostics Troubleshooting Chart (continued)

DIAGNOSTIC DISPLAYED	REASON FOR DIAGNOSTIC	UCM'S REACTION	RESET REQUIRED
<p>Compressor Trip (Ckt-1 or Ckt-2)</p> <p>Used With: See compressor protection devices on MCM control wiring schematic.</p> <p>Module: MCM</p>	<p>Problem: There have been 4 occurrences*, during active compressor operation, of the compressor proving input for the given circuit being detected open continuously for more than 3 seconds.</p> <p>Check: All compressor protection devices in the associated refrigerant circuit's 115v contactor control wiring circuit.</p>	<p>Prior to the (PMR), each occurrence of a compressor trip will inhibit all compressor operation of the circuit for a period of 15 minutes. After this period the circuit will be allowed to restart.</p> <p>During the (PMR), all compressors on the associated circuit will be locked out and prevented from operation.</p>	<p>(PMR) A manual reset¹ is required after this diagnostic occurs. The Diagnostic can be reset by the unit mounted Human Interface Module or Tracer, or by cycling power to the RTM.</p> <p>Note: *Prior to the (PMR), if any compressor on the circuit has 3 continuous minutes of operation, the occurrences counter resets to zero and no error is generated.</p>
<p>Condenser Pressure Sensor Failure (Ckt-1 or Ckt-2)</p> <p>Used With: DX cooling w/ water cooled condensers.</p> <p>Module: MPM</p>	<p>Problem: The saturated condenser pressure sensor input is out of range for the given circuit.</p> <p>Check: Wiring from the MPM to the pressure sensor. The input voltage range should be between: 0.625 and 4.80VDC.</p>	<p>All compressors on the associated circuit will be locked out and prevented from operation.</p>	<p>(PAR) An automatic reset occurs after the Condenser Pressure Sensor input returns to within range for 10 continuous seconds.</p>
<p>Condenser Sump Heater Failure Manual</p> <p>Used With: DX cooling w/ water cooled condensers w/sump heater.</p> <p>Module: MCM</p>	<p>Problem: The sump min level switch is CLOSED, and the Sump Water Temperature is less than 37.5 F, and has remained this way for 20 minutes.</p> <p>Check: Actual water level, minimum level switch, heater power circuitry.</p>	<p>The unit will perform Sump Water Freeze Protection function.</p>	<p>(PMR) A manual reset is required anytime after the Diagnostic is set to re-enable compressor operation. The Diagnostic can be reset by the Human Interface or Tracer, or by cycling power to the RTM.</p>
<p>Condenser Sump Pump Manual Fail</p> <p>Used With: DX cooling w/ water cooled condensers.</p> <p>Module: MCM</p>	<p>Problem: Sump Pump contactor auxiliary contacts do not close (state change), within 6 seconds, when the pump is requested ON for mechanical cooling, or are open for 6 continuous seconds during compressor operation.</p> <p>Check: Wiring to sump pump, contactor, and auxiliary contacts. Check for pump operation.</p>	<p>A compressor lockout is generated on all circuits.</p>	<p>(PMR) A manual reset is required anytime after the Diagnostic is set to re-enable compressor operation. The Diagnostic can be reset by the Human Interface or Tracer, or by cycling power to the RTM.</p>

Table 11: Diagnostics Troubleshooting Chart (continued)

DIAGNOSTIC DISPLAYED	REASON FOR DIAGNOSTIC	UCM'S REACTION	RESET REQUIRED
<p>Cond Sump Max Level Failure</p> <p>Used With: DX cooling w/ water cooled condensers.</p> <p>Module: MCM</p>	<p>Problem: The condenser sump water level reaching the <i>Cond Sump Max Level Switch</i> is considered an undesirable condition indicating a problem with the mechanical float valve or some other water control mechanism.</p> <p>Check: Max level switch, float apparatus, and wiring</p>	<p>The <i>Cond Sump Fill Relay</i> will be de-energized.</p>	<p>(PAR) Once the <i>Cond Sump Max Level Switch</i> input is open for 120 continuous seconds the diagnostic will be cleared and the <i>Cond Sump Fill Relay</i> will be energized.</p>
<p>Cond Sump Min Level or Drain Fail</p> <p>Used With: DX cooling w/ water cooled condensers.</p> <p>Module: MCM</p>	<p>Problem:</p> <p>Min Level Fail: The <i>Cond Water Sump Fill Relay</i> is energized, the 30-minute fill timer expired and the <i>Cond Water Sump Min Level Input</i> has not closed.</p> <p>Drain Fail: The Cond Sump Min Level Input has remained CLOSED for 5 continuous minutes after a Cond Sump Drain Request has occurred.</p> <p>Check: wiring from the MCM to the Sump Fill valve, water flow to the sump, sump min level switch and associated wiring.</p>	<p>All compressor circuits are locked out due to inability to determine if the sump has sufficient water level.</p> <p>De-energize the Heat relay.</p>	<p>(PAR) An automatic reset occurs after:</p> <p>Min Level Fail: the Cond Water Sump Min Level Input is closed for 10 continuous seconds.</p> <p>Drain Fail: the Cond Sump Min Level is open for 10 continuous seconds.</p> <p>Both: clear the diagnostic and compressor lockouts.</p>
<p>Condenser Sump Temp Sensor Failure</p> <p>Used With: DX cooling w/ water cooled condensers.</p> <p>Module: MCM</p>	<p>Problem: The <i>Condenser Sump Temperature Sensor</i> input is out of range. (Temperature < -40F or Temperature > 200 F).</p> <p>Check: Wiring from the MCM to the temperature sensor. Removing the plug from the MCM there should be no shorts or opens on the wires, readings should be between 830 ohms and 345k ohms.</p>	<p>A compressor lockout is generated on all circuits and the Condenser Sump is drained completely if the <i>Outdoor Air Temp</i> is below 35F or failed.</p>	<p>(PAR) An automatic reset occurs and the sump is allowed to fill after the Condenser Sump Temp input rises above 40F for 10 seconds.</p>

DIAGNOSTICS Menu

Table 11: Diagnostics Troubleshooting Chart (continued)

DIAGNOSTIC DISPLAYED	REASON FOR DIAGNOSTIC	UCM'S REACTION	RESET REQUIRED
<p>Condenser Sump Min Level Short Cycle Failure</p> <p>Used With: DX cooling w/ water cooled condensers.</p> <p>Module: MCM</p>	<p>Problem: The <i>Sump Min Level Input</i> has opened three times without 60 seconds of continuous sump pump operation.</p> <p>Check: Water flow rate, leaking drain, faulty min level switch or wiring.</p>	A compressor lockout is generated on all circuits.	(PMR) A manual reset is required anytime after the diagnostic is set to re-enable compressor operation. The diagnostic can be reset by the Human Interface or Tracer, or by cycling power to the RTM.
<p>Cond Temp Sensor Failure (Ckt-1 or Ckt-2)</p> <p>Used With: DX cooling w/ air cooled condensers.</p> <p>Module: MCM</p>	<p>Problem: The saturated condenser temperature sensor input is out of range for the given circuit.</p> <p>Check: Wiring from the MCM to the temperature sensor. Removing the plug from the MCM there should be no shorts or opens on the wires, readings should be between 830 ohms and 345k ohms.</p>	All compressors on the associated circuit will be locked out and prevented from operation.	(PAR) An automatic reset occurs after the Condenser Temp Sensor input returns to its allowable range within 10 seconds.
<p>Dirty Filter</p> <p>Module: RTM</p>	<p>Problem: The dirty filter switch input on the RTM has closed for more than 60 continuous seconds.</p> <p>Check: Dirty filters, shorted wiring, failed switch, tubing.</p>	An Information Only Diagnostic is set.	(INFO) An automatic reset occurs after the Dirty Filter input reopens for 60 continuous seconds.
<p>Dirty Final Filter</p> <p>Module: RTMS</p>	<p>Problem: The dirty final filter switch input on the RTM has closed for more than 60 continuous seconds.</p> <p>Check: Dirty filters, shorted wiring, failed switch, tubing.</p>	An Information Only diagnostic is set.	(INFO) An automatic reset occurs after the Recovery Filter proving switch input reopens for 60 continuous seconds.
<p>Dirty Recovery Filter</p> <p>Module: MPM</p>	<p>Problem: The dirty recovery filter switch input on the MPM has closed for more than 60 continuous seconds.</p> <p>Check: Dirty filters, shorted wiring, failed switch, tubing.</p>	An Information Only diagnostic is set.	(INFO) An automatic reset occurs after the Recovery Filter proving switch input reopens for 60 continuous seconds.

Table 11: Diagnostics Troubleshooting Chart (continued)

DIAGNOSTIC DISPLAYED	REASON FOR DIAGNOSTIC	UCM'S REACTION	RESET REQUIRED
ECEM Communications Failure Module: ECEM	Problem: The RTM has lost communications with the ECEM. Check: Wiring between the communications terminal block and the ECEM. Check for polarity, crimp and wire integrity of the pins.	On units w/ Comparative Enthalpy option, the Economizer Enable Enthalpy function will revert to Reference Enthalpy or Drybulb comparison. On units w/ Statitrac option, the space pressure control is deactivated, the exhaust fan is turned off, the exhaust damper is closed and the outside damper is limited to minimum position.	(PAR) An automatic reset occurs after communication has been restored.
Economizer DryBulb Setpoint Failure Module: GBAS(5VDC/10VDC)	Problem: The GBAS input assigned to <i>Economizer DryBulb Setpoint</i> is out of range. (Temperature <50 F or Temperature > 140 F) Check: Wiring and external devices on the associated GBAS input.	The <i>Active Economizer DryBulb Setpoint</i> reverts to the HI default <i>Economizer DryBulb Enable Setpoint</i> value.	(PAR) An automatic reset occurs after the GBAS input returns to within range for 10 continuous seconds, or after a different valid <i>Economizer DryBulb Enable Setpoint</i> source selection is user-defined.
Emergency Stop Module: RTM	Problem: The circuit wired to the Emergency Stop Input has opened. This can occur by design or unintentionally. Check: An open circuit has occurred on the Emergency Stop input caused either by a High Duct Temp T-stat trip, the opening of field-provided contacts, etc., or due to a fault of the wiring or external devices.	The unit will trip all outputs, de-energize dx cooling, staged heating, fans, etc., and will drive all analog outputs closed/stop, fan speed, dampers, modulating heat, etc.	(PMR) A manual reset is required after the Emergency Stop input recloses. The Diagnostic can be reset by the Human Interface or Tracer or by cycling power to the RTM.

DIAGNOSTICS Menu

Table 11: Diagnostics Troubleshooting Chart (continued)

DIAGNOSTIC DISPLAYED	REASON FOR DIAGNOSTIC	UCM'S REACTION	RESET REQUIRED
<p>Energy Recovery Wheel Proof Failure</p> <p>Module: MPM</p>	<p>Problem: Comparison of the <i>Leaving Recovery Exhaust Temp</i> and <i>Return Air Temp</i> indicates inadequate temperature differential exists which could be caused by improper energy recovery wheel operation.</p> <p>Check: Wheel operation, dirty wheel material, temperature sensor integrity.</p>	<p>Energy Wheel output is de-energized and associated dampers closed while in heat mode. In cooling mode the dampers will still open during economizing operation.</p>	<p>(PMR) A manual reset is required anytime after the Diagnostic is set. The Diagnostic can be reset by the Human Interface or Tracer, or by cycling power to the RTM.</p>
<p>Entering Evaporator Temperature Sensor Failure (Ckt-1 or Ckt-2)</p> <p>Used With: DX cooling.</p> <p>Module: MCM</p>	<p>Problem: The <i>Entering Evap Temp Sensor</i> input for the given circuit is out of range. (Temperature < -55 F or Temperature > 209 F)</p> <p>Check: The HI value and wiring between the MCM and specific sensor. Removing the plug from the MCM there should be no shorts, opens and sensor resistance should be between 830 ohms and 345.7Kohms.</p>	<p>The <i>Low Charge Protection</i> function (either Ckt-1 or Ckt-2) is disabled on units with that function and all compressors on the given circuit will be locked out and prevented from operating.</p>	<p>(PAR) An automatic reset occurs after the entering Evaporator Temperature Sensor input returns to within range continuously for 10 seconds.</p>
<p>Evaporator Temperature Sensor Failure (Ckt-1 and Ckt-2)</p> <p>Used With: DX cooling.</p> <p>Module: MCM</p>	<p>Problem: The <i>Evap Temp Sensor</i> input for the given circuit is out of range. (Temperature < -55 F or Temperature > 209 F)</p> <p>Check: The HI value and wiring between the MCM and specific sensor. Removing the plug from the MCM there should be no shorts, opens and sensor resistance should be between 830 ohms and 345.7Kohms.</p>	<p>The <i>Coil Frost Protection</i> function for the given refrigeration is disabled. The <i>Low Charge Protection</i> function (either Ckt-1 or Ckt-2) is disabled on units with that function and all compressors on the given circuit will be locked out and prevented from operating.</p>	<p>(PAR) An automatic reset occurs after the evaporator temperature input returns to its allowable range for 10 seconds.</p>

Table 11: Diagnostics Troubleshooting Chart (continued)

DIAGNOSTIC DISPLAYED	REASON FOR DIAGNOSTIC	UCM'S REACTION	RESET REQUIRED
<p>Excessive Outdoor Air</p> <p>Used With: FDD operation.</p> <p>Module: RTM/VSM</p>	<p>Problem: The voltage feedback from the OA Damper actuator indicates the damper has failed OPEN (> 10% of commanded value) during ventilation mode for 5 continuous minutes.</p> <p>Check: OA Damper apparatus for linkage binding or failure. Wiring/voltages between actuator and VSM. Wiring/voltages between the RTM and actuator.</p>	<p>None. Only an information diagnostic is annunciated.</p>	<p>(INFO) An automatic reset occurs when any of the following occurs: 1) the unit control has changed, or stopped, or 2) the feedback voltage has returned within its expected range.</p>
<p>Exhaust Fan Failure</p> <p>Used With: Power Exhaust w/ or w/o Statitrac option, and when Return Fan is not installed.</p> <p>Module: RTM</p>	<p>Problem: The unit has power exhaust and the exhaust proving switch input has been detected OPEN for 40 continuous seconds during any period of time in which the Exhaust Fan binary output is ON.</p> <p>Check: Check belts, linkages, etc. on the exhaust fan assembly. If these are ok, check field/unit wiring between RTM and exhaust fan. If exhaust fan will run in service mode, then verify airflow proving switch and wiring.</p>	<p>A "minimum position" request is issued to the Economizer Actuator Control function. And a "Fan off" request is issued to the Exhaust Fan Control function.</p> <p>Note: <i>On units with an exhaust fan installed, an ECEM Comm Fail diagnostic will also generate this diagnostic to insure the defined reaction is observed.</i></p>	<p>(PMR) A manual reset is required anytime after the Diagnostic is set. The Diagnostic can be reset by the Human Interface or Tracer, or by cycling power to the RTM.</p>

DIAGNOSTICS Menu

Table 11: Diagnostics Troubleshooting Chart (continued)

DIAGNOSTIC DISPLAYED	REASON FOR DIAGNOSTIC	UCM'S REACTION	RESET REQUIRED
<p>GBAS 0-5VDC Module Communications Failure</p> <p>Module: GBAS(5VDC)</p>	<p>Problem: The RTM has lost communications with the GBAS(5VDC) Module.</p> <p>Check: Check unit wiring between RTM and GBAS.</p>	<p>The UCM will initiate the following actions:</p> <ul style="list-style-type: none"> a. Any Demand Limit request issued by this GBAS will be canceled. The Demand Limit request may continue if the BAS/Network is requesting it. b. All active Setpoints that source this GBAS will revert to their Human Interface default values. c. A fail safe function in the GBAS module will cause all GBAS outputs to be zeroed and de-energized. 	<p>(PAR) An automatic reset occurs after communication has been restored.</p>
<p>GBAS 0-10 VDC Module Communications Failure</p> <p>Module: GBAS(10VDC)</p>	<p>Problem: The RTM has lost communications with the GBAS(10VDC) Module.</p> <p>Check: Check unit wiring between RTM and GBAS.</p>	<p>The UCM will initiate the following actions:</p> <ul style="list-style-type: none"> a. Any Demand Limit request issued by this GBAS will be canceled. The Demand Limit request may continue if the BAS/Network is requesting it. b. All active Setpoints that source this GBAS will revert to their Human Interface default values. c. A fail safe function in the GBAS module will cause all GBAS outputs to be zeroed and de-energized. 	<p>(PAR) An automatic reset occurs after one complete set of the required IPC packets has been received.</p>
<p>Heat AUX Temp Sensor Fail (formerly: MWU Zone Sensor Fail)</p> <p>Used With: Heat options.</p> <p>Module: HEAT</p>	<p>Problem: The Heat Module's <i>Auxiliary Temperature Sensor</i> has been assigned to at least one function, and this sensor signal is out of range (Temp < -55 F or Temp > 209 F).</p> <p>Check: The HI value and wiring between the HEAT module and the sensor. Removing the plug from the HEAT module there should be no shorts, opens and sensor resistance should be between 830 ohms and 345.7Kohms.</p>	<p>The functions that designated the Heat Module Auxiliary Temperature Input as their input are disabled.</p>	<p>(PAR) An automatic reset occurs after the Heat Module Auxiliary Temperature input returns to its allowable range for 10 seconds.</p>

Table 11: Diagnostics Troubleshooting Chart (continued)

DIAGNOSTIC DISPLAYED	REASON FOR DIAGNOSTIC	UCM'S REACTION	RESET REQUIRED
Heat Failure Module: HEAT	<p>Problem: The Gas or Electric heat controls has failed or has marginal performance and the Heat Fail Input has closed:</p> <ul style="list-style-type: none"> a. for more than 80 seconds, b. for 10 consecutive occurrences (each lasting 5 seconds or more) within a 210 second period. <p>(This is typically caused when the gas heater's igniter failed to light the gas, or because the electric heat section became too hot.)</p> <p>Check Gas Heat: External ignition controller, wiring, combustion fan motor and airflow operation, etc.</p> <p>Check Electric Heat: Wiring, sufficient airflow, etc.</p>	An Information Only diagnostic is set.	(INFO) An automatic reset occurs after the Heat Fail input remains open for 210 seconds continuously.
Heat Module Communication Failure Module: HEAT	<p>Problem: The RTM has lost communications with the HEAT module.</p> <p>Check: Check unit wiring between RTM and HEAT module.</p>	An "All Heat Off" request is sent to the heat operation function: <ul style="list-style-type: none"> a. On staged gas or electric heat units, all heat module outputs will be de-energized. b. On hydronic heat or chilled water units, the supply fan will be turned off, the outside air damper closed, hydronic/chill water valves will be driven to 100%, and the relay outputs will be controlled for proper signal routing to actuators. 	(PAR) An automatic reset occurs after communication has been restored.

DIAGNOSTICS Menu

Table 11: Diagnostics Troubleshooting Chart (continued)

DIAGNOSTIC DISPLAYED	REASON FOR DIAGNOSTIC	UCM'S REACTION	RESET REQUIRED
<p>High Comp Press Diff Failure (Ckt1 and Ckt2)</p> <p>Used With: Low Vi</p> <p>Module: MCM</p>	<p>Problem: An excessive compressor pressure differential condition has tripped the given refrigerant circuit 4 times before the call for mechanical cooling has terminated.</p> <p>Check: The condenser fan operation, condenser and evaporator temperature sensor values for proper readings and refrigerant charge. Check evaporator coil for airflow obstruction.</p>	<p>All compressors on the associated circuit will be locked out and prevented from operation.</p>	<p>(PMR) A manual reset is required anytime after the diagnostic is set to re-enable compressor operation. The diagnostic can be reset by the Human Interface or Tracer, or by cycling power to the RTM.</p>
<p>High Superheat (Ckt-1 or Ckt-2)</p> <p>Used With: DX cooling.</p> <p>Module: MCM</p>	<p>Problem: DX cooling operation has been active for 10 minutes on the given circuit, and the difference in the entering and leaving evaporator temperatures is:</p> <ul style="list-style-type: none"> a. less than the Evaporator Temperature Differential Setpoint for a period of ten minutes, and... b. greater than the <i>Evaporator Temperature Differential Setpoint</i> minus 5 F. <p>Check: Refrigerant. Sensor integrity.</p>	<p>An Information Only diagnostic is set.</p>	<p>(PAR) An automatic reset occurs after the difference in the entering and leaving evaporator temperature is less than the <i>Evaporator Temperature Differential Setpoint</i> minus 5 F.</p>
<p>Leaving Recovery Exhaust Temp Failure</p> <p>Used With: Energy Recovery Wheel option.</p> <p>Module: MPM</p>	<p>Problem: The <i>Leaving Recovery Exhaust Temp</i> sensor is out of range. (Temp < -55 F or Temp > 209 F)</p> <p>Check: The HI value and wiring between the MPM module and the sensor. Removing the plug from the MPM module there should be no shorts, opens and sensor resistance should be between 830 ohms and 345.7Kohms.</p>	<p>Exhaust Air Bypass Damper modulated fully closed if energy recovery for heating is active or if energy recovery is not active. If OA Damper is fully open Exhaust Air Bypass and Outside Air Bypass dampers modulated fully open when Outside Air Temp is 10F or less.</p>	<p>(PAR) An automatic reset occurs after the Leaving Recovery Exhaust Temp input returns to within range continuously for 10 seconds</p>

Table 11: Diagnostics Troubleshooting Chart (continued)

DIAGNOSTIC DISPLAYED	REASON FOR DIAGNOSTIC	UCM'S REACTION	RESET REQUIRED
<p>Low Air Temperature Limit Trip (formerly: Freezestat Trip)</p> <p>Used With: Hydronic or steam heat option, or w/ chilled water installed.</p> <p>Module: HEAT</p>	<p>Problem: The <i>Low Air Temperature Limit Trip</i> condition has been detected. This can occur if either of the following occurs:</p> <ul style="list-style-type: none"> a. the <i>Hydronic Heat Low Air Temperature Limit</i> input closes for > 1 second, or b. the <i>Chilled Water Low Air Temperature Limit</i> input opens for > 1 second. <p>Check: Proper outside air damper actuator/linkage setup.</p>	<p>The UCM will initiate the following actions;</p> <ul style="list-style-type: none"> a. An "Open All Water Valves" request is issued to the heat module function, causing any steam, hot water, or chilled water valves on the unit to open. b. An "All Heat OFF" request is issued to the heat control function. c. A "Fan Off" request is sent to the supply fan and the return fan control functions. d. A "Close Damper" request is sent to the outside air damper control function. 	<p>(PMR) A manual reset is required after the Low Air Temperature Limit Trip condition clears. The Diagnostic can be reset at the unit mounted Human Interface, by Tracer, or by cycling power to the RTM.</p>
<p>Low Pressure Control Open (Ckt-1 or Ckt-2)</p> <p>Used With: DX cooling.</p> <p>Module: MCM</p>	<p>Problem: The <i>LPC Switch Input</i> on the given circuit is detected open for at least 6 seconds.</p> <p>Check: State of refrigerant charge for the given circuit.</p>	<p>A "Lockout Circuit" request is issued to the given circuit's compressor staging control function.</p>	<p>(PMR) A manual reset is required anytime after the Diagnostic is set. The Diagnostic can be reset by the Human Interface or Tracer, or by cycling power to the RTM.</p>
<p>Low Refrigerant Charge (Ckt-1 or Ckt-2)</p> <p>Used With: DX cooling.</p> <p>Module: MCM</p>	<p>Problem: The cooling circuit of interest has been active for 10 minutes and the difference in the entering and leaving evaporator temperatures has been greater than the <i>Evaporator Temperature Differential Setpoint</i> for 10 continuous minutes.</p> <p>Check: Refrigerant charge, temperature sensor values.</p>	<p>A "Lockout" request is issued to the given circuit's compressor Staging Control Function.</p>	<p>(PMR) A manual reset is required anytime after the Diagnostic is set. The Diagnostic can be reset by the Human Interface or Tracer, or by cycling power to the RTM."</p>

DIAGNOSTICS Menu

Table 11: Diagnostics Troubleshooting Chart (continued)

DIAGNOSTIC DISPLAYED	REASON FOR DIAGNOSTIC	UCM'S REACTION	RESET REQUIRED
<p>Manual Reset Return Pressure Limit Trip</p> <p>Used With: Return Fan.</p> <p>Module: MPM</p>	<p>Problem: The return plenum pressure has exceeded the Return Plenum Pressure High Limit (3.5 IWC).</p> <p>Check: Check return plenum pressure, exhaust/return damper actuators, return pressure transducer assembly and wiring, etc.</p>	<p>The unit will trip all outputs, de-energize dx cooling, staged heating, fans, etc., and will drive all analog outputs closed/stop, fan speed, dampers, modulating heat, etc.</p>	<p>(PMR) A manual reset is required anytime after the Diagnostic is set. The Diagnostic can be reset by the Human Interface or Tracer, or by cycling power to the RTM.</p>
<p>Manual Reset Supply Air Static Pressure Limit</p> <p>Used With: VVDA units, or CVDA/CVZT units with supply air pressure sensor installed.</p> <p>Module: RTM</p>	<p>Problem: The supply air pressure has exceeded the Supply Air Pressure High Limit Setpoint the 3rd consecutive time while the unit is operating in any mode.</p> <p>Check: Supply air ductwork, supply fan speed control, supply air pressure transducer assembly and wiring.</p>	<p>A "Supply Air Pressure Shutdown" signal is sent to the following functions:</p> <ol style="list-style-type: none"> Compressor Staging Control, Economizer Actuator Control, Heat Operation, Supply Fan/Return Fan Control, IGV / VFD Control, Exhaust Fan Control Exhaust Actuator Control 	<p>(PMR) A manual reset is required and can be accomplished at the Human Interface or by Tracer, or by cycling the power to the RTM.</p>
<p>Manual Reset Space Press Low Limit Trip</p> <p>Used With: Return Fan w/ Statitrac.</p> <p>Module: RTM</p>	<p>Problem: The building's space pressure has dropped below the <i>Building Pressure Low Limit Setpoint</i> for the 3rd time without the building pressure ever rising above <i>Building Pressure Setpoint</i> bottom deadband.</p> <p>Check: Check return plenum pressure, exhaust/return damper actuators, etc.</p>	<p>The unit will trip all outputs, de-energize dx cooling, staged heating, fans, etc., and will drive all analog outputs closed/stop, fan speed, dampers, modulating heat, etc.</p>	<p>(PMR) A manual reset is required anytime after the Diagnostic is set. The Diagnostic can be reset by the Human Interface or Tracer, or by cycling power to the RTM.</p> <p>Note: See Auto Reset Space Press Low Limit Trip Above.</p>
<p>MCM Communications Failure</p> <p>Module: MCM</p>	<p>Problem: The RTM has lost communications with the MCM module.</p> <p>Check: Check unit wiring between RTM and MCM module.</p>	<p>A "Lockout" request is sent to the Compressor Staging Control function. And a fail-safe function in the MCM will cause all MCM outputs to be zeroed and de-energized.</p>	<p>(PAR) An automatic reset occurs after communication has been restored.</p>

Table 11: Diagnostics Troubleshooting Chart (continued)

DIAGNOSTIC DISPLAYED	REASON FOR DIAGNOSTIC	UCM'S REACTION	RESET REQUIRED
MDM Communications Failure Module: MDM	Problem: The RTM has lost communications with the MDM module. Check: Check unit wiring between RTM and MDM module.	All active commands and setpoints provided by the MDM module will be canceled and/or ignored. All binary outputs will be de-energized and analog output set to fail-safe. Dehumidification control function is disabled and a compressor lockout request is issued for the Reheat Circuit (IPak:Ckt-2, IPakII:Ckt-1)	(PAR) An automatic reset occurs after one complete set of the required IPC packets has been received.
MPM Communications Failure Module: MPM	Problem: The RTM has lost communications with the MPM module. Check: Check unit wiring between RTM and MPM module.	a. All active commands provided by the MPM module will be canceled and/or ignored. Return fan control function is disabled and a "Unit Shutdown" request is issued. b. For evaporative condensing units, a lockout request is issued, for all circuits, to the compressors staging control function.	(PAR) An automatic reset occurs after one complete set of the required IPC packets has been received.
Minimum Outdoor Air Flow Setpoint Failure Used With: Fresh Air Measurement (VCM) option. Module: VCM	Problem: The GBAS input assigned to <i>Minimum Outdoor Air Flow Setpoint</i> is out of range. (OAFlowStp is < 0 or OAFlowStp > Max Unit Airflow ¹ Check: Wiring and external devices on the associated GBAS input. ¹ See Setpoints menu <i>Min OA Flow Setpoint</i> for max unit airflows table.	The <i>Active Minimum OA Flow Setpoint</i> reverts to the default <i>Minimum OA Flow Setpoint</i> of the Human Interface.	(PAR) An automatic reset occurs after the Minimum OA Flow Setpoint input returns to within range for 10 continuous seconds, or after a different, valid <i>Active Minimum OA Flow Setpoint</i> value is specified (BAS/Network).
Mode Input Failure Module: RTM	Problem: The RTM Mode input is out of range. (R < 1k ohm or R > 40k ohm) Check: Mode input resistance should be between 1 Kohm and 40 Kohms. If so, check field/unit wiring between Sensor and RTM.	The system mode reverts to the default (HI set) System Mode.	(INFO) An automatic reset occurs after the Mode input returns to its allowable range for 10 seconds.

DIAGNOSTICS Menu

Table 11: Diagnostics Troubleshooting Chart (continued)

DIAGNOSTIC DISPLAYED	REASON FOR DIAGNOSTIC	UCM'S REACTION	RESET REQUIRED
Morning Warmup Setpoint Failure Module: RTM	Problem: The GBAS input assigned to <i>MWU Setpoint</i> is out of range (Temp < 50 F or Temp > 90 F). Check: Wiring and external devices on the associated GBAS input.	The <i>Active MWU Setpoint</i> reverts to the default <i>MWUSetpoint</i> from the Human Interface.	(PAR) An automatic reset occurs after the GBAS input assigned to the <i>MWU Setpoint</i> input returns to within range for 10 continuous seconds, or after a different, valid <i>MWU Setpoint</i> source is applied (BAS/Network).
NSB Panel Communication Failure Module: NSB Panel	Problem: The RTM has lost communications with the NSB Panel (Night SetBack Panel or programmable zone sensor). Check: Check field/unit wiring between RTM and NSB Panel.	a. The unit reverts to the next lower priority mode switching source (typically the HI default mode). b. if the NSB Panel Zone Sensor is the designated sensor source for any functions, those functions are disabled.	(PAR) An automatic reset occurs after communication has been restored.
NSB Panel Zone Temp Sensor Failure Module: NSB Panel	Problem: The <i>NSB Panel's</i> zone temp sensor input is out of range. (This input is at the <i>NSB Panel</i> , not on the Rooftop unit itself). Check: If an external sensor is connected to the <i>NSB Panel</i> zone sensor input the internal <i>NSB Panel</i> zone sensor should be disabled, therefore verify external sensor's resistance. If in valid range, check wiring between sensor and the <i>NSB Panel</i> .	a. If the external sensor has failed the NSB will revert to its local value and no diagnostic will be generated. b. If the local sensor has failed also, or is the only sensor of the two being used, the unit will generate the diagnostic and set all of the associated functions to disabled.	(PAR) An automatic reset occurs after the NSB Panel's sensor returns to within range for 10 continuous seconds, or after a different, valid <i>Active Zone Temp Sensor</i> value is specified (BAS/Network).
OA Humidity Sensor Failure Used With: Comparative Enthalpy option. Module: RTM	Problem: The outside air humidity sensor data is out of range (Humidity < 10% or Humidity > 90%). Check: Check field/unit wiring between RTM and the sensor.	The Economizer Enable r.e Enthalpy function reverts to Dry-Bulb Temperature changeover ("Level 1") control.	(PAR) An automatic reset occurs after the OA Humidity input returns to its allowable range for 10 seconds.

Table 11: Diagnostics Troubleshooting Chart (continued)

DIAGNOSTIC DISPLAYED	REASON FOR DIAGNOSTIC	UCM'S REACTION	RESET REQUIRED
<p>OA Temperature Sensor Failure</p> <p>Used With: Comparative Enthalpy, DX cooling, Energy Recovery Wheel options.</p> <p>Module: RTM</p>	<p>Problem: The RTM <i>OA Temperature Sensor</i> has been assigned to at least one function, and this sensor signal is out of range (Temp < -55 F or Temp > 209 F).</p> <p>Check: The HI value and wiring between the RTM module and the sensor. Removing the plug from the RTM module there should be no shorts, opens and sensor resistance should be between 830 ohms and 345.7Kohms.</p>	<p>Unit functions that are disabled include:</p> <ol style="list-style-type: none"> Low Ambient CompressorLockout The Outside Air Damper drives to minimum position. On VAV units with SA Temp Reset type selected as OA Temp Reset, the Reset type reverts to NONE for the duration of the failure. 	<p>(PAR) An automatic reset occurs after the OA Temp input returns to its allowable range. In order to prevent rapid cycling of the Diagnostic, there is a 10 second delay before the automatic reset.</p>
<p>Occupied Dehumidification Setpoint Failure</p> <p>Module: RTM</p>	<p>Problem: The GBAS input assigned to <i>Occupied Dehumidification Setpoint</i> is out of range (Humidity < 10% or Humidity > 90%).</p> <p>Check: Wiring and external devices on the associated GBAS input.</p>	<p>The <i>Active Occupied Dehumidification Setpoint</i> reverts to the default <i>Occupied Dehumidification Setpoint</i> from the Human Interface.</p>	<p>(PAR) An automatic reset occurs after the GBAS input assigned to the <i>Occupied Dehumidification Setpoint</i> input returns to within range for 10 continuous seconds, or after a different, valid <i>Occupied Dehumidification Setpoint</i> source is applied (BAS/Network).</p>
<p>Occupied Humidification Setpoint Failure</p> <p>Module: RTM</p>	<p>Problem: The GBAS input assigned to <i>Occupied Humidification Setpoint</i> is out of range (Humidity < 10% or Humidity > 90%).</p> <p>Check: Wiring and external devices on the associated GBAS input.</p>	<p>The <i>Active Occupied Humidification Setpoint</i> reverts to the default <i>Occupied Humidification Setpoint</i> from the Human Interface.</p>	<p>(PAR) An automatic reset occurs after the GBAS input assigned to the <i>Occupied Humidification Setpoint</i> input returns to within range for 10 continuous seconds, or after a different, valid <i>Occupied Humidification Setpoint</i> source is applied (BAS/Network).</p>
<p>Occupied Zone Cool Setpoint Failure</p> <p>Used With: CVZT units.</p> <p>Module: RTM</p>	<p>Problem: The source assigned to <i>Occupied Zone Cool Setpoint</i> is out of range (Temperature < 45 F or Temperature > 94 F).</p> <p>Check: Wiring and external devices on the associated RTM input.</p>	<p>The <i>Active Occupied Zone Cooling Setpoint</i> reverts to the default <i>Occupied Zone Cooling Setpoint</i> of the Human Interface.</p>	<p>(PAR) An automatic reset occurs after the source input assigned to the <i>Occupied Zone Cooling Setpoint</i> input returns to within range for 10 continuous seconds, or after a different, valid <i>Occupied Zone Cooling Setpoint</i> source is applied (BAS/Network).</p>

DIAGNOSTICS Menu

Table 11: Diagnostics Troubleshooting Chart (continued)

DIAGNOSTIC DISPLAYED	REASON FOR DIAGNOSTIC	UCM'S REACTION	RESET REQUIRED
<p>Occupied Zone Heat Setpoint Failure</p> <p>Used With: CVZT units, VVDA/CVDA units w/DWU option.</p> <p>Module: RTM</p>	<p>Problem: The source assigned to <i>Occupied Zone Heat Setpoint</i> is out of range (Temperature < 45 F or Temperature > 94 F).</p> <p>Check: Wiring and external devices on the associated RTM input.</p>	<p>The <i>Active Occupied Zone Heating Setpoint</i> reverts to the default <i>Occupied Zone Heating Setpoint</i> of the Human Interface.</p>	<p>(PAR) An automatic reset occurs after the source input assigned to the <i>Occupied Zone Heating Setpoint</i> input returns to within range for 10 continuous seconds, or after a different, valid <i>Occupied Zone Heating Setpoint</i> source is applied (BAS/Network).</p>
<p>Outdoor Air Damper Not Modulating</p> <p>Used With: FDD operation.</p> <p>Module: RTM/VSM</p>	<p>Problem: The voltage feedback from the OA Damper actuator indicates the damper has failed CLOSED (< 10% of commanded value) during ventilation mode for 5 continuous minutes.</p> <p>Check: OA Damper apparatus for linkage binding or failure. Wiring/voltages between actuator and VSM. Wiring/voltages between the RTM and actuator.</p>	<p>None. Only an information diagnostic is annunciated.</p>	<p>(INFO) An automatic reset occurs when any of the following occurs: 1) the unit control has changed, or stopped, or 2) the feedback voltage has returned within its expected range.</p>
<p>RTM Auxiliary Temperature Sensor Failure</p> <p>Module: RTM</p>	<p>Problem: The <i>RTM Aux Temperature Sensor</i> has been assigned to at least one function, and this sensor signal is out of range (Temp < -55 F or Temp > 209 F).</p> <p>Check: The HI value and wiring between the RTM module and the sensor. Removing the plug from the RTM module there should be no shorts, opens and sensor resistance should be between 830 ohms and 345.7Kohms.</p>	<p>The functions with the <i>RTM Aux Temperature</i> input designated as their sensor are disabled.</p>	<p>(PAR) An automatic reset occurs after the designated temperature input returns to its allowable range. In order to prevent rapid cycling of the diagnostic, there is a 10 seconds delay before the automatic reset.</p>

Table 11: Diagnostics Troubleshooting Chart (continued)

DIAGNOSTIC DISPLAYED	REASON FOR DIAGNOSTIC	UCM'S REACTION	RESET REQUIRED
<p>RTM Space Humidity Sensor Failure</p> <p>Used With: Dehumidification or Humidification option.</p> <p>Module: RTM</p>	<p>Problem: The RTM space humidity sensor data is out of range (Humidity < 1% or Humidity > 100%).</p> <p>Check: Check field/unit wiring between RTM and the sensor.</p>	<p>The dehumidification and humidification functions are disabled if the <i>RTM Space Humidity Sensor</i> is selected as sensor source for these functions.</p>	<p>(PAR) An automatic reset occurs after the <i>RTM Space Humidity Sensor</i> input returns to within range continuously for 10 seconds.</p>
<p>RTM Zone Temperature Sensor Failure</p> <p>Module: RTM</p>	<p>Problem: The <i>RTM Zone Temperature Sensor</i> has been assigned to at least one function, and this sensor signal is out of range (Temp < -55 F or Temp > 209 F).</p> <p>Check: The HI value and wiring between the RTM module and the sensor. Removing the plug from the RTM module there should be no shorts, opens and sensor resistance should be between 830 ohms and 345.7Kohms.</p>	<p>The functions with the <i>RTM Zone Temperature Sensor</i> input designated as their sensor are disabled.</p>	<p>(PAR) An automatic reset occurs after the designated temperature signal returns to its allowable range. In order to prevent rapid cycling of the diagnostic, there is a 10 second delay before the automatic reset.</p>
<p>RA Humidity Sensor Failure</p> <p>Used With: Dehumidification or Humidification option, or Comparative Enthalpy installed.</p> <p>Module: ECEM</p>	<p>Problem: The return air humidity sensor data is out of range (Humidity < 10% or Humidity > 90%).</p> <p>Check: Check field/unit wiring between ECEM and the sensor.</p>	<p>The Economizer Enable r.e. Enthalpy function reverts to Reference Enthalpy changeover ("Level 2") control.</p>	<p>(PMR) An automatic reset occurs after the RA Humidity input returns to its allowable range continuously for 10 seconds.</p>
<p>Rapid Restart HW Configuration Failure</p> <p>Used With: Rapid Restart.</p> <p>Module: RTM</p>	<p>Problem: The GBAS(5VDC) hardware configuration module or input has failed, or has been changed since the last power cycle.</p> <p>Check: The wire harness, the GBAS(5VDC) config module input. Refer to the Human Interface GBAS(5VDC) status screen for proper index value.</p>	<p>The unit will not honor the Rapid Restart start sequence. Normal unit start times and DX interstage will be honored.</p>	<p>(PAR) An automatic reset occurs after the user has accessed and followed the instructions on the Human Interface Rapid Restart configuration menu. Press + or - key then press the ENTER key to reset the configuration. Power down the unit, troubleshoot then power up the unit and return to this screen for verification.</p>

DIAGNOSTICS Menu

Table 11: Diagnostics Troubleshooting Chart (continued)

DIAGNOSTIC DISPLAYED	REASON FOR DIAGNOSTIC	UCM'S REACTION	RESET REQUIRED
<p>Return Air Temperature Sensor Failure</p> <p>Used With: Comparative Enthalpy installed, or Energy Recovery Wheel option.</p> <p>Module: ECEM</p>	<p>Problem: The ECEM <i>RA Temperature Sensor</i> has been assigned to at least one function, and this sensor signal is out of range (Temp < -55 F or Temp > 209 F).</p> <p>Check: The HI value and wiring between the ECEM module and the sensor. Removing the plug from the ECEM module there should be no shorts, opens and sensor resistance should be between 830 ohms and 345.7Kohms.</p>	<p>The Economizer Enable r.e. Enthalpy function reverts to Reference Enthalpy changeover ("Level 2") control.</p>	<p>(PAR) An automatic reset occurs after the RA Temperature input returns to its allowable range continuously for 10 seconds.</p>
<p>Return Fan failure</p> <p>Module: RTM</p>	<p>Problem: The return fan proving input is detected OPEN for 40 continuous seconds during any period of time in which the return fan relay is ON.</p> <p>Check: The return fan drive and belt. Faulty wiring with the return fan proving switch circuit.</p> <p>Note: <i>A communications error from the MPM will also cause a return fan failure lockout.</i></p>	<p>The unit will trip all outputs, de-energize dx cooling, staged heating, fans, etc., and will drive all analog outputs closed/stop, fan speed, dampers, modulating heat, etc.</p>	<p>(PMR) A manual reset is required anytime after the diagnostic is set. The diagnostic can be reset by the Human Interface or Tracer, or by cycling power to the RTM.</p>

Table 11: Diagnostics Troubleshooting Chart (continued)

DIAGNOSTIC DISPLAYED	REASON FOR DIAGNOSTIC	UCM'S REACTION	RESET REQUIRED
<p>Return Plenum Pressure Sensor Failure</p> <p>Used With: Return Fan option.</p> <p>Module: MPM</p>	<p>Problem: The return plenum pressure sensor input is out of range and one of the following is occurring</p> <ul style="list-style-type: none"> a. The return plenum pressure sensor value has risen above +3.5 IWC b. The return fan is on, the return fan speed is 100%, and the return plenum pressure sensor value has fallen below -0.75 IWC. b. The return fan is off and the return plenum pressure sensor value has fallen below -0.75 IWC. <p>Check: Return pressure transducer assembly, tubing and wiring. Return fan drive and belt. Wiring between the MPM and sensor.</p>	<p>The unit will trip all outputs, de-energize dx cooling, staged heating, fans, etc., and will drive all analog outputs closed/stop, fan speed, dampers, modulating heat, etc.</p>	<p>(PAR) An automatic reset occurs after the return plenum pressure input returns to within range for 10 continuous seconds.</p>
<p>Rooftop Module Data Storage Error</p> <p>Used With: All units.</p> <p>Module: RTM</p>	<p>Problem: There is an older version Human Interface (prior to 32.xx) installed in the unit or There was a data transmission error.</p> <p>Check:</p> <ul style="list-style-type: none"> a. Make sure the proper Human Interface version is installed in the unit. b. This can also be caused by an intermittent power loss. Turn the unit off for 1-2 minutes, then back on again. If diagnostic persists, then the RTM may need to be replaced. 	<p>The diagnostic will be displayed at the top level status screen, and unit operation will be prevented.</p>	<p>(PMR) A manual reset is required anytime after the diagnostic is set. The diagnostic can be reset by the Human Interface or Tracer, or by cycling power to the RTM.</p>
<p>SCM Communications Failure</p> <p>Module: SCM</p>	<p>Problem: The RTM has lost communications with the SCM.</p> <p>Check: Check unit wiring between RTM and SCM module.</p>	<p>A "Lockout" request is sent to the compressor staging control function. And a fail-safe function in the SCM will cause all SCM outputs to be zeroed and de-energized.</p>	<p>(PAR) An automatic reset occurs after communication has been restored.</p>

DIAGNOSTICS Menu

Table 11: Diagnostics Troubleshooting Chart (continued)

DIAGNOSTIC DISPLAYED	REASON FOR DIAGNOSTIC	UCM'S REACTION	RESET REQUIRED
<p>SZVAV HW Configuration Failure</p> <p>Used With: SZVAV units.</p> <p>Module: RTM</p>	<p>Problem: The GBAS(5VDC) hardware configuration module or input has failed, or has been changed since the last power cycle.</p> <p>Check: the wire harness, the GBAS(5VDC) config module input. Refer to the Human Interface GBAS(5VDC) status screen for proper index value.</p>	<p>The unit will not honor the Single Zone VAV control sequence. The unit will perform normal Zone Temperature control (CVZT).</p>	<p>(PAR) An automatic reset occurs after the user has accessed and followed the instructions on the Human Interface SZVAV configuration menu. Press + or - key then press the ENTER key to reset the configuration. Power down the unit, troubleshoot then power up the unit and return to this screen for verification.</p>
<p>Space Press Low Limit Trip Auto Reset</p> <p>Used With: Return Fan w/ Statitrac.</p> <p>Module: RTM</p>	<p>Problem: The building's space pressure has dropped below the <i>Building Pressure Low Limit Setpoint</i> for the 1st or 2nd time out of 3 occurrences</p> <p>Check: Check return plenum pressure, exhaust/return damper actuators, etc.</p>	<p>The unit will trip all outputs, de-energize dx cooling, staged heating, fans, etc., and will drive all analog outputs closed/stop, fan speed, dampers, modulating heat, etc.</p>	<p>(PAR) An auto reset occurs when the building's space pressure has risen above the Building Pressure Low Limit Setpoint plus .02 IWC.</p> <p>Note: Each occurrence will increment a counter which upon the third occurrence will generate a manual reset diagnostic. The counter will be cleared if the building pressure ever exceeds the building pressure setpoint bottom deadband.</p>
<p>Space Press Low Limit Trip Warning</p> <p>Used With: Return Fan w/ Statitrac.</p> <p>Module: RTM</p>	<p>Problem: The building's space pressure has dropped below the <i>Building Pressure Low Limit Setpoint</i> plus 0.02 IWC.</p> <p>Check: Check return plenum pressure, exhaust/return damper actuators, etc.</p>	<p>Information only.</p>	<p>(PAR) An auto reset occurs when the building's space pressure has risen above the Building Pressure Low Limit Setpoint plus .03 IWC.</p>

Table 11: Diagnostics Troubleshooting Chart (continued)

DIAGNOSTIC DISPLAYED	REASON FOR DIAGNOSTIC	UCM'S REACTION	RESET REQUIRED
<p>Space Pressure Sensor Failure</p> <p>Used With: Power Exhaust w/Statitrac option (Building pressure control).</p> <p>Module: ECEM</p>	<p>Problem: The unit is reading a signal that is out of range for the <i>Space Pressure Sensor</i> transducer input (During calibration: V < 40 mV or V > 420 mV, During operational times: V < 40 mV or V > 0.75 V).</p> <p>Check: Check unit wiring between sensor and ECEM, and solenoid and ECEM. Check the transducer assembly tubing and operation of the calibration solenoid which should shunt the ambient pressure (Windbird) to both the high and low ports of the transducer for a duration of 1 sec. every minute.</p>	<p>The Space Pressure Control function is disabled, and the exhaust fan and the exhaust damper actuator are controlled as if the unit did not have Statitrac. Default exhaust enable point is used.</p>	<p>(PAR) An automatic reset occurs after the designated Space Pressure transducer sends a signal within range for 10 continuous seconds.</p>
<p>Space Static Pressure Setpoint Failure</p> <p>Used With: Power Exhaust w/Statitrac option (Building pressure control).</p> <p>Module: ECEM</p>	<p>Problem: The GBAS input assigned to the <i>Space Static Pressure Setpoint</i> is out of range (Input < 0.03 IWC or Input > 0.20 IWC).</p> <p>Check: The wiring between the GBAS input assigned to this setpoint and the external device.</p>	<p>The <i>Active Space Pressure Setpoint</i> will revert to the default <i>Space Pressure Setpoint</i> from the Human Interface.</p>	<p>(PAR) An automatic reset occurs after the source input assigned to the <i>Space Pressure Setpoint</i> input returns to within range for 10 continuous seconds, or after a different, valid <i>Space Pressure Setpoint</i> source is applied (BAS/Network).</p>
<p>Supply Air Pressure Sensor Failure</p> <p>Used With: VVDA.</p> <p>Module: RTM</p>	<p>Problem: The Supply Air Pressure sensor voltage input is out of range (Input < 40mV or Input > 4.75V)</p> <p>Check: Check field/unit wiring between Sensor and RTM.</p>	<p>The IGV will drive closed or supply fan speed to minimum, and the following functions are disabled;</p> <p>a. SA Pressure Control b. SA Static Pressure Limit</p>	<p>(PAR) An automatic reset occurs after the SA Pressure input returns to its allowable range for 10 seconds.</p>
<p>Supply Air Pressure Setpoint Failure</p> <p>Used With: VVDA.</p> <p>Module: RTM</p>	<p>Problem: The GBAS input assigned to the <i>Supply Air Pressure Setpoint</i> is out of range (Input < 1.0 IWC or Input > 4.3 IWC).</p> <p>Check: The wiring between the GBAS input assigned to this setpoint and the external device.</p>	<p>The default <i>Supply Air Pressure Setpoint</i> at the Human Interface will become the <i>Active Supply Air Pressure SETPOINT</i>.</p>	<p>(PAR) An automatic reset occurs after the source input assigned to the <i>Supply Air Pressure Setpoint</i> input returns to within range for 10 continuous seconds, or after a different, valid <i>Supply Air Pressure Setpoint</i> source is applied (BAS/Network).</p>

DIAGNOSTICS Menu

Table 11: Diagnostics Troubleshooting Chart (continued)

DIAGNOSTIC DISPLAYED	REASON FOR DIAGNOSTIC	UCM'S REACTION	RESET REQUIRED
<p>Supply Air Reheat Setpoint Failure</p> <p>Used With: Dehumidification option.</p> <p>Module: RTM</p>	<p>Problem: The GBAS input assigned to the <i>Supply Air Reheat Setpoint</i> is out of range (Temp < 60 F or Temp > 90 F).</p> <p>Check: The wiring between the GBAS input assigned to this setpoint and the external device.</p>	<p>The <i>Active Supply Air Reheat Setpoint</i> reverts to the default <i>Supply Air Reheat Setpoint</i> defined at the Human Interface.</p>	<p>(PAR) An automatic reset occurs after the source input assigned to the <i>Supply Air Reheat Setpoint</i> input returns to within range for 10 continuous seconds, or after a different, valid <i>Supply Air Reheat Setpoint</i> source is applied (BAS/Network).</p>
<p>Supply Air Temperature Cool Setpoint Failure</p> <p>Used With: VVDA.</p> <p>Module: RTM</p>	<p>Problem: The source assigned to <i>SA Temp Cool Setpoint</i> is out of range (Temp < 35 F or Temp > 95 F).</p> <p>Check: Wiring and external devices on the associated RTM input.</p>	<p>The <i>Active Supply Air Temp Cool Setpoint</i> reverts to the default <i>Supply Air Temp Cool Setpoint</i> defined at the Human Interface.</p>	<p>(PAR) An automatic reset occurs after the source input assigned to the <i>Supply Air Temp Cool Setpoint</i> input returns to within range for 10 continuous seconds, or after a different, valid <i>Supply Air Temp Cool Setpoint</i> source is applied (BAS/Network).</p>
<p>Supply Air Temperature Heat Setpoint Failure</p> <p>Used With: VVDA.</p> <p>Module: RTM</p>	<p>Problem: The source assigned to <i>SA Temp Heat Setpoint</i> is out of range (Temperature < 35 F or Temperature > 185 F).</p> <p>Check: Wiring and external devices on the associated RTM input.</p>	<p>The <i>Active Supply Air Temp Heat Setpoint</i> reverts to the default <i>Supply Air Temp Heat Setpoint</i> defined at the Human Interface.</p>	<p>(PAR) An automatic reset occurs after the source input assigned to the <i>Supply Air Temp Heat Setpoint</i> input returns to within range for 10 continuous seconds, or after a different, valid <i>Supply Air Temp Heat Setpoint</i> source is applied (BAS/Network).</p>
<p>Supply Air Temperature Sensor Failure</p> <p>Used With: All units.</p> <p>Module: RTM</p>	<p>Problem: The <i>RTM Supply Air Temperature Sensor</i> signal is out of range (Temp < -55 F or Temp > 209 F).</p> <p>Check: The HI value and wiring between the RTM module and the sensor. Removing the plug from the RTM module there should be no shorts, opens and sensor resistance should be between 830 ohms and 345.7Kohms.</p>	<p>These unit functions are disabled:</p> <ol style="list-style-type: none"> Supply Air Tempering Economizing On CV units, the Supply Air Temperature low limit function is disabled. On VAV units, the Supply Air Temperature Control heating and cooling functions are disabled. 	<p>(PAR) An automatic reset occurs after the designated Supply Air Temperature input returns to its allowable range. In order to prevent rapid cycling of the Diagnostic, there is a 10 second delay before the automatic reset.</p>

Table 11: Diagnostics Troubleshooting Chart (continued)

DIAGNOSTIC DISPLAYED	REASON FOR DIAGNOSTIC	UCM'S REACTION	RESET REQUIRED
<p>Supply Fan Failure</p> <p>Module: RTM</p>	<p>Problem: There is no supply irflow indication after the supply fan has been requested on. The supply airflow proving input is detected OPEN for 40 continuous seconds during any period of time in which the supply fan relay is ON. This input is ignored for up to 5 minutes after the supply fan is first started, until airflow is first detected.</p> <p>Check: Check belts, linkages, etc. on the Supply Fan assembly. If these are ok, check field/unit wiring between RTM and Supply Fan. If Supply Fan will run in service mode, then verify airflow proving switch and wiring.</p>	<p>"OFF or "Close" requests are issued as appropriate to the following functions:</p> <ul style="list-style-type: none"> a. Compressor staging/ Chilled Water control b. Heat operation c. Supply fan control and proof of operation. d. Return fan control and proof of operation. e. Exhaust fan control and proof of operation f. Exhaust actuator control g. Economizer actuator control h. IGV / VFD control 	<p>(PMR) A manual reset is required anytime after the Diagnostic is set. The Diagnostic can be reset by the Human Interface or Tracer, or by cycling power to the RTM.</p>
<p>Supply Fan Proving Failure</p> <p>Used With: Required w/ units with isolation dampers (fire dampers) installed to insure proper airflows and proving switch operation.</p> <p>Module: RTM</p>	<p>Problem: The unit has isolation dampers and the <i>Isolation Damper Interlock</i> function is set to ENABLED. When the supply fan is requested OFF the unit expects the proving input to OPEN and will prevent the supply fan relay on the RTM from turning on again if being requested to do so. If the switch does not open within 5 minutes this diagnostic will occur.</p> <p>Check: Check the supply fan airflow proving switch and wiring.</p>	<p>The unit will trip all outputs, de-energize dx cooling, staged heating, fans, etc., and will drive all analog ouputs closed/stop, fan speed, dampers, modulating heat, etc.</p>	<p>(PMR) A manual reset is required anytime after the Diagnostic is set. The Diagnostic can be reset by the Human Interface or Tracer, or by cycling power to the RTM.</p>

DIAGNOSTICS Menu

Table 11: Diagnostics Troubleshooting Chart (continued)

DIAGNOSTIC DISPLAYED	REASON FOR DIAGNOSTIC	UCM'S REACTION	RESET REQUIRED
<p>Unit HI Communications Failure</p> <p>Module: RTM</p>	<p>Problem: The RTM has lost communications with the Unit mounted (local) Human Interface (HI).</p> <p>Check: Field/unit wiring between RTM and Local HI.</p>	<p>A fail-safe function in the HI will:</p> <ul style="list-style-type: none"> a. disallow any interaction between the HI and the RTM or any other modules. b. render all HI keystrokes ineffective, and c. cause the following to be displayed on the unit-mounted HI display: LOCAL HI COMMUNICATIONS LOSS CHECK COMM LINK WIRING BETWEEN MODULES <p>(If the unit has a remote HI option, then on the remote HI module, this diagnostic will be reported and displayed as any other automatic reset diagnostic.)</p>	<p>(INFO) An automatic reset occurs after communication has been restored between the RTM and the HI. When the failure screen is cleared, the General display is restored and HI interaction with the interaction with the RTM is again permitted.</p>
<p>Unit Economizing When It Should Not</p> <p>Used With: FDD operation.</p> <p>Module: RTM/VSM</p>	<p>Problem: Problem: The voltage feedback from the OA Damper actuator indicates the damper has failed OPEN (> 10% of commanded value) during economizer cooling mode for 5 continuous minutes.</p> <p>Check: OA Damper apparatus for linkage binding or failure. Wiring/voltages between actuator and VSM. Wiring/voltages between the RTM and actuator.</p>	<p>None. Only an information diagnostic is annunciated.</p>	<p>(INFO) An automatic reset occurs when any of the following occurs: 1) the unit control has changed, or stopped, or 2) the feedback voltage has returned within its expected range.</p>

Table 11: Diagnostics Troubleshooting Chart (continued)

DIAGNOSTIC DISPLAYED	REASON FOR DIAGNOSTIC	UCM'S REACTION	RESET REQUIRED
<p>Unit Not Economizing When It Should</p> <p>Used With: FDD operation.</p> <p>Module: RTM/VSM</p>	<p>Problem: Problem: The voltage feedback from the OA Damper actuator indicates the damper has failed CLOSED (< 10% of commanded value) during economizer cooling mode for 5 continuous minutes.</p> <p>Check: OA Damper apparatus for linkage binding or failure. Wiring/voltages between actuator and VSM. Wiring/voltages between the RTM and actuator.</p>	<p>None. Only an information diagnostic is annunciated.</p>	<p>(INFO) An automatic reset occurs when any of the following occurs: 1) the unit control has changed, or stopped, or 2) the feedback voltage has returned within its expected range.</p>
<p>Unoccupied Dehumidification Setpoint Failure</p> <p>Module: RTM</p>	<p>Problem: The GBAS input assigned to <i>Unoccupied Dehumidification Setpoint</i> is out of range (Humidity < 10% or Humidity > 90%).</p> <p>Check: Wiring and external devices on the associated GBAS input.</p>	<p>The <i>Active Unoccupied Dehumidification Setpoint</i> reverts to the default Unoccupied Dehumidification Setpoint from the Human Interface.</p>	<p>(PAR) An automatic reset occurs after the GBAS input assigned to the <i>Unoccupied Dehumidification Setpoint</i> input returns to within range for 10 continuous seconds, or after a different, valid <i>Unoccupied Dehumidification Setpoint</i> source is applied (BAS/Network).</p>
<p>Unoccupied Humidification Setpoint Failure</p> <p>Module: RTM</p>	<p>Problem: The GBAS input assigned to <i>Unoccupied Humidification Setpoint</i> is out of range (Humidity < 10% or Humidity > 90%).</p> <p>Check: Wiring and external devices on the associated GBAS input.</p>	<p>The <i>Active Unoccupied Humidification Setpoint</i> reverts to the default Unoccupied Humidification Setpoint from the Human Interface.</p>	<p>(PAR) An automatic reset occurs after the GBAS input assigned to the <i>Occupied Humidification Setpoint</i> input returns to within range for 10 continuous seconds, or after a different, valid <i>Occupied Humidification Setpoint</i> source is applied (BAS/Network).</p>

DIAGNOSTICS Menu

Table 11: Diagnostics Troubleshooting Chart (continued)

DIAGNOSTIC DISPLAYED	REASON FOR DIAGNOSTIC	UCM'S REACTION	RESET REQUIRED
Unoccupied Zone Cool Setpoint Failure Module: RTM	Problem: The source assigned to <i>Unoccupied Zone Cool Setpoint</i> is out of range (Temperature < 45 F or Temperature > 94 F). Check: Wiring and external devices on the associated RTM input.	The <i>Active Unoccupied Zone Cooling Setpoint</i> reverts to the default <i>Unoccupied Zone Cooling Setpoint</i> of the Human Interface.	(PAR) An automatic reset occurs after the source input assigned to the <i>Unoccupied Zone Cooling Setpoint</i> input returns to within range for 10 continuous seconds, or after a different, valid <i>Unoccupied Zone Cooling Setpoint</i> source is applied (BAS/Network).
Unoccupied Zone Heat Setpoint Failure Module: RTM	Problem: The source assigned to <i>Unoccupied Zone Heat Setpoint</i> is out of range (Temperature < 45 F or Temperature > 94 F). Check: Wiring and external devices on the associated RTM input.	The <i>Active Unoccupied Zone Heating Setpoint</i> reverts to the default <i>Unoccupied Zone Heating Setpoint</i> of the Human Interface.	(PAR) An automatic reset occurs after the source input assigned to the <i>Unoccupied Zone Heating Setpoint</i> input returns to within range for 10 continuous seconds, or after a different, valid <i>Unoccupied Zone Heating Setpoint</i> source is applied (BAS/Network).
VCM Aux Temp. Sensor Failure. Module: VCM	Problem: At least one enabled unit function has the <i>VCM Aux Temperature Sensor</i> input designated as its sensor, and the signal is out of range (Temp < -40 F or Temp > 200 F). Check: The HI value and wiring between the VCM module and the sensor. Removing the plug from the VCM module there should be no shorts, opens and sensor resistance should be between 830 ohms and 345.7Kohms.	The functions with the <i>VCM Aux Temperature Sensor</i> input designated as their sensor are disabled.	(PAR) An automatic reset occurs after the designated temperature input returns to its allowable range. In order to prevent rapid cycling of the Diagnostic, there is a 10 seconds delay before the automatic reset.
VCM Communications Failure. Module: VCM	Problem: The RTM has lost communications with the VCM module. Check: Check unit wiring between RTM and VCM module.	Airflow measurement will be disabled and the unit will revert to the default <i>OA Damper Minimum Position</i> . CO ₂ sensor value will be disabled, DCV functionality will be disabled.	(PAR) An automatic reset occurs after communication has been restored.

Table 11: Diagnostics Troubleshooting Chart (continued)

DIAGNOSTIC DISPLAYED	REASON FOR DIAGNOSTIC	UCM'S REACTION	RESET REQUIRED
<p>Velocity Pressure Sensor Failure</p> <p>Used With: IPak I Fresh Air Measurement (VCM) option.</p> <p>Module: VCM</p>	<p>Problem: The velocity pressure input signal is out of range (During calibration: volts < 40 mV or volts > 420 mV, During operational times: volts < 40 mV or volts > 0.75 V).</p> <p>Check: Check unit wiring between sensor and VCM, and solenoid and VCM. Check the transducer assembly tubing and operation of the calibration solenoid which should shunt the differential pressure of the track sensor to both the high and low ports of the transducer for a duration of 1 sec. every minute.</p>	<p>Airflow measurement will be disabled and the unit will revert to <i>OA CFM Compensation Function</i> if enabled, or to the default <i>OA Damper Minimum Position</i>.</p>	<p>(PAR) An automatic reset occurs after the designated velocity pressure transducer sends a signal within range for 10 continuous seconds.</p>
<p>Velocity Pressure Sensor Failure (Left or Right)</p> <p>Note: "Left" and "Right" are the left side of the unit, or right side, relative to someone facing the control box of the unit.</p> <p>Used With: IPak II Fresh Air Measurement (VCM) option.</p> <p>Module: VCM</p>	<p>Problem: The velocity pressure input signal of the designated flow station is out of range (During calibration: volts < 40 mV or volts > 420 mV, During operational times: volts < 40 mV or volts > 0.75 V).</p> <p>Check: Check unit wiring between sensor and VCM, and solenoid and VCM. Check the transducer assembly tubing and operation of the calibration solenoid which should shunt the differential pressure of the track sensor to both the high and low ports of the transducer for a duration of 1 sec. every minute.</p>	<p>Airflow measurement will be disabled and the unit will revert to <i>OA CFM Compensation Function</i> if enabled, or to the default <i>OA Damper Minimum Position</i>.</p>	<p>(PAR) An automatic reset occurs after the designated velocity pressure transducer sends a signal within range for 10 continuous seconds.</p>
<p>VOM Communications Failure</p> <p>Module: VOM</p>	<p>Problem: The RTM has lost communications with the VOM module.</p> <p>Check: Check unit wiring between RTM and VOM module.</p>	<p>Ventilation override actions will not be allowed, and the VOM Output relay will be de-energized.</p>	<p>(PAR) An automatic reset occurs after communication has been restored.</p>

DIAGNOSTICS Menu

Table 11: Diagnostics Troubleshooting Chart (continued)

DIAGNOSTIC DISPLAYED	REASON FOR DIAGNOSTIC	UCM'S REACTION	RESET REQUIRED
VSM Communications Failure Module: VSM	Problem: The RTM has lost communications with the VSM module. Check: Check unit wiring between RTM and VSM module. Check VSM power supply input.	A "Lockout" request is sent to the Compressor Staging/Speed Control function for the variable speed compressor circuit. A fail-safe function in the MCM will cause the MCM variable speed command output to be zeroed.	(PAR) An automatic reset occurs after communication has been restored.

Module Input / Output Descriptions

Table 12. Module I/O Descriptions

UNIT MODULE	ANALOG INPUTS	ANALOG OUTPUTS	BINARY INPUTS	BINARY OUTPUTS
Human Interface Module (LHI or RHI)	<ul style="list-style-type: none"> None 	<ul style="list-style-type: none"> None 	<ul style="list-style-type: none"> None 	<ul style="list-style-type: none"> None
Rooftop Module (RTM)	<ul style="list-style-type: none"> Zone Temp Sensor S/A Temp Sensor O/A Temp Sensor Mode Input (from remote panel) Cooling Setpoint (from remote panel) Heating Setpoint (from remote panel) S/A Pressure Transducer O/A Humidity Sensor Aux Temp Sensor Economizer Min. Pos. Space Humidity Sensor 	<ul style="list-style-type: none"> O/A Damper Output IGV/VFD Outputs 	<ul style="list-style-type: none"> Emergency Stop Dehumidification Configuration Input External Auto/Stop Occupied/Unoccupied Supply Airflow Proof Dirty Filter VAV Changeover IntelliPak II Configuration Input Dirty Final Filter Exhaust/Return Airflow 	<ul style="list-style-type: none"> Occupied/Unoccupied Relay Alarm Relay Supply Fan Relay LED 1-4 Transistor Exhaust/return Fan Relay Humidification Relay

Table 12. Module I/O Descriptions (continued)

UNIT MODULE	ANALOG INPUTS	ANALOG OUTPUTS	BINARY INPUTS	BINARY OUTPUTS
Multiple Circuit Compressor Module (MCM)	<ul style="list-style-type: none"> Leaving Evap Temp Sensor (Ckt-1) Leaving Evap Temp Sensor (Ckt-2) Entering Evap Temp Sensor (Ckt-1) Entering Evap Temp Sensor (Ckt-2) Saturated Condenser Temp Sensor (Ckt-1) Saturated Condenser Temp Sensor (Ckt-2) Sump Water Temp (Ckt-1) 	<ul style="list-style-type: none"> Condenser Fan Speed (Low Ambient Ckt-1) Condenser Fan Speed (Low Ambient Ckt-2) 	<ul style="list-style-type: none"> Low Pressure Control (Ckt-1) Low Pressure Control (Ckt-2) Compressor Proving (Ckt-1) Compressor Proving (Ckt-2) Water Level Min Water Level Max Sump Pump Proving External Sump Drain Request Low VI Config 	<ul style="list-style-type: none"> Compressor Relay (K11) Compressor Relay (K12) Compressor Relay (K3) Compressor Relay (K4) Condenser Fan 1A Condenser Fan 1B Condenser Fan 2A Condenser Fan 2B Sump Pump ON/OFF Sump Heat ON/OFF Sump Fill Sump Drain
Heat Module (HEAT)	<ul style="list-style-type: none"> Morning Warmup Temperature Sensor (Heat Aux Temp) 	<ul style="list-style-type: none"> Modulating Heat / Chilled Water Actuator 	<ul style="list-style-type: none"> HW Freeze Status (Heat Fail w/ Staged) CW Freeze Status 	<ul style="list-style-type: none"> Heat 1 (K11) Relay Heat 2 (K12) Relay Heat 3 (K1) Relay
Exhaust/Comparative Enthalpy Module (ECEM)	<ul style="list-style-type: none"> Return Air Temperature Sensor Return Air Humidity Sensor Space Pressure 	<ul style="list-style-type: none"> Exhaust Fan Speed-Damper 	<ul style="list-style-type: none"> None 	<ul style="list-style-type: none"> Space Pressure Calibration Solenoid
Ventilation Control Module (VCM)	<ul style="list-style-type: none"> Front Velocity Pressure Transducer Back Velocity Pressure Transducer Auxiliary Temperature Space CO₂ Sensor 	<ul style="list-style-type: none"> Outside Air CFM (PCB Only) 	<ul style="list-style-type: none"> None 	<ul style="list-style-type: none"> Preheater Relay Pressure Calibration
Ventilation Override Module (VOM)		<ul style="list-style-type: none"> None 	<ul style="list-style-type: none"> VOM Mode A Contacts VOM Mode B Contacts VOM Mode C Contacts VOM Mode D Contacts VOM Mode E Contacts 	<ul style="list-style-type: none"> VOM Relay
Variable Speed Compressor Module (VSM)	<ul style="list-style-type: none"> None OA Damper Actuator feedback voltage. 	<ul style="list-style-type: none"> Variable Speed Compressor Command 	<ul style="list-style-type: none"> None 	<ul style="list-style-type: none"> None

DIAGNOSTICS Menu

Table 12. Module I/O Descriptions (continued)

UNIT MODULE	ANALOG INPUTS	ANALOG OUTPUTS	BINARY INPUTS	BINARY OUTPUTS
Generic BAS Module 5V (GBAS5)	<ul style="list-style-type: none"> • Configuration Module • Analog Input 1 • Analog Input 2 • Analog Input 3 • Analog Input 4 <p>Note:</p> <ol style="list-style-type: none"> 1. Each of these inputs can be configured as defined in GBAS(5VDC) input assignments. 2. No 2 inputs can be assigned to the same definition. 3. The min voltage (0.5vdc) is associated with the min range of the assigned setpoint. 4. The max voltage (4.5vdc) is associated with the max range of the assigned setpoint. 	<ul style="list-style-type: none"> • None 	<ul style="list-style-type: none"> • Binary Input 1 <p>Note: This input is designated as the GBAS5 Demand Limit Input</p>	<ul style="list-style-type: none"> • Binary Output 1 • Binary Output 2 • Binary Output 3 • Binary Output 4 • Binary Output 5 <p>Note: These outputs, when energized, indicated the diagnostic(s) assigned to them under GBAS5 output assignments are active.</p>
Generic BAS Module 10V (GBAS10)	<ul style="list-style-type: none"> • Analog Input 1 • Analog Input 2 • Analog Input 3 • Analog Input 4 <p>Note:</p> <ol style="list-style-type: none"> 1. Each of these inputs can be configured as defined in GBAS(10VDC) input assignments. 2. No 2 inputs can be assigned to the same definition. 3. The min voltage (0.5vdc) is associated with the min range of the assigned setpoint. 4. The max voltage (9.5vdc) is associated with the max range of the assigned setpoint. 	<ul style="list-style-type: none"> • Analog Output 1 • Analog Output 2 • Analog Output 3 • Analog Output 4 <p>Note:</p> <ol style="list-style-type: none"> 1. Each output can be configured as defined in GBAS(10VDC) analog output assignments. 2. The min voltage (0.5vdc) is associated with the min range of the assigned value. 3. The max voltage (9.5vdc) is associated with the max range of the assigned value. 	<ul style="list-style-type: none"> • Binary Input 1 <p>Note: This input is designated as the GBAS10 Demand Limit Input</p>	<ul style="list-style-type: none"> • Binary Output 1 <p>Note: This output, when energized, indicates the diagnostic(s) assigned to them under GBAS10 output assignments are active.</p>

Table 12. Module I/O Descriptions (continued)

UNIT MODULE	ANALOG INPUTS	ANALOG OUTPUTS	BINARY INPUTS	BINARY OUTPUTS
Multi-Purpose Module (MPM)	<ul style="list-style-type: none"> • Return Air Plenum Pressure • Liquid Line Pressure Ckt 1 • Liquid Line Pressure Ckt 2 • Leaving Recovery Temperature 	<ul style="list-style-type: none"> • Outdoor Air Bypass Damper • Exhaust Air Bypass Damper/Return Fan Speed 	<ul style="list-style-type: none"> • Dirty Recovery Filter 	<ul style="list-style-type: none"> • Energy Recovery Wheel • Return Air Plenum Pressure Calibration • Energy Recovery Preheat
Modulating Dehumidification Module (MDM)		<ul style="list-style-type: none"> • Reheat Valve Output (Phase A & B) • Cooling Valve Output (Phase A & B) 		<ul style="list-style-type: none"> • Reheat Pumpout Relay
Interprocessor Communications Bridge Module (IPCB)	<ul style="list-style-type: none"> • None 	<ul style="list-style-type: none"> • None 	<ul style="list-style-type: none"> • None 	<ul style="list-style-type: none"> • None

Index

A

Active Setpoints 6

B

BACnet® 6, 10

BAS 122, 123

BCI 10

C

Calibration and Offset Submenu
Screens 76

Comm3/4 6

Comm5 6

Commonly Used Acronyms 5

Communication Link Problems 120

Comparative Enthalpy 6

Compressor and Condenser Control
Service Test Setup Submenu
Screens 109

Compressor Modules 9

Compressor Protection Switch 6

Compressor Status Submenu
Screens 30

Condenser Pressure 6

CONFIGURATION Menu 98

Control Algorithm Parameters Setup
Submenu Screens 84

Control Band 7

Control Point 7

Controlling Sensor Status Submenu
Screens 45

Controlling Setpoint Status Submenu
Screens 40

D

Data Manipulation Keys
Overview 12

Deadband 7

Dehumid Ovrdr High Zone Temp 7

Dehumid Ovrdr Low Zone Temp 7

Demand Control Ventilation 7

Device Characteristics Setup
Submenu Screens 77

Diag. - BAS Module Comm. Fail 122

Diag. - BAS/Network Comm.
Fail 123

Diag. - Blocked Air Return Fail 123

Diag. - CO2 Sensor Fail 123

Diag. - Compressor Contactor
Fail 123

Diag. - Compressor Trip 124

Diag. - Cond. Press. Sensor Fail 124

Diag. - Cond. Sump Heat Fail

Manual 124

Diag. - Cond. Sump Max Level
Fail 125

Diag. - Cond. Sump Min Level Short
Cycle Fail 126

Diag. - Cond. Sump Min Level/Drain
Fail 125

Diag. - Cond. Sump Pump Fail
Manual 124

Diag. - Cond. Sump Temp. Sensor
Fail 125

Diag. - Dirty Filter 126

Diag. - Dirty Final Filter 126

Diag. - Dirty Recovery Filter 126

Diag. - ECEM Comm. Fail 127

Diag. - Economizer DryBulb Stpt
Fail 127

Diag. - Emergency Stop 127

Diag. - Energy Recovery Wheel Proof
Fail 128

Diag. - Entering Evap. Temp. Sensor
Fail 128

Diag. - Evap. Temp. Sensor Fail 128

Diag. - Exhaust Fan Fail 129

Diag. - GBAS(10VDC) Module Comm.
Fail 130

Diag. - GBAS(5VDC) Module Comm.
Fail 130

Diag. - Heat AUX(MWU) Temp.
Sensor Fail 130

Diag. - Heat Failure 131

Diag. - HEAT Module Comm.
Fail 131

Diag. - High Superheat 132

Diag. - Leaving Recovery Exhaust
Temp. Fail 132

Diag. - Low Air Temp. Limit
(Freezestat) Trip 133

Diag. - Low Press. Control Open 133

Diag. - Low Refrigerant Charge 133

Diag. - MCM Comm. Fail 134

Diag. - MDM Comm. Fail 135

Diag. - Min Outdoor Air Flow Stpt
Fail 135

Diag. - MODE Input Fail 135

Diag. - MPM Comm. Fail 135

Diag. - MWU Stpt Fail 136

Diag. - NSB Panel Comm. Fail 136

Diag. - NSB Panel Zone Temp. Sensor
Fail 136

Diag. - OA Humidity Sensor Fail 136

Diag. - OA Temp. Sensor Fail 137

Diag. - Occ. Dehumidification Stpt

Fail 137

Diag. - Occ. Humidification Stpt
Fail 137

Diag. - Occ. Zone Cool Stpt Fail 137

Diag. - Occ. Zone Heat Stpt Fail 138

Diag. - RA Humidity Sensor Fail 139

Diag. - Return Air Temp. Sensor
Fail 140

Diag. - Return Fan Fail 140

Diag. - Return Plenum Press. Sensor
Fail 141

Diag. - Return Press. Limit
Manual 134

Diag. - Return Press. Limit Trip -
Auto 122

Diag. - Rooftop Module Data Storage
Error 141

Diag. - RTM AUX Temp. Sensor
Fail 138

Diag. - RTM Space Humidity Sensor
Fail 139

Diag. - RTM Zone Temp. Sensor
Fail 139

Diag. - SA Static Press. Limit -
Auto 122

Diag. - SCM Comm. Fail 141

Diag. - Space Press. Low Limit
Auto 142

Diag. - Space Press. Low Limit
Manual 134

Diag. - Space Press. Low Limit
Warn 142

Diag. - Space Press. Sensor Fail 143

Diag. - Space Static Press. Stpt
Fail 143

Diag. - Supply Air Press. Sensor
Fail 143

Diag. - Supply Air Press. Stpt
Fail 143

Diag. - Supply Air Reheat Stpt
Fail 144

Diag. - Supply Air Static Press. Limit
Manual 134

Diag. - Supply Air Temp. Cool Stpt
Fail 144

Diag. - Supply Air Temp. Heat Stpt
Fail 144

Diag. - Supply Air Temp. Sensor
Fail 144

Diag. - Supply Fan Fail 145

Diag. - Supply Fan Proving Fail 145

Diag. - Unit HI Comm. Fail 146

Diag. - Unocc. Dehumidification Stpt
Fail 147

Diag. - Unocc. Humidification Stpt Fail 147
Diag. - Unocc. Zone Cool Stpt Fail 148
Diag. - Unocc. Zone Heat Stpt Fail 148
Diag. - VCM AUX Temp. Sensor Fail 148
Diag. - VCM Comm. Fail 148
Diag. - Velocity Press. Sensor Fail 149
Diag. - VOM Comm. Fail 149
DIAGNOSTICS Menu 116
Diagnostics Overview 122
Dry Bulb 7

E

ECEM 9, 127, 139, 140, 143, 151
Economizer Control Functions Setup Submenu Screens 60
Economizer Status Submenu Screens 35
Economizer Zone Temp Setpoint Suppression 7
Emergency Override - (Depressurize) 66
Emergency Override - (Fire) 67
Emergency Override - (Pressurize) 66
Emergency Override - (Purge) 66
Emergency Override - (Shutdown) 66
Emergency Override Definitions 66
Emergency Override Modes 16
Emergency Stop 7
Energy Recovery Control Service Test Setup Screens 108
Energy Recovery Status Submenu Screens 39
Energy Recovery Wheel 7
Evaporator Differential (Evap Diff) 7
Exhaust/Comparative Enthalpy Module 9
External Stop 7

F

Factory Presets List 17
Figure 1 - Human Interface Module 11
Figure 2 - Human Interface Keypad 14

G

GBAS 127, 130, 152
GBAS(10VDC) 10
GBAS(10VDC) I/O Assignments Screens 72
GBAS(10VDC) Status Submenu 52
GBAS(5VDC) 10
GBAS(5VDC) I/O Assignments Screens 71
GBAS(5VDC) Status Submenu Screens 51
General Status Display Overview 13
General System Status Screens 26
General Unit Functions Setup Submenu Screens 54
Generic Building Automation System 10
Glossery Of Terms 6

H

Head Pressure Control Setup Submenu Screens 60
HEAT 9, 130, 131, 133, 151
Heat Module 9
Hot Gas Bypass 7
Human Interface Module 10
Humidification Control 7
Humidity Control Submenu Screens 87
Humidity Setpoint Source Selection Submenu Screens 96

I

IntelliPak 7
IntelliPak™ I 7
IntelliPak™ II 7
Interprocessor Communications Bridge 10
IPCB 10, 153

K

Key - Auto 13
Key - Cancel 12
Key - Configuration 12
Key - Custom 13
Key - Decrement – (Minus) 13
Key - Diagnostics 12
Key - Enter 12
Key - Increment + (Plus) 12
Key - Next 13
Key - Previous 13
Key - Service Mode 12
Key - Setpoints 12
Key - Setup 12
Key - Status 11
Key - Stop 13
Key - Test Start 13

L

LCI-I 10
LHI 10, 150
List – Auto Diagnostics 118
List – GBAS Alarm Output Assign. 71
List – GBAS Analog Output Assign. 74
List – GBAS Setpoint Assign. 71
List – History Diagnostics 119
List – Information Diagnostics 119
List – Manual Diagnostics 117
Local Hardwired Input Status Submenu Screens 49
LonTalk® 7, 10, 66
Low Ambient Compressor Lockout 7
Low Vi Compressor Operation 7

Index

M

MCM 9, 123, 124, 125, 126, 128, 132, 133, 134, 151
MDM 9, 135, 153
Menu Keys Overview 11
Modulating Dehumidification Module 9
Module I/O Descriptions - ECEM 151
Module I/O Descriptions - GBAS(10VDC) 152
Module I/O Descriptions - GBAS(5VDC) 152
Module I/O Descriptions - HEAT 151
Module I/O Descriptions - IPCB 153
Module I/O Descriptions - LHI or RHI 150
Module I/O Descriptions - MCM 151
Module I/O Descriptions - MDM 153
Module I/O Descriptions - MPM 153
Module I/O Descriptions - RTM 150
Module I/O Descriptions - VCM 151
Module I/O Descriptions - VOM 151
Module I/O Descriptions List 150
MPM 9, 122, 124, 126, 128, 132, 134, 135, 141, 153
Multi Purpose Module 9

N

Night SetBack (NSB) 8
No Configuration 16
NSB 136

O

Outside Air Control Submenu Screens 89
Outside Air Ventilation Setup Submenu Screens 63
Outside Air Ventilation Status Submenu Screens 36

P

Password Protected Screens 24

R

Reference Enthalpy 8
Remote Human Interface 8
Reset Amount Maximum 8
Reset End Temperature 8
Reset Start Temperature 8
Return Fan Control 8
Return Fan Plenum Pressure 8
Return Fan Status Submenu Screens 38
Return Plenum Pressure High Limit 8
RHI 10, 150
Rooftop Module 9
RTM 9, 122, 127, 129, 134, 135, 136, 137, 138, 139, 140, 141, 142, 143, 144, 145, 146, 147, 148, 150
RTM Alarm Output Assignment Screens 75

S

SCM 9, 141
Screen Navigation Procedure 25

Sensor Source Selection Setup Submenu Screens 62
SERVICE TEST MODE Menu 107
SETPOINT Menu 86
Setpoint Source Selection Submenu Screens 94
SETUP Menu 54
Space Pressure 8
STATUS Menus 26
Supply Air Pressure 8
Supply Air Pressure High Limit 8
Supply Air Temperature Control Point 8
Supply Air Temperature Reset 8
Supply Air Tempering 8

T

Table 1 - Acronyms 5
Table 12 - Module I/O Descriptions 150
Table 7 - Sump Drain Valve States 110
Target Setpoints 8
Temperature Input Calibration Screens 76
Temperature Input Status Submenu Screens 48
Top Level Configuration Screen 98
Top Level Service Mode Screen 107
Top Level Setpoints Screen 86
Top Level Setup Screen 54
Top Level Status Screen 26

U

UCM Control System Overview 8
Unit Off or Stopped Command 15
Unit On Command 15
Unit Operation Keys Overview 13

V

Variable Speed Module 10
VAV Control Functions Setup Submenu Screens 57
VCM 9, 123, 135, 148, 149, 151
Ventilation Control Module 9
Ventilation Override Menu Screens 69
Ventilation Override Mode Definitions 67
Ventilation Override Module 10
VOM 10, 149, 151
VOM Active 16
VOM Mode A - (Unit Off) 67
VOM Mode B - (Pressurize) 67
VOM Mode C - (Exhaust) 68
VOM Mode D - (Purge) 68
VOM Mode E - (Purge with Duct Pressure Control) 68
VSM 10



Trane optimizes the performance of homes and buildings around the world. A business of Ingersoll Rand, the leader in creating and sustaining safe, comfortable and energy efficient environments, Trane offers a broad portfolio of advanced controls and HVAC systems, comprehensive building services, and parts. For more information, visit www.Trane.com.

Trane has a policy of continuous product and product data improvement and reserves the right to change design and specifications without notice.

© 2014 Trane All rights reserved
RT-SVP07D-EN 22 Jul 2014
Supersedes RT-SVP07C-EN (25 Jun 2013)

We are committed to using environmentally
conscious print practices that reduce waste.

