

Table 1. Components

Wired remote control	Cable	Cable clamps (3)	M4X16 screws (5)	User manual (1)	Installation manual (1)	U terminals (6)

Important: Environmental Concerns! Scientific research has shown that certain man-made chemicals can affect the earth's naturally occurring stratospheric ozone layer when released to the atmosphere. In particular, several of the identified chemicals that may affect the ozone layer are refrigerants that contain Chlorine, Fluorine and Carbon (CFCs) and those containing Hydrogen, Chlorine, Fluorine and Carbon (HCFCs). Not all refrigerants containing these compounds have the same potential impact to the environment. Trane advocates the responsible handling of all refrigerants—including industry replacements for CFCs such as HCFCs and HCFCs.

Important: Responsible Refrigerant Practices! Trane believes that responsible refrigerant practices are important to the environment, our customers, and the air conditioning industry. All technicians who handle refrigerants must be certified. The Federal Clean Air Act (Section 608) sets forth the requirements for handling, reclaiming, recovering and recycling of certain refrigerants and the equipment that is used in these service procedures. In addition, some states or municipalities may have additional requirements that must also be adhered to for responsible management of refrigerants. Know the applicable laws and follow them.

! SAFETY WARNING

Only qualified personnel should install and service the equipment. The installation, starting up, and servicing of heating, ventilating, and air-conditioning equipment can be hazardous and requires specific knowledge and training. Improperly installed, adjusted or altered equipment by an unqualified person could result in death or serious injury. When working on the equipment, observe all precautions in the literature and on the tags, stickers, and labels that are attached to the equipment.

! WARNING Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

! CAUTION Indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury. It could also be used to alert against unsafe practices.

! NOTICE: Indicates a situation that could result in equipment or property damage only accidents.

August 2014 © 2014 Trane All Rights Reserved


VRF-SVN59B-EN



UNITS: inch (mm)

2. Arrange the power cable and the communication cable so that they fit in the housing along the edges of the back cover.


If you need more space, this panel can be removed.
Example with un concealed cable
4 (102)



Example with concealed cable
6 (152)

Screw holes

3. Firmly secure the back cover of the remote control to the wall using the three provided screws.



Installation Instructions

Variable Refrigerant Flow (VRF) System Wired Remote Control

Model Number: TVCTRLTWRWD01T, TVCTRLTWRWD01A

! SAFETY WARNING

Installing/servicing this unit could result in exposure to electrical, mechanical and chemical hazards. Before installing/servicing this unit, technicians MUST put on all Personal Protective Equipment (PPE) recommended for the work being undertaken. ALWAYS refer to appropriate MSDS sheets and OSHA guidelines for proper PPE. When working with or around hazardous chemicals, ALWAYS refer to the appropriate MSDS sheets and OSHA guidelines for information on allowable personal exposure levels, proper respiratory protection and handling recommendations. If there is a risk of arc or flash, technicians MUST put on all necessary Personal Protective Equipment (PPE) in accordance with NFPA70E for arcflash protection PRIOR to servicing the unit. Failure to follow recommendations could result in death or serious injury.

! WARNING Proper Field Wiring and Grounding Required!
All field wiring MUST be performed by qualified personnel. Improperly installed and grounded field wiring poses FIRE and ELECTROCUTION hazards. To avoid these hazards, you MUST follow requirements for field wiring installation and grounding as described in NEC and your local/state electrical codes. Failure to follow code could result in death or serious injury.

! PERSONAL PROTECTIVE EQUIPMENT REQUIRED!

Installing/servicing this unit could result in exposure to electrical, mechanical and chemical hazards. Before installing/servicing this unit, technicians MUST put on all Personal Protective Equipment (PPE) recommended for the work being undertaken. ALWAYS refer to appropriate MSDS sheets and OSHA guidelines for proper PPE. When working with or around hazardous chemicals, ALWAYS refer to the appropriate MSDS sheets and OSHA guidelines for information on allowable personal exposure levels, proper respiratory protection and handling recommendations. If there is a risk of arc or flash, technicians MUST put on all necessary Personal Protective Equipment (PPE) in accordance with NFPA70E for arcflash protection PRIOR to servicing the unit. Failure to follow recommendations could result in death or serious injury.

! WARNING Proper Field Wiring and Grounding Required!
All field wiring MUST be performed by qualified personnel. Improperly installed and grounded field wiring poses FIRE and ELECTROCUTION hazards. To avoid these hazards, you MUST follow requirements for field wiring installation and grounding as described in NEC and your local/state electrical codes. Failure to follow code could result in death or serious injury.

! WIRING

Observe the following requirements and precautions when making electrical connections.

! WARNING


Hazardous Voltage! Disconnect all electric power, including remote disconnects before servicing. Follow proper lockout/tagout procedures to ensure the power can not be inadvertently energized. Failure to disconnect power before servicing could result in death or serious injury.

- Make all electrical connections in accordance with electrical codes and ordinances.
- If you install the wired remote control with thermostat wire, remove 12 in. (30 cm) of the cable sheath and install only two of the conductors. The recommended wire size is AWG 18.
- Use either the provided U-terminals or U-terminals that match the specifications of those provided.
- Use an appropriate screwdriver for tightening the terminal screws. A screwdriver with a small head will strip the head and make proper tightening impossible.
- Over-tightening the terminal screws may break them.
- Tightening torque for M4 screws: 0.86–1.06 lb/ft (12.0–14.7 kgf·cm).

! INSTALLATION


Mounting the Unit

1. Insert a flat head screwdriver into the square groove at the center top of the remote control. Pull up the front cover to separate it from the back cover.



! REASSEMBLING THE DEVICE


Reassemble the wired remote control by aligning the front cover with the top of the back cover and then tilting it downward, as shown in the figure to the left. After replacing the cover, confirm that no wires are stuck in the gap between the front and back covers.



! WIRING FOR INDIVIDUAL CONTROL

Individual control refers to the use of one wired remote control for controlling one indoor unit, as shown in Figure 3.


Figure 3. Wired remote control: Individual control example



! CONNECTING COMMUNICATION WIRING

Connect communication wiring to the wired remote control at terminals F3, F4 and to the indoor unit at terminals F3, F4.

Best Practice: Maintain consistent polarity with wiring connections (F3 to F3, F4 to F4) to minimize troubleshooting time.



! ARRANGING THE POWER CABLE AND COMMUNICATION CABLE

Reassemble the wired remote control by aligning the front cover with the top of the back cover and then tilting it downward, as shown in the figure to the left. After replacing the cover, confirm that no wires are stuck in the gap between the front and back covers.

! REASSEMBLING THE DEVICE

Reassemble the wired remote control by aligning the front cover with the top of the back cover and then tilting it downward, as shown in the figure to the left. After replacing the cover, confirm that no wires are stuck in the gap between the front and back covers.

! WIRING

Reassemble the wired remote control by aligning the front cover with the top of the back cover and then tilting it downward, as shown in the figure to the left. After replacing the cover, confirm that no wires are stuck in the gap between the front and back covers.

! TIGHTENING TORQUE FOR TERMINAL SCREWS

Reassemble the wired remote control by aligning the front cover with the top of the back cover and then tilting it downward, as shown in the figure to the left. After replacing the cover, confirm that no wires are stuck in the gap between the front and back covers.


Wiring for Group Control

Group control refers to the use of one wired remote control to control multiple indoor units.

- A maximum of 16 indoor units can be controlled as a group.
- All indoor units in the group must be connected to a wired remote control.

Examples of two different scenarios are shown in Figure 4 and Figure 5.

Figure 4. Wired remote control: Group control with multiple indoor units connected to one outdoor unit



Using Two Wired Remote Controls for Individual or Group Control

Two wired remote controls can control one indoor unit or a group of indoor units.

- In this application, one wired remote control must be configured as a master and one wired remote control must be configured as a slave. (Refer to the Configuration section in the indoor unit manual.)

Figure 6. Two wired remote controls used for individual or group control





Figure 7. Indoor unit tracking in progress



Configuration

To configure or verify option settings on a wired remote control, use the following procedure. Refer to Table 2 for option descriptions and corresponding menu codes.

- If the unit does not support the function, "NONE" will be displayed.
- In configuration mode, temperature value appear in Celsius.

Table 2. Option settings/values (continued)

Main menu code	Sub-menu code	Option description	Digit	Factory default option setting/value	Option setting
		Use of drain pump	2	—	0: Not used, 1: Use
		Use of electric heater	3	—	0: Not used, 1: Use
		Use of hot water coil	4	—	0: Not used, 1: Use
		Use of external control	1	—	0: Not used, 1: Use
		Use of RPM compensation	2	—	0: Not used, 1: Use
		Filter time	3	—	0: 2000 hours, 1: 1000 hours
		Indoor unit option checking (2)	6	—	0: 0-2°C, 1-5°C
		Indoor unit main address	3	1,2	Main address (00-3F, hexadecimal)
		Indoor unit main address setting	4	—	0: 0/80 steps, 1: 1/80 steps
		EEV stop step in heating	5	—	EEV stop step in
		Indoor unit room temperature compensation	4	—	Indoor unit room temperature compensation
		Indoor unit room temperature	1	—	Indoor unit room temperature
		Indoor unit EVAP IN temperature	2	—	Indoor unit EVAP IN temperature
		Indoor unit EVAP OUT temperature	3	—	Indoor unit EVAP OUT temperature
		Indoor unit EV step	4	—	Indoor unit EV step
		Indoor unit Use of central control	1	—	Indoor unit Use of central control
		Indoor unit option checking (1)	5	—	Indoor unit option checking (1)


Table 2. Option settings/values (continued)

Main menu code	Sub-menu code	Option description	Digit	Factory default option setting/value	Option setting
		Temperature control reference	1	1,2,3	0: -9-40°C (16-104°F)
		Room temperature compensation	5	4,5,6	0: 9.9-9.9°C Note: Increments of 0.1°C.
		Number of connected units	6	1,2	0-16
		Not used	3,4	—	—
		Temperature increment/decrement (°C)	7	0: 1°C, 1: 0.5°C, 2: 0.1°C	0: 1°C, 1: 0.5°C, 2: 0.1°C
		Temperature sensor selection	1	0: Indoor unit 1: Wired remote control	8: Not used
		Use of average temperature	2	0: Not used, 1: Use	0: Reset has no effect on settings 1: Reset changes settings to factory defaults
		Use of Auto mode	3	0: Not used, 1: Use	Note: This setting determines what occurs when a system reset is activated.
		Temperature display (2)	4	0: Set temperature 1: Room temperature	0: 0: 1-6 1: 1-6
		Not used	5	—	Software version
		Blade 1	1	0: Unlock, 1: Lock	1: Indoor unit room temperature
		Blade 2	2	0: Unlock, 1: Lock	2: Indoor unit EVAP IN temperature
		Blade 3	3	0: Unlock, 1: Lock	3: Indoor unit EVAP OUT temperature
		Blade 4	4	0: Unlock, 1: Lock	4: Indoor unit EV step
		Not used	3	—	Indoor unit Use of central control
		Not used	4	—	Indoor unit option checking (1)

Table 2. Option settings/values

Main menu code	Sub-menu code	Option description	Digit	Factory default option setting/value	Option setting
		Cooling/Heating selection	1	0: Cooling/Heating only	0: Cooling/Heating only
		Use of wireless remote control	2	1: 0: Not used, 1: Use	1: 0: Not used, 1: Use
		Master/slave wired remote control option settings (1)	3	0: Master, 1: Slave	0: Master, 1: Slave
		Temperature unit	4	0: Celsius (°C), 1: Fahrenheit (°F)	0: Celsius (°C), 1: Fahrenheit (°F)
		Temperature sensor selection	1	0: Indoor unit 1: Wired remote control	8: Not used
		Use of average temperature	2	0: Not used, 1: Use	0: Reset has no effect on settings 1: Reset changes settings to factory defaults
		Use of Auto mode	3	0: Not used, 1: Use	Note: This setting determines what occurs when a system reset is activated.
		Temperature display (2)	4	0: Set temperature 1: Room temperature	2: 1-6
		Not used	5	—	Software version
		Blade 1	1	0: Unlock, 1: Lock	1: Indoor unit room temperature
		Blade 2	2	0: Unlock, 1: Lock	2: Indoor unit EVAP IN temperature
		Blade 3	3	0: Unlock, 1: Lock	3: Indoor unit EVAP OUT temperature
		Blade 4	4	0: Unlock, 1: Lock	4: Indoor unit EV step
		Not used	3	—	Indoor unit Use of central control
		Not used	4	—	Indoor unit option checking (1)

Table 2. Option settings/values



1. Press the **Set** and **Esc** buttons simultaneously for > 3 seconds. The main menu will appear as shown in Figure 8.

Figure 8. Wired remote control LCD display




Table 2. Option settings/values

Main menu code	Sub-menu code	Option description	Digit	Factory default option setting/value	Option setting
		Indoor unit room temperature compensation	4	—	0: 0-2000 hours, 1: 1000 hours
		Indoor unit room temperature	5	—	0: 0-2°C, 1-5°C
		Indoor unit EVAP IN temperature	6	—	Main address (00-3F, hexadecimal)
		Indoor unit EVAP OUT temperature	7	—	Indoor unit main address setting
		Indoor unit room temperature	8	—	Indoor unit room temperature
		Indoor unit EVAP IN temperature	9	—	Indoor unit EVAP IN temperature
		Indoor unit EVAP OUT temperature	10	—	Indoor unit EVAP OUT temperature
		Indoor unit room temperature	11	—	Indoor unit room temperature
		Indoor unit EVAP IN temperature	12	—	Indoor unit EVAP IN temperature
		Indoor unit EVAP OUT temperature	13	—	Indoor unit EVAP OUT temperature
		Indoor unit room temperature	14	—	Indoor unit room temperature
		Indoor unit EVAP IN temperature	15	—	Indoor unit EVAP IN temperature
		Indoor unit EVAP OUT temperature	16	—	Indoor unit EVAP OUT temperature
		Indoor unit room temperature	17	—	Indoor unit room temperature
		Indoor unit EVAP IN temperature	18	—	Indoor unit EVAP IN temperature
		Indoor unit EVAP OUT temperature	19	—	Indoor unit EVAP OUT temperature
		Indoor unit room temperature	20	—	Indoor unit room temperature
		Indoor unit EVAP IN temperature	21	—	Indoor unit EVAP IN temperature
		Indoor unit EVAP OUT temperature	22	—	Indoor unit EVAP OUT temperature
		Indoor unit room temperature	23	—	Indoor unit room temperature
		Indoor unit EVAP IN temperature	24	—	Indoor unit EVAP IN temperature
		Indoor unit EVAP OUT temperature	25	—	Indoor unit EVAP OUT temperature
		Indoor unit room temperature	26	—	Indoor unit room temperature
		Indoor unit EVAP IN temperature	27	—	Indoor unit EVAP IN temperature
		Indoor unit EVAP OUT temperature	28	—	Indoor unit EVAP OUT temperature
		Indoor unit room temperature	29	—	Indoor unit room temperature
		Indoor unit EVAP IN temperature	30	—	Indoor unit EVAP IN temperature
		Indoor unit EVAP OUT temperature	31	—	Indoor unit EVAP OUT temperature
		Indoor unit room temperature	32	—	Indoor unit room temperature
		Indoor unit EVAP IN temperature	33	—	Indoor unit EVAP IN temperature
		Indoor unit EVAP OUT temperature	34	—	Indoor unit EVAP OUT temperature
		Indoor unit room temperature	35	—	Indoor unit room temperature
		Indoor unit EVAP IN temperature	36	—	Indoor unit EVAP IN temperature
		Indoor unit EVAP OUT temperature	37	—	Indoor unit EVAP OUT temperature
		Indoor unit room temperature	38	—	Indoor unit room temperature
		Indoor unit EVAP IN temperature	39	—	Indoor unit EVAP IN temperature
		Indoor unit EVAP OUT temperature	40	—	Indoor unit EVAP OUT temperature
		Indoor unit room temperature	41	—	Indoor unit room temperature
		Indoor unit EVAP IN temperature	42	—	Indoor unit EVAP IN temperature
		Indoor unit EVAP OUT temperature	43	—	Indoor unit EVAP OUT temperature
		Indoor unit room temperature	44	—	Indoor unit room temperature
		Indoor unit EVAP IN temperature	45	—	Indoor unit EVAP IN temperature
		Indoor unit EVAP OUT temperature	46	—	Indoor unit EVAP OUT temperature
		Indoor unit room temperature	47	—	Indoor unit room temperature
		Indoor unit EVAP IN temperature	48	—	Indoor unit EVAP IN temperature
		Indoor unit EVAP OUT temperature	49	—	Indoor unit EVAP OUT temperature
		Indoor unit room temperature	50	—	Indoor unit room temperature
		Indoor unit EVAP IN temperature	51	—	Indoor unit EVAP IN temperature
		Indoor unit EVAP OUT temperature	52	—	Indoor unit EVAP OUT temperature
		Indoor unit room temperature	53	—	Indoor unit room temperature
		Indoor unit EVAP IN temperature	54	—	Indoor unit EVAP IN temperature
		Indoor unit EVAP OUT temperature	55	—	Indoor unit EVAP OUT temperature
		Indoor unit room temperature	56	—	Indoor unit room temperature
		Indoor unit EVAP IN temperature	57		

