
INDOOR UNIT BRANCH PIPE INSTALLATION MANUAL

Thank you very much for purchasing our air conditioner, Before using your air conditioner, please read this manual carefully and keep it for future reference.

Branch List


Name	Low-pressure gas side joints	High-pressure gas side joints	Liquid side joints	Converter pipe	Heat insulation material
TRDK057 HRU	10:15.9	10:12.7	10:9.53 00:12.7 10:12.7 10:12.7 10:12.7 10:12.7 10:12.7		(3 sets)
TRDK112 HRU	10:15.9 00:22.2 10:22.2 10:22.2 10:22.2 10:22.2	10:15.7 10:15.9 10:15.9 10:19.1 10:19.1 10:19.1	10:9.53 00:12.7 10:12.7 10:12.7 10:12.7 10:12.7 10:12.7		(3 sets)
TRDK242 HRU		10115.9 1011	10:15.9 00:19.1 10:19.1 10:19.1 10:19.1 10:19.1	00:12.7 00:12.7 (Liquid side used)	(3 sets)
TRDK354 HRU	D1 B. 1 1 1 1 1 1 1 1 1		10:19.72 10:15.9 10:19.1 10:19.1 10:19.1 10:19.1 10:19.1	10:22.2 10:15.9 00:19.1 00:19.1 (Liquid side used)	(3 sets)
TRDK573 HRU	10:34.9 10:41.3 10:44.5 10:44.5	01:31:0 01:31:0 01:31:0 01:31:0 01:31:0 01:31:0 01:31:0 01:31:0 01:31:0 01:31:0	10:15.9 10:19.1 10:22.2 10:22.2 10:22.2 10:22.2		(3 sets)



Installation Notices

- 1) Select the branch pipes' model according to the Model Selection Guide and the downstream indoor
- 2) According to the actual piping size and cut off the needless parts with special tools such as cutter, take the TRDK354HRU liquid side for example and the operating steps as follow:
- a. When selecting model TRDK354HRU, the actual object as display in Fig.1, and then suppose that the present using pipe $is\Phi15.9$, then as display in Fig.2, cut the welded pipe of the branch pipe
- b.As display in Fig.2, cut the standalone connecting pipe.
- c.weld the branch pipe components with the field pipes.
- 3) Particularly notice the followings:
- When the actual pipe size matches with the un-welded side of U-shape three direct links, weld the pipe with the U-shape three direct links directly.






Choice

Branch pipes for indoor unit

Capacity of downstream indoor units A (×100W)	Name of indoor unit branch pipe	Low-pressure gas pipe (mm)	High-pressure gas pipe (mm)	Liquid pipe (mm)
A<168	TRDK057HRU	Ф15.9	Ф12.7	Ф9.5
168≤A<224	TDDK440UDU	Ф19.1	Ф15.9	Ф9.5
224≤A<330	TRDK112HRU	Ф22.2	Ф19.1	Ф9.5
330≤A<470	TRDK242HRU	Ф28.6	Ф19.1	Ф12.7
470≤A<710	TRDK242HRU	Ф28.6	Ф28.6	Ф15.9
710≤A<1040	TRDK354HRU	Ф34.9	Ф28.6	Ф19.1
1040≤A	TRDK573HRU	Ф41.3	Ф28.6	Ф19.1


Installation Precaution

Pay attention to the distance of straight horizontal pipe.



- a. The straight horizontal pipe's distance between two adjacent branch pipes should ≥0.5m.
- b.Distance between two adjacent branches should ≥0.5m.
- c.The straight horizontal pipe's distance which outdoor unit connecting behind the branch pipe should ≥0.5m.


Horizontally Placing Branch Pipe



Heat insulation

Be sure to insulate the brahches against heat

1) Example of connected branch.



2) Use the supplied heat insulation material to insulate the branches against heat.



heat insulation material(supplied)

3) Apply the heat insulation material and seal all connections with tape.

